
Arduino-Pico Documentation

Release 5.6.1

Earle F. Philhower, III

Jul 01, 2026

CONTENTS:

1	Getting Help	3
2	Contributing and Porting to the Core	5
2.1	Contributing to the Core (Pull Requests)	5
2.2	Adding a New Board	5
2.3	Porting Libraries and Applications to the Core	6
3	Installation	9
3.1	Installing via Arduino Boards Manager	9
3.2	Installing via Arduino CLI	10
3.3	Installing via GIT	10
3.4	Installing both Arduino and CMake	11
3.5	Uploading Sketches	11
3.6	Uploading the First Sketch	11
3.7	Windows 7 Driver Notes	11
3.8	Windows 7 Installation Problems	12
3.9	Uploading Filesystem Images	12
3.10	Uploading Sketches with Picotool	13
3.11	Uploading Sketches with Picoprobe	13
3.12	Uploading Sketches with OpenOCD	14
3.13	Debugging with Picoprobe/Debugprobe, OpenOCD, and GDB	14
4	IDE Menus	15
4.1	Board	15
4.2	Flash Size	15
4.3	CPU Speed	15
4.4	Debug Port and Debug Level	15
4.5	Generic RP2040 Support	15
4.6	Boot Stage 2 Options for Generic RP2040	15
5	Using this core with PlatformIO	17
5.1	What is PlatformIO?	17
5.2	Important steps for Windows users, before installing	19
5.3	Updating platformio.ini to use the proper platform	20
5.4	Deprecation warnings	20
5.5	Selecting the new core	21
5.6	Flash size	21
5.7	PSRAM size	21
5.8	PSRAM chip select (CS)	22
5.9	Boot2 Source	22

5.10	CPU Speed	22
5.11	Debug Port	22
5.12	Debug Level	23
5.13	C++ Exceptions	23
5.14	Stack Protector	23
5.15	RTTI	23
5.16	USB Stack	24
5.17	USB Customization	24
5.18	IP Stack	24
5.19	Bluetooth Stack	24
5.20	FreeRTOS	24
5.21	Selecting a different core version	25
5.22	Selecting the CPU architecture	25
5.23	Examples	25
5.24	Debugging	25
5.25	Filesystem Uploading	27
6	Pin Assignments	29
6.1	I2S	29
6.2	Serial1 (UART0), Serial2 (UART1)	29
6.3	SPI (SPI0), SPI1 (SPI1)	29
6.4	Wire (I2C0), Wire1 (I2C1)	29
7	RP2040 Helper Class	31
7.1	Core Internals	31
7.2	Hardware Watchdog	31
7.3	Memory Information	32
7.4	Hardware Identification	32
7.5	Bootloader	32
7.6	DMA-based MEMCPY	32
8	Analog I/O	35
8.1	Analog Input	35
8.2	Analog Outputs	35
8.3	Analog Output Restrictions	35
9	Digital I/O	37
9.1	Board-Specific Pins	37
9.2	Pin Notation	37
9.3	Input Modes	37
9.4	Output Modes (Pad Strength)	37
9.5	Tone/noTone	37
10	BOOTSEL Button	39
11	EEPROM Library	41
11.1	EEPROM Class API	41
11.2	EEPROM Examples	42
12	I2S (Digital Audio) Audio Library	43
12.1	I2S Class API	43
12.2	Sample Writing/Reading API	46
12.3	Note About 24-bit Samples	47
13	PWM Audio Library	49

13.1	PWM Class API	49
14	ADC Input Library	51
14.1	ADC Input API	51
15	Serial Ports (USB, UART, and BLE “Nordic SPP Service”)	53
15.1	Inversion	53
15.2	Nordic SPP Serial Service	54
15.3	RP2040 Specific SerialUSB methods	54
16	“SoftwareSerial” PIO-based UART	55
16.1	Inversion	55
17	SoftwareSerial Emulation	57
18	Servo Library	59
18.1	Pulse Width Defaults	59
19	SPI Master (Serial Peripheral Interface)	61
20	Software SPI (Master Only)	63
21	SPI Slave (SPISlave)	65
22	Asynchronous Operation	67
22.1	bool transferAsync(const void *send, void *recv, size_t bytes)	67
22.2	bool finishedAsync()	67
22.3	void abortAsync()	67
23	Examples	69
24	Wire (I2C Master and Slave)	71
24.1	Asynchronous Operation	71
25	File Systems	73
25.1	Flash Layout	73
25.2	Compatible Filesystem APIs	73
25.3	FatFS File System Caveats and Warnings	74
25.4	LittleFS File System Limitations	74
25.5	Uploading Files to the LittleFS File System on IDE 1.x (RP2040 only)	74
25.6	Uploading Files to the LittleFS File System on IDE 2.x (RP2040 and RP2350)	75
25.7	Downloading Files from a LittleFS System	75
25.8	SD Library Information	75
25.9	Using Second SPI port for SD	75
25.10	Enabling SDIO operation for SD	76
25.11	Using VFS (Virtual File System) for POSIX support	76
25.12	File system object (LittleFS/SD/SDFS/FatFS)	77
25.13	Filesystem information structure	79
25.14	Directory object (Dir)	80
25.15	File object	81
26	USB (Arduino and Adafruit_TinyUSB)	85
26.1	Pico SDK USB Support	85
26.2	USB class	85
26.3	Dynamic USB Configuration	85
26.4	HID Polling Interval	86

26.5	Ethernet over USB	86
26.6	Native TinyUSB Sketches	86
26.7	Adafruit TinyUSB Arduino Support	87
26.8	Adafruit TinyUSB Configuration and Quirks	87
27	Multicore Processing	89
27.1	Core 1 Operation	89
27.2	Stack Sizes	89
27.3	Pausing Cores	89
27.4	Communicating Between Cores	90
28	Semihosting Support	91
28.1	Running Semihosting on the Development Host	91
28.2	SerialSemi - Serial over Semihosting	91
28.3	SemiFS - Host filesystem access through Semihosting	91
29	Profiling Applications with GPROF	93
29.1	Enabling Profiling in an Application	93
29.2	Collecting and Analyzing Profile Data	94
30	RP2350 Specific Notes	95
30.1	ARM and RISC-V Modes	95
30.2	P2350-E9 Errata (“Increased leakage current on Bank 0 GPIO when pad input is enabled”)	95
31	RP2350 PSRAM Support	97
31.1	Using PSRAM for regular variables	97
31.2	Using PSRAM for dynamic allocations	97
31.3	Checking on PSRAM space	98
32	Bluetooth on PicoW Support	99
32.1	Enabling Bluetooth	99
32.2	Included Bluetooth Libraries	99
32.3	Writing Custom Bluetooth Applications	99
32.4	Locking Requirements	99
33	Bluetooth HID Master	101
33.1	BTDeviceInfo Class	101
33.2	BluetoothHCI Class	101
33.3	BluetoothHIDMaster Operation	101
33.4	Callback Event Handlers	102
33.5	BluetoothHIDMaster Class	103
34	Bluetooth Audio (A2DP Source and Sink)	105
34.1	A2DPSink	105
34.2	A2DPSource	105
35	BLE (Bluetooth Low Energy) Server/Client	107
35.1	General Architecture	107
35.2	General Bluetooth Support Classes	108
35.3	BLE (Bluetooth Low Energy) Base	109
35.4	Accessing the Global BLEServer or BLEClient	109
35.5	Configuring BLE Advertising	109
35.6	Finding BLE Servers to Connect To	110
35.7	Implementing a BLE Server (peripheral/device)	110
35.8	Implementing a BLE Client (BLE Central)	113

35.9	BLE Beacons	115
35.10	BLE Battery Service	115
35.11	BLE Serial UART (Nordic SPP Service)	115
36	SingleFileDrive	117
36.1	Callbacks, Interrupt Safety, and File Operations	117
36.2	Using SingleFileDrive	117
37	FatFSUSB	119
37.1	Callbacks, Interrupt Safety, and File Operations	119
38	FreeRTOS SMP	121
38.1	Enabling FreeRTOS	121
38.2	Configuration and Predefined Tasks	121
38.3	Caveats	121
38.4	More Information	122
39	WiFi (Raspberry Pi Pico W) Support	123
39.1	Non-Raspberry Pi WiFi Support	123
39.2	Supported Features	123
39.3	Important Information	123
39.4	Special Thanks	124
40	EthernetLWIP (Wired Ethernet) Support	125
40.1	Supported Wired Ethernet Modules	125
40.2	Enabling Wired Ethernet	125
40.3	Adjusting LWIP Polling	126
40.4	Using Interrupt-Driven Handling	126
40.5	Adjusting SPI Speed	126
40.6	Using the WIZnet W5100S-EVB-Pico	127
40.7	Example Code	127
40.8	Caveats	127
40.9	Special Thanks	127
41	Ethernet over USB	129
41.1	USB Device configuration on Raspberry Pi Pico	129
41.2	USB Host configuration on Windows	130
41.3	USB Host configuration on Linux	130
41.4	Special Thanks	133
42	WiFiClient	135
42.1	flush and stop	135
42.2	setNoDelay	135
42.3	getNoDelay	136
42.4	setSync	136
42.5	getSync	136
42.6	setDefaultNoDelay and setDefaultSync	136
42.7	getDefaultNoDelay and getDefaultSync	136
42.8	Other Function Calls	136
43	Server Class	139
43.1	accept	139
43.2	available	139
43.3	write (write to all clients) not supported	139
43.4	setNoDelay	140

43.5	Other Function Calls	140
44	UDP Class	141
45	Network Time Protocol (NTP)	143
45.1	bool NTP.waitSet(uint32_t timeout)	143
45.2	bool NTP.waitSet(void (*cb)(), uint32_t timeout)	144
46	BearSSL WiFi Classes	145
46.1	CPU Requirements	145
46.2	Memory Requirements	145
46.3	Object Lifetimes	145
46.4	TLS and HTTPS Basics	146
46.5	Public and Private Keys	146
46.6	TLS Sessions	146
46.7	X.509 Certificate(s)	147
46.8	Certificate Stores	147
46.9	Supported Crypto	147
47	WiFiClientSecure Class	149
47.1	Validating X509 Certificates (Am I talking to the server I think I'm talking to?)	149
47.2	Client Certificates (Proving I'm who I say I am to the server)	150
47.3	MFLN or Maximum Fragment Length Negotiation (Saving RAM)	150
47.4	Sessions (Resuming connections fast)	151
47.5	Errors	151
47.6	Limiting Ciphers (New connections faster)	151
47.7	Limiting TLS(SSL) Versions	151
47.8	setTLSConnectTimeout(int connectTimeout)	151
47.9	ESP32 Compatibility	152
48	WiFiServerSecure Class	153
48.1	setBufferSizes(int recv, int xmit)	153
48.2	Setting Server Certificates	153
48.3	Client sessions (Resuming connections fast)	153
48.4	Requiring Client Certificates	154
49	HTTPClient Library	155
50	OTA Updates	157
50.1	Introduction	157
50.2	Compression	160
50.3	Uploading from the Arduino IDE	161
50.4	Password Protection	161
50.5	Web Browser	162
50.6	HTTP Server	162
50.7	Stream Interface	163
51	Libraries Ported/Optimized for the RP2040	165
52	Using the Raspberry Pi Pico SDK (PICO-SDK)	167
52.1	Included SDK	167
52.2	Multicore (CORE1) Processing	167
52.3	PIOASM (Compiling for the PIO processors)	167
53	Licensing and Credits	169

This is the documentation for the Raspberry Pi Pico Arduino core, Arduino-Pico. Arduino-Pico is a community port of Arduino to the RP2040 (Raspberry Pi Pico processor) and RP2350 (Raspberry Pi Pico 2 processor), intended to make it easier and more fun to use and program the Raspberry Pi Pico / RP2040 / RP2350 based boards.

This Arduino core uses a custom toolset with GCC 14.2 and Newlib 4.3 and doesn't require any system-installed prerequisites.

For the latest version, always check <https://github.com/earlephilhower/arduino-pico>

GETTING HELP

This is a community supported project and has multiple ways to get assistance. Posting complete details, in a polite and organized way will get the best response.

For bugs in the Core, or to submit patches, please use the [GitHub Issues](#) or [GitHub Pull Requests](#)

For general questions/discussions use either [GitHub Discussions](#) or live-chat with [gitter.im](#)

CONTRIBUTING AND PORTING TO THE CORE

First of all, thank you for contributing to the project. It's a lot of work keeping up with all the different uses of the RP2040, so the more people working on the code, the better. Your assistance can help the project succeed.

2.1 Contributing to the Core (Pull Requests)

We use the standard GitHub Pull Request model. If you're unfamiliar with it, this [guide](#) gives a simple overview of the process.

All pull requests have to pass a set of Continuous Integration (CI) checks which help make sure the code compiles under different configurations and has no spelling or style errors.

2.1.1 Tips for a Good Pull Request (PR)

All code in the core and libraries, except for INO sketches, uses a 4-space indent with cuddled brackets. When in doubt, copy your formatting from the surrounding code. You should install `astyle` and run `tests/restyle.sh` on your machine before committing and pushing any pull requests to ensure the formatting is correct.

Describe the change you're proposing and why it's important in your `git commit` message. If it fixes an open issue, place `Fixes #xxxx` (where `xxxx` is the issue number) in the message to link the two.

Try and only change one thing per pull request. That makes it easier to review and prioritize. Opening up a separate PR per change also helps keep track of them when release messages are generated.

2.2 Adding a New Board

Adding a new board requires:

- Updated `tools/makeboards.py` script
- Updated `boards.txt` file, generated by `makeboard.py`
- Updated `package_pico_index.template.json` file, generated by `makeboard.py`
- New `tools/json/BOARD_NAME.json` board file for Platform.IO
- New `variants/BOARD_NAME/pins_arduino.h` header defining the I/O pins

To add a new RP2040 board you will need to update the `tools/makeboards.py` script. Do *NOT* manually edit `boards.txt`, that file is machine generated. You will need to add a `MakeBoard` call at the end of the file. Please be sure to add your board so that it sorts alphabetically, starting with the company name and then the board name. Otherwise it is hard to find a specific board in the menu.

Run `python3 tools/makeboards.py` to update the `boards.txt` file and generate a Platform.IO JSON file in the `tools/json` directory.

Create a folder called `variants/BOARD_NAME` and place in a `pins_arduino.h` file in it that contains your default pin name mapping (i.e. SPI0/I pins, UART pins, LED_DEFAULT, etc.). Copying one of the existing ones as a template can make this task much simpler.

In your git commit be sure to add the newly generated `tools/json/XXX.json` file as well as the modified `makeboards` script and `boards.txt`, the new `pins_arduino.h` header you generated, and the Arduino packaging JSON `package/package_pico_index.template.json`. You should also add a note in the `README.md` file listing your new board.

Submit the updated commit as a PR and, if all goes well, your board will be in on the next core release.

2.3 Porting Libraries and Applications to the Core

We try and follow Arduino standards so, with luck, porting to this core should be relatively straightforward. The WiFi library and associates support libraries like `WebServer` are modeled after the ESP32 and ESP8266 versions of those libraries, combined with the “standard” Arduino WiFi one.

2.3.1 Compiler Defines for Porting

If you are adding RP2040 support to an existing library and need to isolate code that only runs on this core, use the following define.

```
#if defined(ARDUINO_ARCH_RP2040) && !defined(__MBED__)
~~~ your changes ~~~
#endif
```

2.3.2 Identifying RP2040, RP2350A, or RP2350B

To check if a board is an original RP2040

```
#if defined(PICO_RP2040)
...OG Pico code...
#endif
```

For RP2350(A or B):

```
#if defined(PICO_RP2350)
...Pico 2 code...
#endif
```

For only RP2350A variants (using the compile options, not the onboard ID register):

```
#if defined(PICO_RP2350A) && PICO_RP2350A
...RP2350A only code...
#endif
```

For only RP2350B variants (again, at compile time as identified by the selected board and not the chip ID register):

```
#if defined(PICO_RP2350A) && !PICO_RP2350A
...48-GPIO version code here
#endif
```

2.3.3 Library Architectures

After adding support in the code, libraries need their `library.properties` and `library.json` files updated to indicate support, or the IDE will not know your new code is compatible here.


Add `rp2040` to `architectures` (in `library.properties`) and `"rp2040"` to `platforms[]` (in `library.json`) to let the tools know. Note that even the RP2350 is identified as `rp2040` for this purpose.

INSTALLATION


The Arduino-Pico core can be installed using the Arduino IDE Boards Manager or using *git*. If you want to simply write programs for your RP2040 board, the Boards Manager installation will suffice, but if you want to try the latest pre-release versions and submit improvements, you will need the *git* installation.

3.1 Installing via Arduino Boards Manager

1. Open up the Arduino IDE and go to File->Preferences.
2. In the dialog that pops up, enter the following URL in the “Additional Boards Manager URLs” field: https://github.com/earlephilhower/arduino-pico/releases/download/global/package_rp2040_index.json



3. Hit OK to close the dialog.
4. Go to Tools->Boards->Board Manager in the IDE
5. Type “pico” in the search box and select “Add”:



3.1.1 Arduino IDE Installation Warning

Note for Windows Users: Please do not use the Windows Store version of the actual Arduino application because it has issues detecting attached Pico boards. Use the “Windows ZIP” or plain “Windows” executable (EXE) download direct from <https://arduino.cc>. and allow it to install any device drivers it suggests. Otherwise the Pico board may not be detected.

Note

Windows users with non-ASCII characters in their username (e.g., accented letters like Í, umlauts like ü, or characters like ñ): The ARM GCC toolchain (pqt-gcc) used by this core does not handle non-ASCII characters in Windows file paths. If your Windows username contains such characters (e.g., C:\Users\Íñigo instead of C:\Users\Inigo), compilation will fail with linker errors like `cannot open linker script file ... Invalid argument`. The recommended workaround is to create an additional local Windows user with an ASCII-only name and use that profile for RP2040/RP2350 development. See [issue #2689](#) for more details.

Note for Linux Users: If you installed the Arduino IDE using Flatpak, which is common in Pop!_OS, Fedora, and Mint, among others, you may need to configure Flatpak to allow the IDE access to files outside your home folder. The RP2040 device is sometimes mounted as a folder in /opt or /media, which Flatpak will prevent the Arduino IDE from accessing. For Arduino IDE V2, override the filesystem restriction using `flatpak override --user --filesystem=host cc.arduino.IDE2`. For For Arduino IDE < V2, use `flatpak override --user --filesystem=host cc.arduino.arduinoide`.

3.2 Installing via Arduino CLI

To install using the Arduino command line tool (arduino-cli):

```
arduino-cli config add board_manager.additional_urls https://github.com/earlephilhower/
↪arduino-pico/releases/download/global/package_rp2040_index.json
arduino-cli core update-index
arduino-cli core install rp2040:rp2040
```

To list the supported boards:

```
arduino-cli board listall | grep rp2040
```

3.3 Installing via GIT

To install via GIT (for latest and greatest versions):

```
mkdir -p ~/Arduino/hardware/pico
git clone https://github.com/earlephilhower/arduino-pico.git ~/Arduino/hardware/pico/
```

(continues on next page)

(continued from previous page)

```
→rp2040
cd ~/Arduino/hardware/pico/rp2040
git submodule update --init
cd pico-sdk
git submodule update --init
cd ../tools
python3 ./get.py
```

3.4 Installing both Arduino and CMake

Tom's Hardware presented a very nice writeup on installing *arduino-pico* on both Windows and Linux, available at [Tom's Hardware](#).

If you follow their step-by-step you will also have a fully functional *CMake*-based environment to build Pico apps on if you outgrow the Arduino ecosystem.

3.5 Uploading Sketches

To upload your first sketch, you will need to hold the BOOTSEL button down while plugging in the Pico to your computer. Then hit the upload button and the sketch should be transferred and start to run.

After the first upload, this should not be necessary as the *arduino-pico* core has auto-reset support. Select the appropriate serial port shown in the Arduino Tools->Port->Serial Port menu once (this setting will stick and does not need to be touched for multiple uploads). This selection allows the auto-reset tool to identify the proper device to reset. Then hit the upload button and your sketch should upload and run.

In some cases the Pico will encounter a hard hang and its USB port will not respond to the auto-reset request. Should this happen, just follow the initial procedure of holding the BOOTSEL button down while plugging in the Pico to enter the ROM bootloader.

3.6 Uploading the First Sketch


The first time you upload a sketch to a board, you'll need to use the built-in ROM bootloader to handle the upload and not a serial port.

1. Hold the BOOTSEL button while plugging in the board.
2. Select Tools->Port->UF2 Board from the menu.
3. Upload as normal.
4. After the board boots up, select the new serial port from the Tools->Port menu.

3.7 Windows 7 Driver Notes

Windows 10, Linux, and Mac will all support the Pico CDC/ACM USB serial port automatically. However, Windows 7 may not include the proper driver and therefore no detect the Pico for automatic uploads or the Serial Monitor.

For Windows 7, if this occurs, you can use *Zadig* <<https://zadig.akeo.ie/>> to install the appropriate driver. Select the USB ID of 2E8A and use the USB Serial (CDC) driver.



3.8 Windows 7 Installation Problems

When running MalwareBytes antivirus (or others) the scanner may lock the compiler or other toolchain executables, causing installation or build failures. (Thanks to @Andy2No)

Symptoms include:

- Access denied during update in the boards manager - affects the .exe files, because MalwareBytes has locked them.
- Access denied during compilation, to one of the .exe files - same reason.
- Can't delete the .exe files - they're locked by MalwareBytes.

A workaround is possible, involving setting the toolchain as an “excluded directory” and reinstalling.

1. In MalwareBytes Settings, click the Exclusions tab. Add an exclusion for the equivalent of this folder path:

C:\Users\{YOUR_USERNAME_HERE}\AppData\Local\Arduino15\packages\rp2040\tools\pqt-gcc\1.1.0-a-81a1771

2. Reboot to unlock the files.
3. Do the boards manager installation / upgrade again.
4. Set the board type, e.g. to Raspberry Pi Pico and check it can compile.

3.9 Uploading Filesystem Images

The onboard flash filesystem for the Pico, LittleFS, lets you upload a filesystem image from the sketch directory for your sketch to use. Download the needed plugin from

- *IDE 1.x*: <https://github.com/earlephilhower/arduino-pico-littlefs-plugin/releases>
- *IDE 2.x*: <https://github.com/earlephilhower/arduino-littlefs-upload/releases>

To install, follow the directions in

- *IDE 1.x*: <https://github.com/earlephilhower/arduino-pico-littlefs-plugin/blob/master/README.md>
- *IDE 2.x*: <https://github.com/earlephilhower/arduino-littlefs-upload/blob/main/README.md>

For detailed usage information, please check the repo documentation available at

- <https://arduino-pico.readthedocs.io/en/latest/fs.html>

3.10 Uploading Sketches with Picotool

Because the Picotool uses a custom device driver in the Pico to handle upload, when using the Upload Method->Picotool mode custom code needs to be run on the Pico which is not included by default for compatibility and code savings.

So for the first sketch you will need to rebuild (with the Upload Method->Picotool selected in them menus) and then manually hold down BOOTSEL and insert the Pico USB cable to enter the ROM bootloader.

After the initial upload, as long as the running binary was built using the Picotool upload method, then the normal upload process should work.

For Ubuntu and other Linux operating systems you may need to add the following lines to a new *udev* config file(99-picotool.rules) to allow normal users to access the special USB device the Pico exports:

```
echo 'SUBSYSTEM=="usb", ATTRS{idVendor}=="2e8a", ATTRS{idProduct}=="0003", MODE="660", ↵
↵GROUP="plugdev" | sudo tee -a /etc/udev/rules.d/98-Picotool.rules
echo 'SUBSYSTEM=="usb", ATTRS{idVendor}=="2e8a", ATTRS{idProduct}=="000a", MODE="660", ↵
↵GROUP="plugdev" | sudo tee -a /etc/udev/rules.d/98-Picotool.rules
echo 'SUBSYSTEM=="usb", ATTRS{idVendor}=="2e8a", ATTRS{idProduct}=="f00a", MODE="660", ↵
↵GROUP="plugdev" | sudo tee -a /etc/udev/rules.d/98-Picotool.rules
echo 'SUBSYSTEM=="usb", ATTRS{idVendor}=="2e8a", ATTRS{idProduct}=="000f", MODE="660", ↵
↵GROUP="plugdev" | sudo tee -a /etc/udev/rules.d/98-Picotool.rules
echo 'SUBSYSTEM=="usb", ATTRS{idVendor}=="2e8a", ATTRS{idProduct}=="f00f", MODE="660", ↵
↵GROUP="plugdev" | sudo tee -a /etc/udev/rules.d/98-Picotool.rules
sudo udevadm control --reload
```

Note that in some Linux distributions the *plugdev* above needs to be *dialout* and for boards other than the Raspberry Pi Pico line you may need to manually add their USB VID and PID to the list above.

3.11 Uploading Sketches with Picoprobe

If you have built a Raspberry Pi Picoprobe, you can use OpenOCD to handle your sketch uploads and for debugging with GDB.

Under Windows a local admin user should be able to access the Picoprobe port automatically, but under Linux *udev* must be told about the device and to allow normal users access.

To set up user-level access to Picoprobes on Ubuntu (and other OSes which use *udev*):

```
echo 'SUBSYSTEMS=="usb", ATTRS{idVendor}=="2e8a", ATTRS{idProduct}=="0004", GROUP="users ↵
↵", MODE="0666"' | sudo tee -a /etc/udev/rules.d/98-PicoProbe.rules
sudo udevadm control --reload
```

The first line creates a file with the USB vendor and ID of the Picoprobe and tells UDEV to give users full access to it. The second causes *udev* to load this new rule. Note that you will need to unplug and re-plug in your device the first time you create this file, to allow *udev* to make the device node properly.

Once Picoprobe permissions are set up properly, then select the board “Raspberry Pi Pico (Picoprobe)” in the Tools menu and upload as normal.

3.12 Uploading Sketches with OpenOCD

Under Windows and macOS, any user should be able to access OpenOCD automatically, but under Linux *udev* must be told about the device and to allow normal users access.

To set up user-level access to all CMSIS-DAP adapters on Ubuntu (and other OSes which use *udev*):

```
echo 'ATTRS{product}=="*CMSIS-DAP*", MODE="664", GROUP="plugdev" | sudo tee -a /etc/  
→udev/rules.d/98-CMSIS-DAP.rules  
sudo udevadm control --reload
```

The first line creates a file that recognizes all CMSIS-DAP adapters and tells UDEV to give users full access to it. The second causes *udev* to load this new rule. Note that you will need to unplug and re-plug in your device the first time you create this file, to allow *udev* to make the device node properly.

Once CMSIS-DAP permissions are set up properly, then select the Upload Method “Picoprobe/Debugprobe (CMSIS-DAP)” in the Tools menu.

3.13 Debugging with Picoprobe/Debugprobe, OpenOCD, and GDB

The installed tools include a version of OpenOCD (in the `pqt-openocd` directory) and GDB (in the `pqt-gcc` directory). These may be used to run GDB in an interactive window as documented in the Pico Getting Started manuals from the Raspberry Pi Foundation.

4.1 Board

Use the boards menu to select your model of RP2040 board.

There is also a *Generic RP2040* board which allows you to individually select things such as flash size or boot2 flash type. Use this if your board isn't yet fully supported and isn't working with the normal *Raspberry Pi Pico* option.

4.2 Flash Size

Arduino-Pico supports onboard filesystems which will set aside some of the flash on your board for the filesystem, shrinking the maximum code size allowed. Use this menu to select the desired ratio of filesystem to sketch.

4.3 CPU Speed

While it is unsupported, the Raspberry Pi Pico RP2040 can often run much faster than the stock 125MHz. Use the *CPU Speed* menu to select a desired over or underclock speed. **If the sketch fails at the higher speed, hold the BOOTSEL while plugging it in to enter update mode and try a lower overclock.**

4.4 Debug Port and Debug Level

Debug messages from *printf* and the Core can be printed to a Serial port to allow for easier debugging. Select the desired port and verbosity. Selecting a port for debug output does not stop a sketch from using it for normal operations.

4.5 Generic RP2040 Support

If your RP2040 board isn't in the menus you can still use it with the IDE by using the *Board->Generic RP2040* menu option. You will need to then set the flash size (see above) and tell the IDE how to communicate with the flash chip using the *Tools->Boot Stage 2* menu.

4.6 Boot Stage 2 Options for Generic RP2040

The Arduino Pico needs to set up its internal flash interface to talk to whatever flash chip is in the system. While all flash chips support a basic (and slow) 1-bit operation using common timings, each different brand (and sometimes model) of flash chip require custom timings to work in QSPI (4-bit) mode. The *Boot Stage 2* menu lets you select from the supported timings.

The options with */2* in them divide the system clock by 2 to drive the bus. Options with */4* divide the clock by 4 and so are slower but more compatible.

If you can't match a chip name in the menu to your flash chip, a simple test can be run to determine which is correct. Simply load the *Blink* example, select the first option in the *Boot Stage 2* menu, and upload. If that works, note it and continue. Iterate through the options and note which ones work. If an option doesn't work, unplug the chip and hold the BOOTSEL button down while re-inserting it to enter the ROM uploader mode. (The CPU and flash will not be harmed if the test fails.)

If one of the custom bootloaders (not *Generic SPI /2 or /4*) worked, use that option to get best performance. If none worked other than the *Generic SPI /2 or /4* then use that. The */2* options of all models is preferred as it is faster, but some boards do require */4* on the custom chip interfaces.

When in doubt, *Generic SPI /4* should work with any flash chip but is slow.

USING THIS CORE WITH PLATFORMIO

5.1 What is PlatformIO?

PlatformIO is a free, open-source build-tool written in Python, which also integrates into VSCode code as an extension.

PlatformIO significantly simplifies writing embedded software by offering a unified build system, yet being able to create project files for many different IDEs, including VSCode, Eclipse, CLion, etc. Through this, PlatformIO can offer extensive features such as IntelliSense (autocomplete), debugging, unit testing etc., which not available in the standard Arduino IDE.

The Arduino IDE experience:

```

raspbi_blink | Arduino 1.8.13
Datei Bearbeiten Sketch Werkzeuge Hilfe

raspbi_blink $
int led = PIN_LED;

void setup() {
  pinMode(led, OUTPUT);
  Serial.begin(115200);
}


void loop() {
  Serial.println("Test");
  digitalWrite(led, HIGH); // turn the LED on
  delay(200);              // wait for a second
  digitalWrite(led, LOW);  // turn the LED off
  delay(200);              // wait for a second
}

Kompilieren abgeschlossen.
"C:\Users\Max\Desktop\Programming Stuff\arduino-1.8.13\hardware
Der Sketch verwendet 57936 Bytes (2%) des Programmspeicherplatzes. I
Globale Variablen verwenden 11644 Bytes (4%) des dynamischen Speiche

14 Generic RP2040 auf COM3

```

The PlatformIO experience:



Refer to the general documentation at <https://docs.platformio.org/>.

Especially useful is the [Getting started with VSCode + PlatformIO](#), [CLI reference](#) and the [platformio.ini options](#) page.

Hereafter it is assumed that you have a basic understanding of PlatformIO in regards to project creation, project file structure and building and uploading PlatformIO projects, through reading the above pages.

5.2 Important steps for Windows users, before installing

By default, Windows has a limited path length that is not long enough to fully clone the Pico-SDK's `tinycusb` repository, resulting in error messages like the one below while attempting to fetch the repository.

```
error: unable to create file '.....': Filename too long
```

To work around this requires performing two steps and rebooting Windows once. These steps will enable longer file paths at the Windows OS and the `git` level.

5.2.1 Step 1: Enabling long paths in git


Open up a Windows `cmd` or terminal window and execute the following command

```
git config --system core.longpaths true
```

5.2.2 Step 2: Enabling long paths in the Windows OS

(taken from <https://www.microfocus.com/documentation/filr/filr-4/filr-desktop/t47bx2ogpfz7.html>)

1. Click Window key and type gpedit.msc, then press the Enter key. This launches the Local Group Policy Editor.
2. Navigate to Local Computer Policy > Computer Configuration > Administrative Templates > System > Filesystem.
3. Double click Enable NTFS/Win32 long paths and close the dialog.



5.2.3 Step 3: Reboot the computer

Once the two prior stages are complete, please do a full reboot or power cycle so that the new settings will take effect.

5.3 Updating platformio.ini to use the proper platform

First create a standard Raspberry Pi Pico + Arduino project within PlatformIO. This will give you a project with the `platformio.ini`

```
[env:pico]
platform = raspberrypi
board = pico
framework = arduino
```

Here, you need to change the `platform` to take advantage of the features described hereunder and switch to the new core.

```
[env:pico]
platform = https://github.com/maxgerhardt/platform-raspberrypi.git
board = pico
framework = arduino
board_build.core = earlephilhower
```

When the support for this core has been merged into mainline PlatformIO, this notice will be removed and a standard `platformio.ini` as shown above will work as a base.

5.4 Deprecation warnings

Previous versions of this documentation told users to inject the framework and toolchain package into the project by using

```
; note that download link for toolchain is specific for OS. see https://github.com/
↪earlephilhower/pico-quick-toolchain/releases.
platform_packages =
    maxgerhardt/framework-arduinopico@https://github.com/earlephilhower/arduino-pico.git
```

(continues on next page)

(continued from previous page)

```
maxgerhardt/toolchain-pico@https://github.com/earlephilhower/pico-quick-toolchain/
↳releases/download/1.3.1-a/x86_64-w64-mingw32.arm-none-eabi-7855b0c.210706.zip
```

This is now **deprecated** and should not be done anymore. Users should delete these `platform_packages` lines and update the platform integration by issuing the command

```
pio pkg update -g -p https://github.com/maxgerhardt/platform-raspberrypi.git
```

in the `PlatformIO CLI`. The same can be achieved by using the VSCode PIO Home -> Platforms -> Updates GUI.

The toolchain, which was also renamed to `toolchain-rp2040-earlephilhower` is downloaded automatically from the registry. The same goes for the `framework-arduino-pico` toolchain package, which points directly to the Arduino-Pico Github repository. However, users can still select a custom fork or branch of the core if desired so, as detailed in a chapter below.

5.5 Selecting the new core

Prerequisite for using this core is to tell PlatformIO to switch to it. There will be board definition files where the Earle-Philhower core will be the default since it's a board that only exists in this core (and not the other <https://github.com/arduino/ArduinoCore-mbed>). To switch boards for which this is not the default core (which are only `board = pico` and `board = nanorp2040connect`), the directive

```
board_build.core = earlephilhower
```

must be added to the `platformio.ini`. This controls the `core switching logic`.

When using Arduino-Pico-only boards like `board = rpipico` or `board = adafruit_feather`, this is not needed.

5.6 Flash size

Controlled via specifying the size allocated for the filesystem. Available sketch size is calculated accordingly by using (as in `makeboards.py`) that number and the (constant) EEPROM size (4096 bytes) and the total flash size as known to PlatformIO via the board definition file. The expression on the right can involve "b","k","m" (bytes/kilobytes/megabytes) and floating point numbers. This makes it actually more flexible than in the Arduino IDE where there is a finite list of choices. Calculations happen in `the platform`.

```
; in reference to a board = pico config (2MB flash)
; Flash Size: 2MB (Sketch: 1MB, FS:1MB)
board_build.filesystem_size = 1m
; Flash Size: 2MB (No FS)
board_build.filesystem_size = 0m
; Flash Size: 2MB (Sketch: 0.5MB, FS:1.5MB)
board_build.filesystem_size = 1.5m
```

5.7 PSRAM size

For RP2350 based boards, this controls how much PSRAM the firmware will think it has available in bytes, mapped at starting address 0x11000000.

To learn more about PSRAM usage, see: *RP2350 PSRAM Support*

```
; PSRAM size: 1MB
board_upload.psrram_length = 1048576
; PSRAM size: 2MB
board_upload.psrram_length = 2097152
; PSRAM size: 4MB
board_upload.psrram_length = 4194304
```

5.8 PSRAM chip select (CS)

For RP2350 based boards, this controls what chip-select (also called: slave-select / SS) pin to use when wanting to talk to the PSRAM chip.

Note that it's not needed to set this with a board that is known to have a PSRAM chip on-board, such as a “Sparkfun Thing Plus 2350”. The `pins_arduino.h` of that variant already has the correct definition.

To learn more about PSRAM usage, see: *RP2350 PSRAM Support*

```
; PSRAM CS is at GP47
build_flags =
  -DRP2350_PSRAM_CS=47
```

5.9 Boot2 Source

Boot2 is the second stage bootloader and predominantly used on the RP2040. Its main purpose is to configure the communication with the Flash at the highest, safest speed it can. All known boards have their correct value already configured. However, when choosing `board = generic`, you can freely configure the Boot2 to be for a different flash.

For possible Boot2 filenames, please see [here](#).

```
; expect an ISSI IS25LP080 flash, SPI frequency = CPU frequency divided by 2
board_build.arduino.earlephilhower.boot2_source = boot2_is25lp080_2_padded_checksum.S
```

5.10 CPU Speed

As for all other PlatformIO platforms, the `f_cpu` macro value (which is passed to the core) can be changed as documented

```
; 133MHz
board_build.f_cpu = 133000000L
```

5.11 Debug Port

Via `build_flags` as done for many other cores (example).

```
; Debug Port: Serial
build_flags = -DDEBUG_RP2040_PORT=Serial
; Debug Port: Serial 1
build_flags = -DDEBUG_RP2040_PORT=Serial1
; Debug Port: Serial 2
build_flags = -DDEBUG_RP2040_PORT=Serial2
```

5.12 Debug Level

Done again by directly adding the needed `build flags`. When wanting to define multiple build flags, they must be accumulated in either a single line or a newline-separated expression.

```
; Debug level: Core
build_flags = -DDEBUG_RP2040_CORE
; Debug level: SPI
build_flags = -DDEBUG_RP2040_SPI
; Debug level: Wire
build_flags = -DDEBUG_RP2040_WIRE
; Debug level: All
build_flags = -DDEBUG_RP2040_WIRE -DDEBUG_RP2040_SPI -DDEBUG_RP2040_CORE
; Debug level: NDEBUG
build_flags = -DNDEBUG

; example: Debug port on serial 2 and all debug output
build_flags = -DDEBUG_RP2040_WIRE -DDEBUG_RP2040_SPI -DDEBUG_RP2040_CORE -DDEBUG_RP2040_
↪PORT=Serial2
; equivalent to above
build_flags =
  -DDEBUG_RP2040_WIRE
  -DDEBUG_RP2040_SPI
  -DDEBUG_RP2040_CORE
  -DDEBUG_RP2040_PORT=Serial2
```

5.13 C++ Exceptions

Exceptions are disabled by default. To enable them, use

```
; Enable Exceptions
build_flags = -DPIO_FRAMEWORK_ARDUINO_ENABLE_EXCEPTIONS
```

5.14 Stack Protector

To enable GCC's stack protection feature, use

```
; Enable Stack Protector
build_flags = -fstack-protector
```

5.15 RTTI

RTTI (run-time type information) is disabled by default. To enable it, use

```
; Enable RTTI
build_flags = -DPIO_FRAMEWORK_ARDUINO_ENABLE_RTTI
```

5.16 USB Stack

Not specifying any special build flags regarding this gives one the default Pico SDK USB stack. To change it, add

```
; Adafruit TinyUSB
build_flags = -DUSE_TINYUSB
; No USB stack
build_flags = -DPIO_FRAMEWORK_ARDUINO_NO_USB
```

Note that the special “No USB” setting is also supported, through the shortcut-define `PIO_FRAMEWORK_ARDUINO_NO_USB`.

5.17 USB Customization

If you want to change the USB VID, PID, product or manufacturer name that the device will appear under, configure them as follows:

```
board_build.arduino.earlephilhower.usb_manufacturer = Custom Manufacturer
board_build.arduino.earlephilhower.usb_product = Ultra Cool Product
board_build.arduino.earlephilhower.usb_vid = 0xABCD
board_build.arduino.earlephilhower.usb_pid = 0x1337
```

5.18 IP Stack

The lwIP stack can be configured to support only IPv4 (default) or additionally IPv6. To activate IPv6 support, add

```
; IPv6
build_flags = -DPIO_FRAMEWORK_ARDUINO_ENABLE_IPV6
```

to the `platformio.ini`.

5.19 Bluetooth Stack

The Bluetooth Classic (BTC) and Bluetooth Low Energy (BLE) stack can be activated by adding

```
; BTC and BLE
build_flags = -DPIO_FRAMEWORK_ARDUINO_ENABLE_BLUETOOTH
```

to the `platformio.ini`.

5.20 FreeRTOS

FreeRTOS support can be activated by adding

```
; Enable FreeRTOS Support
build_flags = -DPIO_FRAMEWORK_ARDUINO_ENABLE_FREERTOS
```

to the `platformio.ini`.

5.21 Selecting a different core version

If you wish to use a different version of the core, e.g., the latest git `master` version, you can use a `platform_packages` directive to do so. Simply specify that the framework package (`framework-arduino-pico`) comes from a different source.

```
platform_packages =
  framework-arduino-pico@https://github.com/earlephilhower/arduino-pico.git#master
```

Whereas the `#master` can also be replaced by a `#branchname` or a `#commithash`. If left out, it will pull the default branch, which is `master`.

The `file://` and `symlink://` pseudo-protocols can also be used instead of `https://` to point to a local copy of the core (with e.g. some modifications) on disk (see [documentation](#)).

Note that this can only be done for versions that have the PlatformIO builder script it in, so versions before 1.9.2 are not supported.

5.22 Selecting the CPU architecture

By default Platform.IO will build for the onboard ARM cores on the RP2350. To build RISC-V binaries adjust the `board_build.mcu` option accordingly:

```
; RP2350 based (RISC-V)
[env:rpipico2-riscv]
board = rpipico2
board_build.mcu = rp2350-riscv
```

5.23 Examples

The following example `platformio.ini` can be used for a Raspberry Pi Pico and 0.5MByte filesystem.

```
[env:pico]
platform = https://github.com/maxgerhardt/platform-raspberrypi.git
board = pico
framework = arduino
; board can use both Arduino cores -- we select Arduino-Pico here
board_build.core = earlephilhower
board_build.filesystem_size = 0.5m
```

The initial project structure should be generated just creating a new project for the Pico and the Arduino framework, after which the auto-generated `platformio.ini` can be adapted per above.

5.24 Debugging

With recent updates to the toolchain and OpenOCD, debugging firmwares is also possible.

To specify the debugging adapter, use `debug_tool` ([documentation](#)). Supported values are:

- `picoprobe`
- `cmsis-dap`
- `jlink`

- raspberrypi-swd
- blackmagic


These values can also be used in `upload_protocol` if you want PlatformIO to upload the regular firmware through this method, which you likely want.

Especially the PicoProbe method is convenient when you have two Raspberry Pi Pico boards. One of them can be flashed with the PicoProbe firmware ([documentation](#)) and is then connected to the target Raspberry Pi Pico board (see [documentation](#) chapter “Picoprobe Wiring”). Remember that on Windows, you have to use [Zadig](#) to also load “WinUSB” drivers for the “Picoprobe (Interface 2)” device so that OpenOCD can speak to it.

Note

Newer PicoProbe firmware versions have dropped the proprietary “PicoProbe” USB communication protocol and emulate a **CMSIS-DAP** instead. Meaning, you have to use `debug_tool = cmsis-dap` for these newer firmwares, such as those obtained from [raspberrypi/picoprobe](#)

With that set up, debugging can be started via the left debugging sidebar and works nicely: Setup breakpoints, inspect the value of variables in the code, step through the code line by line. When a breakpoint is hit or execution is halted, you can even see the execution state both Cortex-M0+ cores of the RP2040.



For further information on customizing debug options, like the initial breakpoint or debugging / SWD speed, consult

the documentation.

Note


For the BlackMagicProbe debugging probe (as can be e.g., created by simply flashing a STM32F103C8 “Bluepill” board), you currently have to use the branch `fix/rp2040-flash-reliability` (or at least commit `1d001bc`) **and** use the [official ARM provided toolchain](#).

You can obtain precompiled binaries from [here](#). A flashing guide is available [here](#). You then have to configure the target serial port (“GDB port”) in your project per [documentation](#).

5.25 Filesystem Uploading

For the Arduino IDE, a [plugin](#) is available that enables a data folder to be packed as a LittleFS filesystem binary and uploaded to the Pico.

This functionality is also built-in in the PlatformIO integration. Open the [project tasks](#) and expand the “Platform” tasks:



The files you want to upload should be placed in a folder called `data` inside the project. This can be customized if needed.

The task “Build Filesystem Image” will take all files in the `data` directory and create a `littlefs.bin` file from it using the `mklittlefs` tool.

The task “Upload Filesystem Image” will upload the filesystem image to the Pico via the specified `upload_protocol`.

Note

Set the space available for the filesystem in the `platformio.ini` using e.g., `board_build.filesystem_size = 0.5m`, or filesystem creation will fail!

PIN ASSIGNMENTS

The Raspberry Pi Pico has an incredibly flexible I/O configuration and most built-in peripherals (except for the ADC) can be used on multiple sets of pins. Note, however, that not all peripherals can use all I/Os. Refer to the RP2040 datasheet or an online pinout diagram for more details.

Additional methods have been added to allow you to select a peripheral's I/O pins **before calling `::begin`**. This is especially helpful when using third party libraries: the library doesn't need to be modified, only your own code in `setup()` is needed to adjust pinouts.

6.1 I2S

```
::setBCLK(pin)  
::setDOUT(pin)
```

6.2 Serial1 (UART0), Serial2 (UART1)

```
::setRX(pin)  
::setTX(pin)  
::setRTS(pin)  
::setCTS(pin)
```

6.3 SPI (SPI0), SPI1 (SPI1)

```
::setSCK(pin)  
::setCS(pin)  
::setRX(pin)  
::setTX(pin)
```

6.4 Wire (I2C0), Wire1 (I2C1)

```
::setSDA(pin)  
::setSCL(pin)
```

For example, because the *SD* library uses the *SPI* library, we can make it use a non-default pinout with a simple call

```
void setup() {  
  SPI.setRX(4);  
}
```

(continues on next page)

(continued from previous page)

```
SPI.setTX(7);  
SPI.setSCK(6);  
SPI.setCS(5);  
SD.begin(5);  
}
```

RP2040 HELPER CLASS

Some of the core functionality of the RP2040 chip powering the Raspberry Pi Pico is exposed in the RP2040 class variable `rp2040`.

7.1 Core Internals

7.1.1 `int rp2040.f_cpu()`

Returns the current frequency of the core clock. This is read at runtime, versus the constant `F_CPU` macro that is also available. This is useful in cases where your code changes the core clock (i.e. low power modes, etc.)

7.1.2 `int rp2040.cpuid()`

Returns the current core ID (0 or 1) of the executing task.

7.1.3 `uint32_t rp2040.getCycleCount()`

Returns a 32-bit cycle count from when the core started running. Because it is only 32-bits, and the Pico runs at 133MHz, this value can loop around in a matter of seconds.

7.1.4 `uint64_t rp2040.getCycleCount64()`

Returns a 64-bit cycle count from when the core started running. This value should never loop around in normal mode (at 133MHz it would take over 4,000 years to overflow).

7.1.5 `uint32_t rp2040.hwrand32()`

Returns a 32-bit value derived from the CPU cycle counter and the ROSC oscillator. Because the ROSC bit is not a true random number generator, the values returned may not meet the most stringent random tests. **If your application needs absolute bulletproof random numbers, consider using dedicated external hardware.**

7.1.6 `void rp2040.reboot()`

Forces a hardware reboot of the Pico.

7.2 Hardware Watchdog

7.2.1 `void rp2040.wdt_begin(uint32_t delay_ms)`

Enables the hardware watchdog timer with a delay value of `delay_ms` milliseconds. Note that on the RP2040, once this function has called, the hardware watchdog can `_not_` be disabled.

The maximum `delay_ms` allowed in this call is 8300, corresponding to 8.3 seconds. Any higher values will be truncated by the hardware.

7.2.2 void rp2040.wdt_reset()

Reloads the watchdog's counter with the amount of time set by `wdt_begin`.

7.2.3 RP2040::resetReason_t rp2040.getResetReason()

Returns the reason for the last reset, defined in enum `RP2040::resetReason_t`. See example `ResetReason` for some details.

7.3 Memory Information

7.3.1 int rp2040.getFreeHeap()

Returns the number of bytes free for heap allocation (i.e. `malloc`, `new`). Note that because there is some overhead, and there may be heap fragmentation, this number is an *upper bound* and you generally will only be able to allocate less than this returned number.

7.3.2 int rp2040.getUsedHeap()

Returns the number of bytes allocated out of the heap.

7.3.3 int rp2040.getTotalHeap()

Returns the total heap that was available to this program at compile time (i.e. the Pico RAM size minus things like the `.data` and `.bss` sections and other overhead).

7.4 Hardware Identification

7.4.1 bool rp2040.isPicoW()

Returns the core's best guess if this code is running on a Raspberry Pi Pico W. This would let you, possibly, use the same UF2 for Pico and PicoW by simply not doing any WiFi calls.

7.5 Bootloader

7.5.1 void rp2040.enableDoubleResetBootloader() (Pico/RP2040 only)

Add a call anywhere in the sketch to `rp2040.enableDoubleResetBootloader()` and the core will check for a double-tap on reset, and if found will start the USB bootloader.

7.5.2 void rp2040.rebootToBootloader()

Will reboot the RP2040 into USB UF2 upload mode.

7.6 DMA-based MEMCPY

The onboard DMA engines can copy 4-byte aligned quantities faster than the CPU.

7.6.1 `void *rp2040.memcpyDMA(void *dest, const void *src, size_t count);`

Uses a DMA engine to transfer data from `src` to `dest` in 4-byte chunks without CPU intervention. If any arguments are not 4-byte aligned, or if the count is not a multiple of 4, then it will fall back to CPU-managed `memcpy`.

8.1 Analog Input

For analog inputs, the RP2040 device has a 12-bit, 4-channel ADC + temperature sensor available on a fixed set of pins (A0...A3). The standard Arduino calls can be used to read their values (with 3.3V nominally reading as 4095).

8.1.1 `int analogRead(pin_size_t pin = A0..A3)`

Returns a value from 0...4095 corresponding to the ADC reading of the specific pin.

8.1.2 `void analogReadResolution(int bits)`

Determines the resolution (in bits) of the value returned by the `analogRead()` function. Default resolution is 10bit.

8.1.3 `float analogReadTemp(float vref = 3.3f)`

Returns the temperature, in Celsius, of the onboard thermal sensor. If you have a custom Vref for the ADC on your RP2040 board, you can pass it in as a parameter. Calling with no parameters assumes the normal, 3.3V Vref. This reading is not exceedingly accurate and of relatively low resolution, so it is not a replacement for an external temperature sensor in many cases.

8.2 Analog Outputs

The RP2040 does not have any onboard DACs, so analog outputs are simulated using the standard method of using pulse width modulation (PWM) using the RP2040's hardware PWM units.

While up to 16 PWM channels can be generated, they are not independent and there are significant restrictions as to allowed pins in parallel. See the [RP2040 datasheet](#) for full details.

8.3 Analog Output Restrictions

The PWM generator source clock restricts the legal combinations of frequency and ranges. At a CPU frequency of 133MHz, the 16 bit maximum range decreases by 1 bit for every doubling of the default PWM frequency of 1 kHz. For example, at 1MHz only about 6 bits of range are possible. When you define an `analogWriteFreq` and `analogWriteRange` that can't be fulfilled by the hardware, the frequency will be preserved but the accuracy (range) will be reduced automatically. Your code will still send in the range you specify, but the core itself will transparently map it into the allowable PWN range.

8.3.1 void analogWriteFreq(uint32_t freq)

Sets the master PWM frequency used (i.e. how often the PWM output cycles). From 100Hz to 1MHz are supported.

8.3.2 void analogWriteRange(uint32_t range) and analogWriteResolution(int res)

These calls set the maximum PWM value (i.e. writing this value will result in a PWM duty cycle of 100%)/ either explicitly (range) or as a power-of-two (res). A range of 16 to 65535 is supported.

8.3.3 void analogWrite(pin_size_t pin, int val)

Writes a PWM value to a specific pin. The PWM machine is enabled and set to the requested frequency and scale, and the output is generated. This will continue until a `digitalWrite` or other digital output is performed.

9.1 Board-Specific Pins

The Raspberry Pi Pico RP2040 chip supports up to 30 digital I/O pins, however not all boards provide access to all pins.

9.2 Pin Notation

When using Analog or Digital I/Os, if you supply an integer it specifies the RP2040 GPIO pin to use. Using Dx or Ax notation (for example, D4 or A3) may be necessary on boards without a direct PCB pin to GPIO mapping.

9.3 Input Modes

The Raspberry Pi Pico has 3 Input modes settings for use with *pinMode*: *INPUT*, *INPUT_PULLUP* and *INPUT_PULLDOWN*

9.4 Output Modes (Pad Strength)

The Raspberry Pi Pico has the ability to set the current that a pin (actually the pad associated with it) is capable of supplying. The current can be set to values of 2mA, 4mA, 8mA and 12mA. By default, on a reset, the setting is 4mA. A *pinMode(x, OUTPUT)*, where *x* is the pin number, is also the default setting. 4 settings have been added for use with *pinMode*: *OUTPUT_2MA*, *OUTPUT_4MA*, which has the same behavior as *OUTPUT*, *OUTPUT_8MA* and *OUTPUT_12MA*.

9.5 Tone/noTone

Simple square wave tone generation is possible for up to 8 channels using Arduino standard `tone` calls. Because these use the PIO to generate the waveform, they must share resources with other calls such as I2S or Servo objects.

BOOTSEL BUTTON

The BOOTSEL button on the Pico is not connected to a standard GPIO, so it cannot be read using the usual `digitalRead` function. It **can**, however, be read using a special (relatively slow) method.

The BOOTSEL object implements a simple way of reading the BOOTSEL button. Simply use the object BOOTSEL as a boolean (as a conditional in an `if` or `while`, or assigning to a `bool`):

```
// Print "BEEP" if the BOOTSEL button is pressed
if (BOOTSEL) {
    Serial.println("BEEP!");
    // Wait until BOOTSEL is released
    while (BOOTSEL) {
        delay(1);
    }
}
```


EEPROM LIBRARY

While the Raspberry Pi Pico RP2040 does not come with an EEPROM onboard, we simulate one by using a single 4K chunk of flash at the end of flash space.

Note that this is a simulated EEPROM and will only support the number of writes as the onboard flash chip, not the 100,000 or so of a real EEPROM. Therefore, do not frequently update the EEPROM or you may prematurely wear out the flash.

11.1 EEPROM Class API

11.1.1 EEPROM.begin(size=256...4096)

Call before the first use of the EEPROM data for read or write. It makes a copy of the emulated EEPROM sector in RAM to allow random update and access.

11.1.2 EEPROM.read(addr), EEPROM[addr]

Returns the data at a specific offset in the EEPROM. See *EEPROM.get* later for a more

11.1.3 EEPROM.write(addr, data), EEPROM[addr] = data

Writes a byte of data at the offset specified. Not persisted to flash until `EEPROM.commit()` is called.

11.1.4 EEPROM.commit()

Writes the updated data to flash, so next reboot it will be readable.

11.1.5 EEPROM.end()

`EEPROM.commit()` and frees all memory used. Need to call *EEPROM.begin()* before the EEPROM can be used again.

11.1.6 EEPROM.get(addr, val)

Copies the (potentially multi-byte) data in EEPROM at the specific byte offset into the returned value. Useful for reading structures from EEPROM.

11.1.7 EEPROM.put(addr, val)

Copies the (potentially multi-byte) value into EEPROM at the byte offset supplied. Useful for storing `struct` in EEPROM. Note that any pointers inside a written structure will not be valid, and that most C++ objects like `String` cannot be written to EEPROM this way because of it.

11.1.8 EEPROM.length()

Returns the length of the EEPROM (i.e. the value specified in `EEPROM.begin()`).

11.2 EEPROM Examples

Three EEPROM [examples](#) are included.

I2S (DIGITAL AUDIO) AUDIO LIBRARY

While the RP2040 chip on the Raspberry Pi Pico does not include a hardware I2S device, it is possible to use the PIO (Programmable I/O) state machines to implement one dynamically.

Digital audio input and output are supported at 8, 16, 24, and 32 bits per sample.

Theoretically up to 6 I2S ports may be created, but in practice there may not be enough resources (DMA, PIO SM) to actually create and use so many.

Create an I2S port by instantiating a variable of the I2S class specifying the direction. Configure it using API calls below before using it.

12.1 I2S Class API

12.1.1 I2S(OUTPUT)

Creates an I2S output port. Needs to be connected up to the desired pins (see below) and started before any output can happen.

12.1.2 I2S(INPUT)

Creates an I2S input port. Needs to be connected up to the desired pins (see below) and started before any input can happen.

12.1.3 I2S(INPUT_PULLUP)

Creates a bi-directional I2S input and output port. Needs to be connected up to the desired pins (see below) and started before any input or output can happen.

12.1.4 bool setSlave()

Enables slave mode. BCLK and LRCLK are inputs and used to control the timing of the DOUT output. Only normal I2S output and input modes are supported in slave mode.

In I2S input slave mode, the clock pins and swapClocks are ignored. The pins must be consecutive starting with DIN, then BCLK, then LRCLK.

12.1.5 bool setBCLK(pin_size_t pin)

Sets the BCLK pin of the I2S device. The LRCLK/word clock will be `pin + 1` due to limitations of the PIO state machines. Call this before `I2S::begin()`

12.1.6 `bool setDATA(pin_size_t pin)`

Sets the DOUT or DIN pin of the I2S device. Any pin may be used. In bi-directional operation, must use `I2S::setDOUT()` and `I2S::setDIN` instead. Call before `I2S::begin()`

12.1.7 `bool setDOUT(pin_size_t pin)`

Sets the DOUT pin of the I2S device. Any pin may be used. Call before `I2S::begin()`

12.1.8 `bool setDIN(pin_size_t pin)`

Sets the DIN pin of the I2S device. Any pin may be used. Call before `I2S::begin()`

12.1.9 `bool setMCLK(pin_size_t pin)`

Sets the MCLK pin of the I2S device and enables MCLK output. Any pin may be used. Call before `I2S::begin()`

12.1.10 `bool setMCLKmult(int mult)`

Sets the sample rate to MCLK multiplier value. Only multiples of 64 are valid. Call before `I2S::begin()`

12.1.11 `bool setBitsPerSample(int bits)`

Specify how many bits per audio sample to read or write. Note that for 24-bit samples, audio samples must be left-aligned (i.e. bits 31...8). Call before `I2S::begin()`

12.1.12 `bool setBuffers(size_t buffers, size_t bufferWords, int32_t silenceSample = 0)`

Set the number of DMA buffers and their size in 32-bit words as well as the word to fill when no data is available to send to the I2S hardware. Call before `I2S::begin()`.

12.1.13 `bool setFrequency(long sampleRate)`

Sets the word clock frequency, but does not start the I2S device if not already running. May be called after `I2S::begin()` to change the sample rate on-the-fly.

12.1.14 `bool setSysClk(int samplerate)`

Changes the PICO system clock to optimise for the desired samplerate. The clock changes to 153.6 MHz for samplerates that are a multiple of 8 kHz, and 135.6 MHz for multiples of 11.025 kHz. Note that using `setSysClk()` may affect the timing of other sysclk-dependent functions. Should be called before any I2S functions and any other sysclk dependent initialisations.

12.1.15 `bool setLSBJFormat()`

Enables LSB-J format for I2S output. In this mode the MSB comes out at the same time as the LRCLK changes, and not the normal 1-cycle delay. Useful for DAC chips like the PT8211.

12.1.16 `bool setTDMFormat()`

Enabled TDM formatted multi-channel output. Be sure to set the number of channels to the expected value (8 normally) and the bits per sample to 32.

12.1.17 bool setTDMChannels(int channels)

Sets the number of TDM channels between frame syncs. Generally should be set to 8.

12.1.18 bool swapClocks()

Certain boards are hardwired with the WCLK before the BCLK, instead of the normal way around. This call swaps the WCLK and BCLK pins. Note that you still call `setBCLK(x)` with `x` being the lowest pin ID (i.e. in `swapClocks` mode the `setBCLK` call actually sets LRCLK).

12.1.19 bool begin()/begin(long sampleRate)

Start the I2S device up with the given sample rate, or with the value set using the prior `setFrequency` call.

12.1.20 void end()

Stops the I2S device.

12.1.21 void flush()

Waits until all the I2S buffers have been output.

12.1.22 void getOverUnderflow()

Returns a flag indicating if the I2S system ran out of data to send on output, or had to throw away data on input.

12.1.23 void getOverflow()

Returns a flag indicating if the I2S system had to throw away data on input.

12.1.24 void getUnderflow()

Returns a flag indicating if the I2S system ran out of data to send on output.

12.1.25 size_t write(uint8_t/int8_t/int16_t/int32_t)

Writes a single sample of `bitsPerSample` to the buffer. It is up to the user to keep track of left/right channels. Note this writes data equivalent to one channel's data, not the size of the passed in variable (i.e. if you have a 16-bit sample size and `write((int8_t)-5); write((int8_t)5);` you will have written **2 samples** to the I2S buffer of whatever the I2S size, not a single 16-bit sample.

This call will block (wait) until space is available to actually write the data.

12.1.26 size_t write(int32_t val, bool sync)

Writes 32 bits of data to the I2S buffer (regardless of the configured I2S bit size). When `sync` is true, it will not return until the data has been written. When `sync` is false, it will return `0` immediately if there is no space present in the I2S buffer.

12.1.27 size_t write(const uint8_t *buffer, size_t size)

Transfers number of bytes from an application buffer to the I2S output buffer. Be aware that `size` is in *bytes** and not samples. Size must be a multiple of **4 bytes**. Will not block, so check the return value to find out how many 32-bit words were actually written.

12.1.28 `int availableForWrite()`

Returns the amount of bytes that can be written without potentially blocking.

12.1.29 `int read()`

Reads a single sample of I2S data, whatever the I2S sample size is configured. Will not return until data is available.

12.1.30 `int peek()`

Returns the next sample to be read from the I2S buffer (without actually removing it).

12.1.31 `size_t read(uint8_t *buffer, size_t size)`

Transfers number of bytes from the I2S input buffer to an application buffer. Be aware that `size` is in *bytes** and not samples. Size must be a multiple of **4 bytes**. Will not block, so check the return value to find out how many 32-bit words were actually read.

12.1.32 `void onTransmit(void (*fn)(void))`

Sets a callback to be called when an I2S DMA buffer is fully transmitted. Will be in an interrupt context so the specified function must operate quickly and not use blocking calls like `delay()` or write to the I2S.

12.1.33 `void onReceive(void (*fn)(void))`

Sets a callback to be called when an I2S DMA buffer is fully read in. Will be in an interrupt context so the specified function must operate quickly and not use blocking calls like `delay()` or read from the I2S.

12.2 Sample Writing/Reading API

Because I2S streams consist of a natural left and right sample, it is often convenient to write or read both with a single call. The following calls allow applications to read or write both samples at the same time, and explicitly indicate the bit widths required (to avoid potential issues with type conversion on calls).

12.2.1 `size_t write8(int8_t l, int8_t r)`

Writes a left and right 8-bit sample to the I2S buffers. Blocks until space is available.

12.2.2 `size_t write16(int16_t l, int16_t r)`

Writes a left and right 16-bit sample to the I2S buffers. Blocks until space is available.

12.2.3 `size_t write24(int32_t l, int32_t r)`

Writes a left and right 24-bit sample to the I2S buffers. See note below about 24-bit mode. Blocks until space is available.

12.2.4 `size_t write32(int32_t l, int32_t r)`

Writes a left and right 32-bit sample to the I2S buffers. Blocks until space is available.

12.2.5 `bool read8(int8_t *l, int8_t *r)`

Reads a left and right 8-bit sample and returns `true` on success. Will block until data is available.

12.2.6 `bool read16(int16_t *l, int16_t *r)`

Reads a left and right 16-bit sample and returns `true` on success. Will block until data is available.

12.2.7 `bool read24(int32_t *l, int32_t *r)`

Reads a left and right 24-bit sample and returns `true` on success. See note below about 24-bit mode. Will block until data is available.

12.2.8 `bool read32(int32_t *l, int32_t *r)`

Reads a left and right 32-bit sample and returns `true` on success. Will block until data is available.

12.3 Note About 24-bit Samples

24-bit samples are stored as left-aligned 32-bit values with bits 7..0 ignored. Only the upper 24 bits 31..8 will be transmitted or received. The actual I2S protocol will only transmit or receive 24 bits in this mode, even though the data is 32-bit packed.

PWM AUDIO LIBRARY

Relatively good quality analog audio out can be generated by using the RP2040 onboard PWM hardware. It can drive an amplifier for speaker output, or be decoupled using a capacitor to drive a headphone-level signal. Mono and stereo signals can be generated.

All samples are sent to the `PWMAudio` library as **signed 16 bits per sample**. Due to frequency limitations of the PWM hardware, at higher bit rates these 16-bits will automatically be reduced to the maximum the hardware can handle.

Multiple `PWMAudio` devices are supported, depending on availability of DMA channels.

The interface for the `PWMAudio` device is very similar to the I2S device, and most code can be ported simply by instantiating a `PWMAudio` object in lieu of an I2S object.

13.1 PWM Class API

13.1.1 `PWMAudio(pin)`

Creates a mono PWM output port. Any pin can be used, but no `analogWrite` calls are allowed to any other pins using that pin's PWM slice hardware. See the RP2040 datasheet for more details about PWM slices.

13.1.2 `PWMAudio(pin, true)`

Creates a stereo PWM output port. Only even pins (left signal) can be used, the next odd pin will automatically be assigned to the right channel (i.e. `PWMAudio pwm(0, true)`; will make GP0 as the left channel, GP1 as the right channel). The same restriction as in mono mode applies.

13.1.3 `bool setBuffers(size_t buffers, size_t bufferWords)`

Set the number of DMA buffers and their size in 32-bit words. Call before `PWMAudio::begin()`.

When running at high sample rates, it is recommended to increase the `bufferWords` to 32 or higher (i.e. `pwm.setBuffers(4, 32);`).

13.1.4 `bool setPin(pin_size_t pin)`

Adjusts the pin to connect to the PWM audio output. Only legal before `PWMAudio::begin()`.

13.1.5 `bool setStereo(bool stereo)`

Adjusts the mono/stereo setting of the PWM audio output. Only legal before `PWMAudio::begin()`.

13.1.6 `bool setFrequency(long sampleRate)`

Sets the sample frequency, but does not start the PWM device (however if the device was already running, it will continue to run at the new frequency).

13.1.7 `bool begin()/begin(long sampleRate)`

Start the PWM Audio device up with the given sample rate, or with the value set using the prior `setFrequency` call.

13.1.8 `void end()`

Stops the PWMAudio device.

13.1.9 `void flush()`

Waits until all the PWM Audio buffers have been output.

13.1.10 `size_t write(int16_t sample, bool sync = true)`

Writes a single 16-bit sample to the buffer. It is up to the user to keep track of left/right channels when in stereo mode. In mono mode, one sample is written per timestep while in stereo mode two `write()` calls are required.

This call will block (wait) until space is available to actually write the data if `sync` is not specified or set to `true`.

13.1.11 `size_t write(const uint8_t *buffer, size_t size)`

Transfers number of bytes from an application buffer to the PWM Audio output buffer. Be aware that `size` is in *bytes** and not samples. Size must be a multiple of **4 bytes**. Will not block, so check the return value to find out how many bytes were actually written.

13.1.12 `int availableForWrite()`

Returns the number of samples that can be written without potentially blocking.

13.1.13 `void onTransmit(void (*fn)(void))`

Sets a callback to be called when a PWM Audio DMA buffer is fully transmitted. Will be in an interrupt context so the specified function must operate quickly and not use blocking calls like `delay()` or write to the PWM Audio.

ADC INPUT LIBRARY

The ADC pins can be sampled and recorded by an application using the same interface as the I2S or PWM Audio libraries. This allows analog devices which need to be periodically sampled to be read by applications, easily, such as:

- Analog electret microphones
- Potentiometers
- Light dependent resistors (LDR), etc.

Up to 4 (or 8 in the case of the RP2350B) analog samples can be recorded by the hardware (A0 ... A3), and all recording is done at 16-bit levels (but be aware that the ADC in the Pico will only ever return values between 0...4095).

The interface for the ADCInput device is very similar to the I2S input device, and most code can be ported simply by instantiating a ADCInput object in lieu of an I2S input object and choosing the pins to record.

Since this uses the ADC hardware, no analogRead or analogReadTemp calls are allowed while in use.

14.1 ADC Input API

14.1.1 ADCInput(pin0 [, pin1, pin2, pin3[, pin4, pin5, pin6, pin7])

Creates an ADC input object which will record the pins specified in the code. Only pins A0 ... A3 (A7 on RP2350B) can be used, and they must be specified in increasing order (i.e. ADCInput(A0, A1); is valid, but ADCInput(A1, A0) is not).

14.1.2 bool setBuffers(size_t buffers, size_t bufferWords)

Set the number of DMA buffers and their size in 32-bit words. Call before ADCInput::begin().

When running at high sample rates, it is recommended to increase the bufferWords to 32 or higher (i.e. adcinput.setBuffers(4, 32);).

14.1.3 bool setPins(pin_size_t pin [, pin1, pin2, pin3])

Adjusts the pin to record. Only legal before ADCInput::begin().

14.1.4 bool setFrequency(long sampleRate)

Sets the ADC sampling frequency, but does not start recording (however if the device was already running, it will continue to run at the new frequency). Note that every pin requested will be sampled at this frequency, one after the other. That is, if you have code like this:

```
ADCInput adc(A0, A1);  
adc.setFrequency(1000);
```

A0 will be sampled at 0ms, 1ms, 2ms, etc. and A1 will be sampled at 0.5ms 1.5ms, 2.5ms, etc. Each input is sampled at the proper frequency but offset in time since there is only one active ADC at a time.

14.1.5 `bool begin()/begin(long sampleRate)`

Start the ADC input up with the given sample rate, or with the value set using the prior `setFrequency` call.

14.1.6 `void end()`

Stops the ADC Input device.

14.1.7 `int read()`

Reads a single sample of recorded ADC data, as a 16-bit value. When multiple pins are recorded the first read will be pin 0, the second will be pin 1, etc. Applications need to keep track of which pin is being returned (normally by always reading out all pins at once). Will not return until data is available.

14.1.8 `int available()`

Returns the number of samples that can be read without potentially blocking.

14.1.9 `void onReceive(void (*fn)(void))`

Sets a callback to be called when a ADC input DMA buffer is fully filled. Will be in an interrupt context so the specified function must operate quickly and not use blocking calls like `delay()`.

SERIAL PORTS (USB, UART, AND BLE “NORDIC SPP SERVICE”)

The Arduino-Pico core implements a software-based Serial-over-USB port using the USB ACM-CDC model to support a wide variety of operating systems.

`Serial` is the USB serial port, and while `Serial.begin()` does allow specifying a baud rate, this rate is ignored since it is USB-based. (Also be aware that this USB `Serial` port is responsible for resetting the RP2040 during the upload process, following the Arduino standard of 1200bps = reset to bootloader).

The RP2040 provides two hardware-based UARTS with configurable pin selection.

`Serial1` is UART0, and `Serial2` is UART1.

Configure their pins using the `setXXX` calls prior to calling `begin()`

```
Serial1.setRX(pin);  
Serial1.setTX(pin);  
Serial1.begin(baud);
```

Pass in `-1` to `setRX` or `setTX` to disable that pin, freeing it for use by your application.

The size of the receive FIFO may also be adjusted from the default 32 bytes by using the `setFIFOSize` call prior to calling `begin()`

```
Serial1.setFIFOSize(128);  
Serial1.begin(baud);
```

The FIFO is normally handled via an interrupt, which reduced CPU load and makes it less likely to lose characters.

For applications where an IRQ driven serial port is not appropriate, use `setPollingMode(true)` before calling `begin()`

```
Serial1.setPollingMode(true);  
Serial1.begin(300)
```

For detailed information about the Serial ports, see the [Arduino Serial Reference](#) .

15.1 Inversion

`Serial1` and `Serial2` can both support inverted input and/or outputs via the methods `Serial1/2::setInvertRX(bool invert)` and `Serial1/2::setInvertTX(bool invert)` and `Serial1/2::serInvertControl(bool invert)`.

15.2 Nordic SPP Serial Service

Please see the `File->Examples->BLE->SerialBLE.ino` example for use over BLE.

15.3 RP2040 Specific SerialUSB methods

15.3.1 `void Serial.ignoreFlowControl(bool ignore)`

In some cases, the target application will not assert the DTR virtual line, thus preventing writing operations to succeed.

For this reason, the `SerialUSB::ignoreFlowControl()` method disables the connection's state verification, enabling the program to write on the port, even though the data might be lost.

15.3.2 `bool Serial.dtr()`

Returns the current state of the DTR virtual line. A USB CDC host (such as the Arduino serial monitor) typically raises the DTR pin when opening the device, and may lower it when closing the device.

15.3.3 `bool Serial.rts()`

Returns the current state of the RTS virtual line.

“SOFTWARESERIAL” PIO-BASED UART

Equivalent to the Arduino SoftwareSerial library, an emulated UART using one or two PIO state machines is included in the Arduino-Pico core. This allows for up to 4 bidirectional or up to 8 unidirectional serial ports to be run from the RP2040 without requiring additional CPU resources.

Instantiate a `SerialPIO(txpin, rxpin, fifosize)` object in your sketch and then use it the same as any other serial port. Even, odd, and no parity modes are supported, as well as data sizes from 5- to 8-bits. `Fifosize`, if not specified, defaults to 32 bytes.

To instantiate only a serial transmit or receive unit, pass in `NOPIN` as the `txpin` or `rxpin`.

For example, to make a transmit-only port on GP16

```
SerialPIO transmitter( 16, NOPIN );
```

For detailed information about the Serial ports, see the [Arduino Serial Reference](#) .

16.1 Inversion

`SoftwareSerial` and `SerialPIO` can both support inverted input and/or outputs via the methods `setInvertRX(bool invert)` and `setInvertTX(bool invert)`.

SOFTWARESERIAL EMULATION

A `SoftwareSerial` wrapper is included to provide plug-and-play compatibility with the Arduino [Software Serial](#) library. Use the normal `#include <SoftwareSerial.h>` to include it. The following differences from the Arduino standard are present:

- All ports are always listening
- `listen` call is a no-op
- `isListening()` always returns `true`

SERVO LIBRARY

A hardware-based servo controller is provided using the Servo library. It utilizes the PIO state machines and generates the appropriate servo control pulses, glitch-free and jitter-free (within crystal limits).

Up to 8 Servos can be controlled in parallel assuming no other tasks require the use of a PIO machine.

See the Arduino standard [Servo documentation](#) for detailed usage instructions. There is also an included sweep example.

18.1 Pulse Width Defaults

The defaults in the Servo library are conservatively set to avoid damage in the case of over-driving. The pulse widths individual servos, especially the no-name or clones, occasionally need tweaking.

You can set the min and max servo pulse width in the attach command, with default values used in most Arduino cores of 540/2400: ``myServo.attach(D3, 540, 2400)``

SPI MASTER (SERIAL PERIPHERAL INTERFACE)

The RP2040 has two hardware SPI interfaces, `spi0` (SPI) and `spi1` (SPI1). These interfaces are supported by the SPI library in master mode.

SPI pinouts can be set **before** `SPI.begin()` using the following calls:

```
bool setRX(pin_size_t pin); // or setMISO()
bool setCS(pin_size_t pin);
bool setSCK(pin_size_t pin);
bool setTX(pin_size_t pin); // or setMOSI()
```

Note that the CS pin can be hardware or software controlled by the sketch. When software controlled, the `setCS()` call is ignored.

Passing in `NOPIN` to either `setRX` or `setTX` will disable SPI on that interface, making it behave as a unidirectional (output- or input-only SPI interface).

The Arduino [SPI documentation](#) gives a detailed overview of the library, except for the following RP2040-specific changes:

- **SPI.begin(bool hwCS) can take an options hwCS parameter.**
By passing in `true` for `hwCS` the sketch does not need to worry about asserting and deasserting the CS pin between transactions. The default is `false` and requires the sketch to handle the CS pin itself, as is the standard way in Arduino.
- The interrupt calls (`attachInterrupt`, and `detachInterrupt`) are not implemented.

SOFTWARE SPI (MASTER ONLY)

Similar to `SoftwareSerial`, `SoftwareSPI` creates a PIO based SPI interface that can be used in the same manner as the hardware SPI devices. The constructor takes the pins desired, which can be any GPIO pins with the rule that if hardware CS is used then it must be on pin `SCK + 1`. Construct a `SoftwareSPI` object in your code as follows and use it as needed (i.e. pass it into `SD.begin(_CS, softwareSPI)`);

```
#include <SoftwareSPI.h>
SoftwareSPI softSPI(_sck, _miso, _mosi); // no HW CS support, any selection of pins can
↳ be used
```


SPI SLAVE (SPISLAVE)

Slave mode operation is also supported on either SPI interface. Two callbacks are needed in your app, set through `SPISlave.onDataRecv` and `SPISlave.onDataSent`, in order to consume the received data and provide data to transmit.

- The callbacks operate at IRQ time and may be called very frequently at high SPI frequencies. So, make them small, fast, and with no memory allocations or locking.

ASYNCHRONOUS OPERATION

Applications can use asynchronous SPI calls to allow for processing while long-running SPI transfers are being performed. For example, a game could send a full screen update out over SPI and immediately start processing the next frame without waiting for the first one to be sent. DMA is used to handle the transfer to/from the hardware freeing the CPU from bit-banging or busy waiting.

Note that asynchronous operations can not be intersped with normal, synchronous ones. `transferAsync` should still occur after a `beginTransaction()` and when `finishedAsync()` returns `true` then `endTransaction()` should also be called.

All buffers need to be valid throughout the entire operation. Read data cannot be accessed until the transaction is completed and can't be "peeked" at while the operation is ongoing.

22.1 `bool transferAsync(const void *send, void *recv, size_t bytes)`

Begins an SPI asynchronous transaction. Either `send` or `recv` can be `nullptr` if data only needs to be transferred in one direction. Check `finishedAsync()` to determine when the operation completes and conclude the transaction. This operation needs to allocate a buffer from heap equal to `bytes` in size if `LSBMODE` is used.

22.2 `bool finishedAsync()`

Call to check if the asynchronous operations is completed and the buffer passed in can be either read or reused. Frees the allocated memory and completes the asynchronous transaction.

22.3 `void abortAsync()`

Cancels the outstanding asynchronous transaction and frees any allocated memory.

CHAPTER
TWENTYTHREE

EXAMPLES

See the `SPIToMyself` and `SPIToMyselfAsync` examples for a complete Master and Slave application.

WIRE (I2C MASTER AND SLAVE)

The RP2040 has two I2C devices, `i2c0` (Wire) and `i2c1` (Wire1).

The default pins for *Wire* and *Wire1* vary depending on which board you're using. (Here are the pinout diagrams for [Pico](#) and [Adafruit Feather](#).)

You may change these pins **before calling `Wire.begin()` or `Wire1.begin()`** using:

```
bool setSDA(pin_size_t sda);  
bool setSCL(pin_size_t scl);
```

Be sure to use pins labeled I2C0 for Wire and I2C1 for Wire1 on the pinout diagram for your board, or it won't work.

Other than that, the API is compatible with the Arduino standard. Both master and slave operation are supported.

Master transmissions are buffered (up to 256 bytes) and only performed on `endTransmission`, as is standard with modern Arduino Wire implementations.

For more detailed information, check the [Arduino Wire documentation](#) .

24.1 Asynchronous Operation

Applications can use asynchronous I2C calls to allow for processing while long-running I2C operations are being performed. For example, a game could send a full screen update out over I2C and immediately start processing the next frame without waiting for the first one to be sent over I2C. DMA is used to handle the transfer to/from the I2C hardware freeing the CPU from bit-banging or busy waiting.

Note that asynchronous operations can not be intersped with normal, synchronous ones. Fully complete or abort an asynchronous operation before attempting to do a normal `Wire.beginTransaction()` or `Wire.requestFrom`.

24.1.1 `bool writeReadAsync(uint8_t address, const void *wbuffer, size_t wbytes, const void *rbuffer, size_t rbytes, bool sendStop)`

Executes a master I2C asynchronous write/read transaction to I2C slave address. First `wbytes` from `wbuffer` are written to the I2C slave, followed by an I2C restart, then `rbytes` are read from the I2C slave into `rbuffer`. The buffers need to be valid throughout the entire asynchronous operation.

At the end of the transaction an I2C stop is sent if `sendStop` is true, and at the beginning of the transaction an I2C start is sent if the previous write/read had `sendStop` set to true.

Check `finishedAsync()` to determine when the operation completes, or use `onFinishedAsync()` to set a callback.

Set `rbytes` to 0 to do a write-only operation, set `wbytes` to 0 to do a read-only operation. Or use:

```
bool writeAsync(uint8_t address, const void *buffer, size_t bytes, bool sendStop)
```

```
bool readAsync(uint8_t address, void *buffer, size_t bytes, bool sendStop)
```

The first call to an asynchronous write/read operation allocates the required DMA channels and internal buffer. If desired, call `end()` to free these resources.

24.1.2 `bool finishedAsync()`

Call to check if the asynchronous operations is completed.

24.1.3 `void onFinishedAsync(void(*function)(void))`

Set a (optional) callback for async operation. The `function` will be called when the asynchronous operation finishes.

24.1.4 `void abortAsync()`

Cancels any outstanding asynchronous transaction.


FILE SYSTEMS

The Arduino-Pico core supports using some of the onboard flash as a file system, useful for storing configuration data, output strings, logging, and more. It also supports using SD cards as another (FAT32) filesystem, with an API that's compatible with the onboard flash file system.

25.1 Flash Layout

Even though file system is stored on the same flash chip as the program, programming new sketch will not modify file system contents (or EEPROM data).

The following diagram shows the flash layout used in Arduino-Pico:



The file system size is configurable via the IDE menus, from 64k up to 15MB (assuming you have an RP2040 board with that much flash)

Note: to use any of file system functions in the sketch, add the following include to the sketch:

```
#include "LittleFS.h" // LittleFS is declared
// #include <SDFS.h>
// #include <SD.h>
// #include <FatFS.h>
```

25.2 Compatible Filesystem APIs

LittleFS is an onboard filesystem that sets aside some program flash for use as a filesystem without requiring any external hardware.

SDFS is a filesystem for SD cards, based on [SdFat 2.0](<https://github.com/earlephilhower/ESP8266SdFat>). It supports FAT16 and FAT32 formatted cards, and requires an external SD card reader.

SD is the Arduino-supported, somewhat old and limited SD card filesystem. It is recommended to use SDFS for new applications instead of SD.

FatFS implements a wear-levelled, FTL-backed FAT filesystem in the onboard flash which can be easily accessed over USB as a standard memory stick via FatFSUSB.

All of these filesystems can open and manipulate `File` and `Dir` objects with the same code because they implement a common end-user filesystem API.

25.3 FatFS File System Caveats and Warnings

The FAT filesystem is ubiquitous, but it is also around 50 years old and ill suited to SPI flash memory due to having “hot spots” like the FAT copies that are rewritten many times over. SPI flash allows a high, but limited, number of writes before losing the ability to write safely. Applications like data loggers where many writes occur could end up wearing out the SPI flash sector that holds the FAT **years** before coming close to the write limits of the data sectors.

To circumvent this issue, the FatFS implementation here uses a flash translation layer (FTL) developed for SPI flash on embedded systems. This allows for the same LBA to be written over and over by the FAT filesystem, but use different flash locations. For more information see [SPIFTL](<https://github.com/earlephilhower/SPIFTL>). In this mode the Pico flash appears as a normal, 512-byte sector drive to the FAT.

What this means, practically, is that about 5KB of RAM per megabyte of flash is required for housekeeping. Writes can also become very slow if most of the flash LBA range is used (i.e. if the FAT drive is 99% full) due to the need for garbage collection processes to move data around and preserve the flash lifetime.

Alternatively, if an FTL is not desired or memory is tight, FatFS can use the raw flash directly. In this mode sectors are 4K in size and flash is mapped 1:1 to sectors, so things like the FAT table updates will all use the same physical flash bits. For low-utilization operations this may be fine, but if significant writes are done (from the Pico or the PC host) this may wear out portions of flash very quickly, rendering it unusable.

25.4 LittleFS File System Limitations

The LittleFS implementation for the RP2040 supports filenames of up to 254 characters + terminating zero (i.e. `char filename[255]` or better `char filename[LFS_NAME_MAX]`), and as many subdirectories as space permits.

Filenames are assumed to be in the root directory if no initial “/” is present.

Opening files in subdirectories requires specifying the complete path to the file (i.e. `LittleFS.open("/sub/dir/file.txt", "r")`;). Subdirectories are automatically created when you attempt to create a file in a subdirectory, and when the last file in a subdirectory is removed the subdirectory itself is automatically deleted.

25.5 Uploading Files to the LittleFS File System on IDE 1.x (RP2040 only)

For the Pico (RP2040) only, *PicoLittleFS* is a tool which integrates into the obsolete Arduino 1.x IDE. It adds a menu item to **Tools** menu for uploading the contents of sketch data directory into a new LittleFS flash file system. Please note that this JAVA plug in for the obsolete 1.x IDE does **NOT** support the RP2350 (Pico 2).

- Download the tool: <https://github.com/earlephilhower/arduino-pico-littlefs-plugin/releases>
- In your Arduino sketchbook directory, create `tools` directory if it doesn't exist yet.
- Unpack the tool into `tools` directory (the path will look like `<home_dir>/Arduino/tools/PicoLittleFS/tool/picolittlefs.jar`) If upgrading, overwrite the existing JAR file with the newer version.
- Restart Arduino IDE.
- Open a sketch (or create a new one and save it).
- Go to sketch directory (choose Sketch > Show Sketch Folder).
- Create a directory named `data` and any files you want in the file system there.
- Make sure you have selected a board, port, and closed Serial Monitor.
- Double check the Serial Monitor is closed. Uploads will fail if the Serial Monitor has control of the serial port.
- Select **Tools > Pico LittleFS Data Upload**. This should start uploading the files into the flash file system.

25.6 Uploading Files to the LittleFS File System on IDE 2.x (RP2040 and RP2350)

For the original Pico (RP2040) and Pico 2 (RP2350), use the Typescript 2.x IDE tool which operates in the new Arduino 2.x IDE. This tool works on all Pico and Pico 2s (and ESP32s if you're so inclined).

- Download the new tool: <https://github.com/earlephilhower/arduino-littlefs-upload/releases>
- Exit the IDE, if running
- Copy the VSIX file manually to (Linux/Mac) `~/ .arduinoIDE/plugins/` (you may need to make this directory yourself beforehand) or to (Windows) `C:\Users\\.arduinoIDE\`
- Restart the IDE
- Double check the Serial Monitor is closed. Uploads will fail if the Serial Monitor has control of the serial port.
- Enter (Linux/Windows) `[Ctrl] + [Shift] + [P]` or (Mac) `[Cmd] + [Shift] + [P]` to bring up the command palette, then select/type `Upload LittleFS to Pico/ESP8266`

25.7 Downloading Files from a LittleFS System

Using `gdb` it is possible to dump the flash data making up the filesystem and then extract it using the `mklittlefs` tool. A working OpenOCD setup, DebugProbe, and `gdb` are required. To download the raw filesystem, from within GDB run:

```
^C (break)
(gdb) dump binary memory littlefs.bin &_FS_start &_FS_end
```

It may take a few seconds as GDB reads out the flash to the file. Once the raw file is downloaded it can be extracted using the `mklittlefs` tool from the BASH/Powershell/command line

```
$ <path-to-mklittlefs>/mklittlefs -u output-dir littlefs.bin
Directory <output-dir> does not exists. Try to create it.
gmon.out   > <output-dir>/gmon.out   size: 24518 Bytes
gmon.bak   > <output-dir>/gmon.bak   size: 1 Bytes
```

The defaults built into `mklittlefs` should be appropriate for normal LittleFS filesystems built on the device or using the upload tool.

25.8 SD Library Information

The included SD library is the Arduino standard one. Please refer to the [Arduino SD reference](<https://www.arduino.cc/en/reference/SD>) for more information.

25.9 Using Second SPI port for SD

The SD library `begin()` has been modified to allow you to use the second SPI port, SPI1. Just use the following call in place of `SD.begin(cspin)`

```
SD.begin(cspin, SPI1);
```

25.10 Enabling SDIO operation for SD

SDIO support is available thanks to SdFat implementing a PIO-based SDIO controller. This mode can significantly increase IO performance to SD cards but it requires that all 4 DAT0..DAT3 lines to be wired to the Pico (most SD breakout boards only provide 1-but SPI mode of operation).

To enable SDIO mode, simply specify the SD_CLK, SD_CMD, and SD_DAT0 GPIO pins. The clock and command pins can be any GPIO (not limited to legal SPI pins). The DAT0 pin can be any GPIO with remaining DAT1...3 pins consecutively connected.

..code:: cpp

```
SD.begin(RP_CLK_GPIO, RP_CMD_GPIO, RP_DAT0_GPIO);
```

No other changes are required in the application to take advantage of this high performance mode.

25.11 Using VFS (Virtual File System) for POSIX support

The VFS library enables sketches to use standard POSIX file I/O operations using standard FILE * operations. Include the VFS library in your application and add a call to map the VFS.root() to your filesystem. I.e.:

```
#include <VFS.h>
#include <LittleFS.h>

void setup() {
  LittleFS.begin();
  VFS.root(LittleFS);
  FILE *fp = fopen("/thisfilelivesonflash.txt", "w");
  fprintf(fp, "Hello!\n");
  fclose(fp);
}
```

Multiple filesystems can be VFS.map() into the VFS namespace under different directory names. For example, the following will make files on /sd reside on an externalSD card and files on /lfs live in internal flash.

```
#include <VFS.h>
#include <LittleFS.h>
#include <SDFS.h>

void setup() {
  LittleFS.begin();
  SDFS.begin();
  VFS.map("/lfs", LittleFS);
  VFS.map("/sd", SDFS);
  FILE *onSD = fopen("/sd/thislivesonsd.txt", "wb");
  ....
}
```

See the examples in the VFS library for more information.

25.12 File system object (LittleFS/SD/SDFS/FatFS)

25.12.1 setConfig

```
LittleFSConfig cfg;
cfg.setAutoFormat(false);
LittleFS.setConfig(cfg);

SDFSConfig c2;
c2.setCSPin(12);
SDFS.setConfig(c2);

FatFSConfig c3;
c3.setUseFTL(false); // Directly access flash memory
c3.setDirEntries(256); // We need 256 root directory entries on a format()
c3.setFATCopies(1); // Only 1 FAT to save 4K of space and extra writes
FatFS.setConfig(c3);
FatFS.format(); // Format using these settings, erasing everything
```

This method allows you to configure the parameters of a filesystem before mounting. All filesystems have their own `*Config` (i.e. `SDFSConfig` or `LittleFSConfig` with their custom set of options. All filesystems allow explicitly enabling/disabling formatting when mounts fail. If you do not call this `setConfig` method before performing `begin()`, you will get the filesystem's default behavior and configuration. By default, `LittleFS` and `FatFS` will autoformat the filesystem if it cannot mount it, while `SDFS` will not. `FatFS` will also use the built-in FTL to support 512 byte sectors and higher write lifetime.

25.12.2 begin

```
SDFS.begin()
or LittleFS.begin()
```

This method mounts file system. It must be called before any other FS APIs are used. Returns `true` if file system was mounted successfully, false otherwise.

Note that `LittleFS` will automatically format the filesystem if one is not detected. This is configurable via `setConfig`.

25.12.3 end

```
SDFS.end()
or LittleFS.end()
```

This method unmounts the file system.

25.12.4 format

```
SDFS.format()
or LittleFS.format()
```

Formats the file system. May be called either before or after calling `begin`. Returns `true` if formatting was successful.

25.12.5 open

```
SDFS.open(path, mode)
or LittleFS.open(path, mode)
```

Opens a file. `path` should be an absolute path starting with a slash (e.g. `/dir/filename.txt`). `mode` is a string specifying access mode. It can be one of “r”, “w”, “a”, “r+”, “w+”, “a+”. The meaning of these modes is the same as for the `fopen` C function.

r	Open text file for reading. The stream is positioned at the beginning of the file.
r+	Open for reading and writing. The stream is positioned at the beginning of the file.
w	Truncate file to zero length or create text file for writing. The stream is positioned at the beginning of the file.
w+	Open for reading and writing. The file is created if it does not exist, otherwise it is truncated. The stream is positioned at the beginning of the file.
a	Open for appending (writing at end of file). The file is created if it does not exist. The stream is positioned at the end of the file.
a+	Open for reading and appending (writing at end of file). The file is created if it does not exist. The initial file position for reading is at the beginning of the file, but output is always appended to the end of the file.

Returns *File* object. To check whether the file was opened successfully, use the boolean operator.

```
File f = LittleFS.open("/f.txt", "w");
if (!f) {
    Serial.println("file open failed");
}
```

25.12.6 exists

```
SDFS.exists(path)
or LittleFS.exists(path)
```

Returns *true* if a file with given path exists, *false* otherwise.

25.12.7 mkdir

```
SDFS.mkdir(path)
or LittleFS.mkdir(path)
```

Returns *true* if the directory creation succeeded, *false* otherwise.

25.12.8 rmdir

```
SDFS.rmdir(path)
or LittleFS.rmdir(path)
```

Returns *true* if the directory was successfully removed, *false* otherwise.

25.12.9 opendir

```
SDFS.opendir(path)
or LittleFS.opendir(path)
```

Opens a directory given its absolute path. Returns a *Dir* object.

25.12.10 remove

```
SDFS.remove(path)
or LittleFS.remove(path)
```

Deletes the file given its absolute path. Returns *true* if file was deleted successfully.

25.12.11 rename

```
SDFS.rename(pathFrom, pathTo)
or LittleFS.rename(pathFrom, pathTo)
```

Renames file from *pathFrom* to *pathTo*. Paths must be absolute. Returns *true* if file was renamed successfully.

25.12.12 info

```
FSInfo fs_info;
or LittleFS.info(fs_info);
```

Fills *FSInfo structure* with information about the file system. Returns *true* if successful, *false* otherwise. *info()* has been updated to support filesystems greater than 4GB and *FSInfo64* and *info64()* have been discarded.

25.13 Filesystem information structure

```
struct FSInfo {
    uint64_t totalBytes;
    uint64_t usedBytes;
    size_t blockSize;
    size_t pageSize;
    size_t maxOpenFiles;
    size_t maxPathLength;
};
```

This is the structure which may be filled using *FS::info* method. - *totalBytes* — total size of useful data on the file system - *usedBytes* — number of bytes used by files - *blockSize* — filesystem block size - *pageSize* — filesystem logical page size - *maxOpenFiles* — max number of files which may be open simultaneously - *maxPathLength* — max file name length (including one byte for zero termination)

25.13.1 setTimeCallback(time_t (*cb)(void))

```
time_t myTimeCallback() {
    return 1455451200; // UNIX timestamp
}
void setup () {
    LittleFS.setTimeCallback(myTimeCallback);
    ...
    // Any files will now be made with Pris' incept date
}
```

The SD, SDFS, and LittleFS filesystems support a file timestamp, updated when the file is opened for writing. By default, the Pico will use the internal time returned from `time(NULL)` (i.e. local time, not UTC, to conform to the existing FAT filesystem), but this can be overridden to GMT or any other standard you'd like by using `setTimeCallback()`. If your app sets the system time using NTP before file operations, then you should not need to use this function. However, if you need to set a specific time for a file, or the system clock isn't correct and you need to read the time from an external RTC or use a fixed time, this call allows you to do so.

In general use, with a functioning `time()` call, user applications should not need to use this function.

25.14 Directory object (Dir)

The purpose of *Dir* object is to iterate over files inside a directory. It provides multiple access methods.

The following example shows how it should be used:

```
Dir dir = LittleFS.openDir("/data");
// or Dir dir = LittleFS.openDir("/data");
while (dir.next()) {
    Serial.print(dir.fileName());
    if(dir.fileSize()) {
        File f = dir.openFile("r");
        Serial.println(f.size());
    }
}
```

25.14.1 next

Returns true while there are files in the directory to iterate over. It must be called before calling `fileName()`, `fileSize()`, and `openFile()` functions.

25.14.2 fileName

Returns the name of the current file pointed to by the internal iterator.

25.14.3 fileSize

Returns the size of the current file pointed to by the internal iterator.

25.14.4 fileTime

Returns the `time_t` write time of the current file pointed to by the internal iterator.

25.14.5 fileCreationTime

Returns the `time_t` creation time of the current file pointed to by the internal iterator.

25.14.6 isFile

Returns `true` if the current file pointed to by the internal iterator is a File.

25.14.7 isDirectory

Returns `true` if the current file pointed to by the internal iterator is a Directory.

25.14.8 openFile

This method takes `mode` argument which has the same meaning as for `SDFS/LittleFS.open()` function.

25.14.9 rewind

Resets the internal pointer to the start of the directory.

25.14.10 setTimeCallback(time_t (*cb)(void))

Sets the time callback for any files accessed from this Dir object via `openNextFile`. Note that the SD and SDFS filesystems only support a filesystem-wide callback and calls to `Dir::setTimeCallback` may produce unexpected behavior.

25.15 File object

`SDFS/LittleFS.open()` and `dir.openFile()` functions return a *File* object. This object supports all the functions of *Stream*, so you can use `readBytes`, `findUntil`, `parseInt`, `println`, and all other *Stream* methods.

There are also some functions which are specific to *File* object.

25.15.1 seek

```
file.seek(offset, mode)
```

This function behaves like `fseek` C function. Depending on the value of `mode`, it moves current position in a file as follows:

- if `mode` is `SeekSet`, position is set to `offset` bytes from the beginning.
- if `mode` is `SeekCur`, current position is moved by `offset` bytes.
- if `mode` is `SeekEnd`, position is set to `offset` bytes from the end of the file.

Returns `true` if position was set successfully.

25.15.2 position

```
file.position()
```

Returns the current position inside the file, in bytes.

25.15.3 size

```
file.size()
```

Returns file size, in bytes.

25.15.4 name

```
String name = file.name();
```

Returns short (no-path) file name, as `const char*`. Convert it to *String* for storage.

25.15.5 fullName

```
// Filesystem:
//  testdir/
//      file1
Dir d = LittleFS.openDir("testdir/");
File f = d.openFile("r");
// f.name() == "file1", f.fullName() == "testdir/file1"
```

Returns the full path file name as a `const char*`.

25.15.6 getLastWrite

Returns the file last write time, and only valid for files opened in read-only mode. If a file is opened for writing, the returned time may be indeterminate.

25.15.7 getCreationTime

Returns the file creation time, if available.

25.15.8 isFile

```
bool amIAFile = file.isFile();
```

Returns *true* if this *File* points to a real file.

25.15.9 isDirectory

```
bool amIADir = file.isDir();
```

Returns *true* if this *File* points to a directory (used for emulation of the SD.* interfaces with the `openNextFile` method).

25.15.10 close

```
file.close()
```

Close the file. No other operations should be performed on *File* object after `close` function was called.

25.15.11 openNextFile (compatibility method, not recommended for new code)

```
File root = LittleFS.open("/");
File file1 = root.openNextFile();
File file2 = root.openNextFile();
```

Opens the next file in the directory pointed to by the File. Only valid when `File.isDirectory() == true`.

25.15.12 rewindDirectory (compatibility method, not recommended for new code)

```
File root = LittleFS.open("/");
File file1 = root.openNextFile();
file1.close();
root.rewindDirectory();
file1 = root.openNextFile(); // Opens first file in dir again
```

Resets the `openNextFile` pointer to the top of the directory. Only valid when `File.isDirectory() == true`.

25.15.13 setTimeCallback(time_t (*cb)(void))

Sets the time callback for this specific file. Note that the SD and SDFS filesystems only support a filesystem-wide callback and calls to `Dir::setTimeCallback` may produce unexpected behavior.

USB (ARDUINO AND ADAFRUIT_TINYUSB)

Two USB stacks are present in the core. Users can choose the simpler Pico-SDK version or the more powerful Adafruit TinyUSB library. Use the Tools->USB Stack menu to select between the two.

26.1 Pico SDK USB Support

This is the default mode and automatically includes a USB-based serial port, `Serial` as well as supporting automatic reset-to-upload from the IDE. Note that if you `Serial.end()` in your code that the reset-to-upload feature will NOT work.

The Arduino-Pico core includes ported versions of the basic Arduino `Keyboard`, `Mouse` and `Joystick` libraries. These libraries allow you to emulate a keyboard, a gamepad or mouse (or all together) with the Pico in your sketches. These libraries only are available when using the built-in USB, not the Adafruit library.

See the examples and Arduino Reference at <https://www.arduino.cc/reference/en/language/functions/usb/keyboard/> and <https://www.arduino.cc/reference/en/language/functions/usb/mouse>

26.2 USB class

The USB class allows for applications and libraries to add, remove, or modify the USB connection. Before calling any of the class functions, be sure to include the appropriate header:

```
#include <USB.h>
```

26.3 Dynamic USB Configuration

Whenever changing the USB device information or adding or removing a device, the USB port must be disconnected in software using `USB.disconnect()` to ensure no partially-updated information gets used by the USB stack. Once configuration is completed calling `USB.connect()` will signal the PC that a new device has been attached to the port and it should re-scan and update the devices seen on your system.

Only the most commonly needed calls will be described in this document. For examples of implementing your own custom HID, please look at the `Keyboard` library shipped with the core.

26.3.1 void USB.disconnect()

Tells the Pico to electrically disconnect from an attached USB host. Any devices exported by the Pico should be removed in the host's OS/ This **must** be called before doing any USB modification calls. It is safe to call this function even if the Pico isn't actually plugged into a PC (i.e. when self-powered).

26.3.2 void USB.connect()

Tells the Pico to signal to the host that a device has been plugged in. The host OS should re-scan the Pico and create the new devices exported by it. Call this after modifying USB configurations

26.3.3 void USB.setVIDPID(uint16_t vid, uint16_t pid)

Sets the VID:PID the Pico will export to the host. By default it will use the settings defined for your specific board. Be aware that Using VID:s that are not registered by you with the USB Implementers Forum may be problematic. Only call after a `usbDisconnect()`.

26.3.4 void USB.setManufacturer(const char *str)

Sets the Manufacturer field text in the USB descriptor. Note that most OSes will use the VID (vendor ID) to identify the manufacturer but a `lsusb -v` or examination in the Windows device manager will show this manufacturer string. The string must be long-lived (i.e. not a local stack stream, make it a constant or on the heap only). Only call after a `usbDisconnect()`.

26.3.5 void USB.setProduct(const char *str)

Similar to `usbSetManufacturer`. Again, the OS may use the PID (product ID) to identify a device and not this string, but it will be present on deeper inspection. Only call after a `usbDisconnect()`.

26.3.6 void USB.setSerialNumber(const char *str)

Similar to `usbSetManufacturer`. This is a free-form string and need not be only numerical. Only call after a `usbDisconnect()`.

26.4 HID Polling Interval

By default, HID devices will request to be polled every 10ms (i.e. 100x per second). If you have a higher performance need, you can override this value by creating a global variable in your main application, set to the polling period:

```
int usb_hid_poll_interval = 1; // Set HID poll interval to 1ms (1kHz)
void setup() {
    ....
}
```

26.5 Ethernet over USB

See *Ethernet over USB*

26.6 Native TinyUSB Sketches

Sketches or libraries which want to implement their own low-level TinyUSB callbacks need to include the appropriate header to have real TinyUSB driver support for HID, MSC (USB stick), MIDI, and NCM (network).

```
// Include one or more headers from the following list
#include <tusb-hid.h>
#include <tusb-midi.h>
#include <tusb-msc.h>
#include <tusb-ncm.h>
```

26.7 Adafruit TinyUSB Arduino Support

Examples are provided in the `Adafruit_TinyUSB_Arduino` for the more advanced USB stack.

To use Serial with TinyUSB, you must include the TinyUSB header in your sketch to avoid a compile error.

```
#include <Adafruit_TinyUSB.h>
```

If you need to be compatible with the other USB stack, you can use an `ifdef`:

```
#ifdef USE_TINYUSB
#include <Adafruit_TinyUSB.h>
#endif
```

Also, this stack requires sketches to manually call `Serial.begin(115200)` to enable the USB serial port and automatic sketch upload from the IDE. If a sketch is run without this command in `setup()`, the user will need to use the standard “hold BOOTSEL and plug in USB” method to enter program upload mode.

26.8 Adafruit TinyUSB Configuration and Quirks

The Adafruit TinyUSB’s configuration header for RP2040 devices is stored in `libraries/Adafruit_TinyUSB_Arduino/src/arduino/ports/rp2040/tusb_config_rp2040.h` ([here](#)).

In some cases it is important to know what TinyUSB is configured with. For example, by having set

```
#define CFG_TUD_CDC 1
#define CFG_TUD_MSC 1
#define CFG_TUD_HID 1
#define CFG_TUD_MIDI 1
#define CFG_TUD_VENDOR 1
```

this configuration file defines the maximum number of USB CDC (serial) devices as 1. Hence, the example sketch `cdc_multi.ino` that is delivered with the library will not work, it will only create one USB CDC device instead of two. It will however work when the above `CFG_TUD_CDC` macro is defined to 2 instead of 1.

To do such a modification when using the Arduino IDE, the file can be locally modified in the Arduino core’s package files. The base path can be found per [this article](#), then navigate further to the `packages/rp2040/hardware/rp2040/<core version>/libraries/Adafruit_TinyUSB_Arduino` folder to find the Adafruit TinyUSB library.

When using PlatformIO, one can also make use of the feature that TinyUSB allows redirecting the configuration file to another one if a certain macro is set.

```
#ifdef CFG_TUSB_CONFIG_FILE
#include CFG_TUSB_CONFIG_FILE
#else
#include "tusb_config.h"
#endif
```

And as such, in the `platformio.ini` of the project, one can add

```
build_flags =
-DUSE_TINYUSB
-DCFG_TUSB_CONFIG_FILE=\"custom_tusb_config.h\"
-Iinclude/
```

and further add create the file `include/custom_tusb_config.h` as a copy of the original `tusb_config_rp2040.h` but with the needed modifications.

Note: Some configuration file changes have no effect because upper levels of the library don't properly support them. In particular, even though the maximum number of HID devices can be set to 2, and two `Adafruit_USBD_HID` can be created, it will not cause two HID devices to actually show up, because of [code limitations](#).

MULTICORE PROCESSING

The RP2040 chip has 2 cores that can run independently of each other, sharing peripherals and memory with each other. Arduino code will normally execute only on core 0, with the 2nd core sitting idle in a low power state.

By adding a `setup1()` and `loop1()` function to your sketch you can make use of the second core. Anything called from within the `setup1()` or `loop1()` routines will execute on the second core.

`setup()` and `setup1()` will be called at the same time, and the `loop()` or `loop1()` will be started as soon as the core's `setup()` completes (i.e. not necessarily simultaneously!).

See the `Multicore.ino` example in the `rp2040` example directory for a quick introduction.

27.1 Core 1 Operation

By default, core1 (the second core) has no non-user written code running on it. No interrupts, exceptions, or other background processing is done (but the core is still subject to hardware stalls due to on-die memory resource conflicts). When flash erase or write operations (i.e. `LittleFS` or `EEPROM`) are called from core0, core1 **will** be paused.

If `rp2040.getCycleCount` is needed to operate on the second core, then a periodic (once ever 16M clock cycles) `SYSTICK` exception will happen behind the scenes. For extremely time-critical operations this may not be desirable and can be disabled by defining a new `bool` variable to `true` anywhere in your sketch:

```
bool core1_disable_systick = true;
```

27.2 Stack Sizes

When the Pico is running in single core mode, core 0 has the full 8KB of stack space available to it. When using multicore `setup1/loop1` the 8KB is split into two 4K stacks, one per core. It is possible for core 0's stack to overwrite core 1's stack in this case, if you go beyond the 4K limitation.

To allocate a separate 8K stack for core 1, resulting in 8K stacks being available for both cores, simply define the following variable in your sketch and set it to `true`:

```
bool core1_separate_stack = true;
```

27.3 Pausing Cores

Sometimes an application needs to pause the other core on chip (i.e. it is writing to flash or needs to stop processing while some other event occurs). In most cases, however, these calls are **SHOULD NOT BE USED**. To synchronize cross-core operations use normal multiprocessor methods such as circular buffers, global `volatile` flags, mutexes, and the like. Stopping a core has massive implications and can kill networking and USB communications if done too long or too frequently.

27.3.1 void rp2040.idleOtherCore()

Sends a message to stop the other core (i.e. when called from core 0 it pauses core 1, and vice versa). Waits for the other core to acknowledge before returning.

The other core will have its interrupts disabled and be busy-waiting in an RAM-based routine, so flash and other peripherals can be accessed.

NOTE If you idle core 0 too long, then the USB port can become frozen. This is because core 0 manages the USB and needs to service IRQs in a timely manner (which it can't do when idled).

27.3.2 void rp2040.resumeOtherCore()

Resumes processing in the other core, where it left off.

27.3.3 void rp2040.restartCore1()

Hard resets Core1 from Core 0 and restarts its operation from `setup1()`. This can cause unpredictable behavior because globals and the heap are shared between cores and not re-initialized with this call. Use with extreme caution.

27.4 Communicating Between Cores

The RP2040 provides a hardware FIFO for communicating between cores, but it is used exclusively for the `idle/resume` calls described above. Instead, please use the following functions to access a software-managed, multicore safe FIFO. There are two FIFOs, one written to by core 0 and read by core 1, and the other written to by core 1 and read by core 0.

On the RP2350, the hardware FIFO is available for use using the SDK APIs or the calls below (which just wrap the SDK APIs very lightly). This is because the `idle/resume` calls above are implemented using a hardware doorbell on the RP2350, not the hardware FIFO.

You can (and probably should) use shared memory (such as `volatile` globals) or other normal multiprocessor communication algorithms to transfer data or work between cores, but for simple tasks these FIFO routines can suffice.

27.4.1 void rp2040.fifo.push(uint32_t)

Pushes a value to the other core. Will block if the FIFO is full.

27.4.2 bool rp2040.fifo.push_nb(uint32_t)

Pushes a value to the other core. If the FIFO is full, returns `false` immediately and doesn't block. If the push is successful, returns `true`.

27.4.3 uint32_t rp2040.fifo.pop()

Reads a value from this core's FIFO. Blocks until one is available.

27.4.4 bool rp2040.fifo.pop_nb(uint32_t *dest)

Reads a value from this core's FIFO and places it in `dest`. Will return `true` if successful, or `false` if the pop would block.

27.4.5 int rp2040.fifo.available()

Returns the number of values available to read in this core's FIFO.

SEMIHOSTING SUPPORT

Using special debugger breakpoints and commands, the Pico can read and write to the debugging console as well as read and write files on a development PC. The `Semihosting` library allows applications to use the semihosting support as a normal filesystem or serial port.

NOTE Semihosting only works when connected to an OpenOCD + GDB debug session. Running an application compiled for Semihosting without the debugger will cause a panic and hang the chip.

As of now, only ARM has support for Semihosting.

28.1 Running Semihosting on the Development Host

Start OpenOCD normally from inside a directory that you can read and write files within (i.e. do not run from `C:\\Program Files\\..` on Windows where general users aren't allowed to write). The starting directory will be where the Pico will read and write files using the `SemiFS` class. Be sure to keep the terminal window you ran OpenOCD in open, because all `SerialSemi` input and output will go to **that** terminal and not `gdb`'s.

Start GDB normally and connect to the OpenOCD debugger and enable semihosting support

```
(gdb) target extended-remote localhost:3333
(gdb) monitor arm semihosting enable
```

At this point load and run your ELF application as normal. Again, all `SerialSemi` output will go to the **OpenOCD** window, not GDB.

See the `hellosemi` example in the `Semihosting` library.

28.2 SerialSemi - Serial over Semihosting

Simply include `<Semihosting.h>` in your application and use `SerialSemi` as you would any other `Serial` port with the following limitations:

- Baud rate, bit width, etc. are all ignored
- Input is limited because `read` may hang indefinitely in the host and `available` is not part of the spec

`SerialSemi` can also be selected as the debug output port in the IDE, in which case `::printf` will write to the debugger directly.

28.3 SemiFS - Host filesystem access through Semihosting

Use `SemiFS` the same way as any other file system. Note that only file creation and renaming are supported, with no provision for iterating over directories or listing files. In most cases simply opening a `File` and writing out a debug dump is all that's needed:

```
SemiFS.begin();
File f = SemiFS.open("debug.dmp", "w");
f.write(buffer, size);
f.close();
SerialSemi.printf("Debug dump now available on host.\n");
```

PROFILING APPLICATIONS WITH GPROF

Applications running on the Pico can be profiled using GNU GPROF to show where the CPU is using its time on the device and how often certain functions are called. It does this by recompiling the application and adding a small preamble to each function built to identify what functions call what others (and how frequently). It also uses the SYSTICK exception timer to sample and record the PC 10,000 times per second. When an application is complete, the recorded data can be dumped to the host PC as a `gmon.out` file which can be processed by `arm-none-eabi-gprof` into useful data.

A histogram of PCs and tally of function caller/callees can take a significant amount of RAM, from 100KB to 10000KB depending on the size of the application. As such, while the RP2040 **may** be able to profile small applications, this is only really recommended on the RP2350 with external PSRAM. The profiler will automatically use PSRAM when available. Call `rp2040.getProfileMemoryUsage()` to get the memory allocated at runtime.

Profiling also adds processing overhead in terms of the periodic sampling and the function preambles. In most cases there is no reason to enable (and many reasons to disable) profiling when an application is deployed to the field.

To transfer the `GMON.OUT` data from the Pico to the host HP can be done by having the application write it out to an SD card or a LittleFS filesystem which is then manually dumped, but for ease of use semihosting can be used to allow the Pico (under the control of OpenOCD and GDB) to write the `gmon.out` file directly on the host PC, ready for use.

NOTE Semihosting only works when connected to an OpenOCD + GDB debug session. Running an application compiled for Semihosting without the debugger will cause a panic and hang the chip.

As of now, only ARM has support for Semihosting or GPROF.

29.1 Enabling Profiling in an Application

The `Tools->Profiling->Enabled` menu needs to be selected to enable profiling support in GCC. This will add the necessary preamble to every function compiled (**Note** that the `libpico` and `libc` will not be instrumented because they are pre-built so calls from them will not be fully instrumented. However, PC data will still be grabbed and decoded from them at runtime.)

The application will automatically start collecting profiling data even before `setup` starts in this mode. It will continue collecting data until you stop and write out the profiling data using `rp2040.writeProfiling()` to dump to the host, a file, serial port, etc.

For example, an application which does all its processing in `setup()` might look like:

```
#include <SemiFS.h>
void setup() {
    SerialSemi.printf("BEGIN\n");
    do_some_work_that_takes_a_long_time_with_many_function_calls();
    // Do lots of other work...
    // Now all done...
```

(continues on next page)

(continued from previous page)

```

SerialSemi.printf("Writing GMON.OUT\n");
SemiFS.begin();
File gmon = SemiFS.open("gmon.out", "w");
rp2040.writeProfiling(&gmon);
gmon.close();
SerialSemi.printf("END\n");
}
void loop() {}

```

29.2 Collecting and Analyzing Profile Data

Running this application under `semihosting` GDB and OpenOCD generates a `gmon.out` file in the OpenOCD current working directory. This file, combined with the ELF binary build in the IDE and loaded through GDB, can produce profiler output using

```

$ /path/to/arm-none-eabi/bin/arm-none-eabi-gprof /path/to/sketch.ino.elf /path/to/gmon.
↪out

```

See the `rp2040/Profiling.ino` example for more details.

RP2350 SPECIFIC NOTES

The RP2350 chip (present on the Raspberry Pi Pico 2 board and many others) is supported by the core with some minor caveats:

- PSRAM is supported via a new `pmalloc` call and PSRAM variable decorator.
- Both RP2350A and RP2350B (48 GPIOs) are supported.

30.1 ARM and RISC-V Modes

Either set of cores can be used on the RP2350, ARM Cortex-M33 or RISC-V Hazard3. Select the desired core from the IDE menus under `Tools->CPU Architecture`. As of the initial release, all libraries should work under the new RISC-V mode with the exception of FreeRTOS. If not, patches are always welcome.

30.2 P2350-E9 Errata (“Increased leakage current on Bank 0 GPIO when pad input is enabled”)

Like all chips, the RP2350-A2 stepping has post-silicon chip errata covering certain bugs found after the chip was manufactured. Probably the most (in)famous and concerning is RP2350-E9 which is noted as resulting in “Increased leakage current on Bank 0 GPIO when pad input is enabled.” At a high level, this means that in some cases when an input pin is being driven by a weak (high impedance) input, it may not read properly.

After discussion with the community and exploration of the issue by many users, this core has decided not to implement any forced workarounds for this issue. Given the physical nature of the problem and how no one specific solution is appropriate for all conditions.

For more information please read the errata yourself and check the Raspberry Pi Forums for the latest updates.

RP2350 PSRAM SUPPORT

The RP2350 chip in the Raspberry Pi Pico 2, and other RP2350 boards, supports an external interface to PSRAM. When a PSRAM chip is attached to the processor (please note that there is none on the Pico 2 board, but iLabs and SparkFun boards, among others, do have it), up to 16 megabytes of additional memory can be used by the chip.

While this external RAM is slower than the built-in SRAM, it is still able to be used in any place where normal RAM would be used (other than for memory-mapped functions and statically initialized variables).

When present, PSRAM can be used in two ways: for specific instantiated variables, or through a malloc-like access method. Both can be used in any single application.

31.1 Using PSRAM for regular variables

Similar to `PROGMEM` in the original Arduino AVR devices, the variable decorator `PSRAM` can be added to map a variable into PSRAM. Simply add `PSRAM` to an array and it will be mapped into PSRAM:

```
...  
float weights[4000] PSRAM; // Place an array of 4000 floats in PSRAM  
char samplefile[1'000'000] PSRAM; // Allocate 1M for WAV samples in PSRAM  
...
```

These variables can be used just like normal ones, no special handling is required. For example:

```
char buff[4 * 1024 * 1024]; // 4MB array  
  
void initBuff() {  
    bzero(buff, sizeof(buff));  
    for (int i = 0; i < 4 * 1024 * 1024; i += 4096) {  
        buff[i] = rand();  
    }  
}
```

The only restriction is that these variables may not be initialized statically. The following example will **NOT** work:

```
char buff[] = "This is illegal and will not function";
```

31.2 Using PSRAM for dynamic allocations

PSRAM can also be used as a heap for dynamic allocations using `pmalloc` and `pcalloc`. These calls function exactly like normal `malloc` and `calloc` except they allocate space from PSRAM.

Simply replace a `malloc` or `calloc` with `pmalloc` or `pcalloc` to use the PSRAM heap. Other calls, such as `free` and `realloc` “just work” and do not need to be modified (they check where the passed-in pointer resides and do the right thing automatically).

For example, to create and modify large buffer in PSRAM:

```
void ex() {
    int *buff;
    // Ignoring OOM error conditions in example for brevity
    buff = (int *)pmalloc(10000 * sizeof(*buff));
    // Something happened and we need more space, so...
    buff = (int *)realloc(buff, 20000 * sizeof(*buff)); // buff now has 20K elements
    for (int i = 0; i < 20000; i++) {
        buff[i] = i;
    }
    // Do some work, now we're done
    free(buff);
}
```

C++ objects can be allocated in PSRAM using “placement new” constructors. Note that this will only place immediate object data in PSRAM: if the object creates any other objects via `new` *those* objects will be placed in normal RAM unless the object also uses placement new constructors.

31.3 Checking on PSRAM space

The `rp2040` helper object has the following calls to return the state of the PSRAM heap with the following calls, similar to the normal RAM heap:

31.3.1 `int rp2040.getPSRAMSize()`

Return the total size of the attached PSRAM chip. This is the **RAW** space and does not take into account any allocations for static variables or dynamic allocations. (i.e. it will return 1, 2, 4, 8, or 16MV depending on the chip).

31.3.2 `int rp2040.getTotalPSRAMHeap()`

Returns the total PSRAM heap (free and used) available or used for `pmalloc` allocations.

31.3.3 `int rp2040.getUsedPSRAMHeap()`

Returns the total used bytes (including any overhead) of the PSRAM heap.

31.3.4 `int getFreePSRAMHeap()`

Returns the total free bytes in the PSRAM heap. (Note that this may include multiple non-contiguous chunks, so this is not always the maximum block size that can be allocated.)

BLUETOOTH ON PICO W SUPPORT

32.1 Enabling Bluetooth

To enable Bluetooth (BT), use the Tools->IP/Bluetooth Stack menu. It requires around 80KB of flash and 20KB of RAM when enabled.

Both Bluetooth Classic and BluetoothBLE are enabled in `btstack_config.h`.

32.2 Included Bluetooth Libraries

You may use the KeyboardBT, MouseBT, or JoystickBT to emulate a Bluetooth Classic HID device using the same API as their USB versions.

You may use the KeyboardBLE, MouseBLE, or JoystickBLE to emulate a Bluetooth Low Energy (BLE) HID device using the same API as their USB versions.

The SerialBT library implements a very simple SPP (Serial Port Profile) Serial-compatible port.

Connect and use Bluetooth peripherals with the PicoW using the BluetoothHIDMaster library.

BluetoothAudio (A2DP) is also supported, both sink and source.

32.3 Writing Custom Bluetooth Applications

You may also write full applications using the BTStack standard callback method, but please be aware that the Raspberry Pi team has built an interrupt-driven version of the BT execute loop, so there is no need to actually call `btstack_run_loop_execute` because the `async_context` handler will do it for you.

Do not call ``cyw43_arch_init`` in your code, either, as that is part of the PicoW variant booting process.

For many BTStack examples, you simply need call the included `btstack_main()` and make sure that `hci_power_control(HCI_POWER_ON)`; is called afterwards to start processing (in the background).

32.4 Locking Requirements

You will also need to acquire the BT `async_context` system lock before calling any BTStack APIs. The proper way to do this is using the RAII locking object `BluetoothLock` which handles FreeRTOS and non-OS cases

```
{  
    BluetoothLock lock; // Creating this object on the stack grabs the lock and ensures_  
↳it's released on exit of this block  
    ... Call BTStack APIs ...  
} // The lock is automatically released
```

Note that if you need to modify the system `btstack_config.h` file, do so in the `include` directory and rebuild the Pico SDK static library. Otherwise the change will not take effect in the precompiled code, leading to really bad behavior.

BLUETOOTH HID MASTER

The PicoW can connect to a Bluetooth Classic or Bluetooth BLE keyboard, mouse, or joystick and receive input events from it. As opposed to the `Keyboard`, `Mouse`, and `Joystick` libraries, which make the PicoW into a peripheral others can use, this lets the PicoW use the same kinds of peripherals in a master role.

33.1 BTDeviceInfo Class

The `BluetoothHCI` class implements a scanning function for classic and BLE devices and can return a `std::vector` of discovered devices to an application. Iterate over the list using any of the STL iteration methods (i.e. `for (auto e : list)`). The elements of this list are `BTDeviceInfo` objects which have the following member functions:

`BTDeviceInfo::deviceClass()` returns the Bluetooth BLE UUID or the Bluetooth device class for the device. This specifies the general class of the device (keyboard, mouse, etc.).

`BTDeviceInfo::address()` and `BTDeviceInfo::addressString()` return the Bluetooth address as a binary array or a string that can be used to print.

`BTDeviceInfo::addressType()` returns whether the BLE address is random or not, and is not generally needed by a user application.

`BTDeviceInfo::rssi()` returns an approximate dB level for the device. Less negative is stronger signal.

`BTDeviceInfo::name()` returns the advertised name of the device, if present. Some devices or scans do not return names for valid devices.

33.2 BluetoothHCI Class

The `BluetoothHCI` class is responsible for scanning for devices and the lower-level housekeeping for a master-mode Bluetooth application. Most applications will not need to access it directly, but it can be used to discover nearby BT devices. As part of the application Bluetooth setup, call `BluetoothHCI::install()` and then `BluetoothHCI::begin()` to start BT processing. Your application is still responsible for all the non-default HCI initialization and customization. See the `BluetoothScanner.ino` example for more info.

33.3 BluetoothHIDMaster Operation

Most applications will use the `BluetoothHIDMaster` class and, after connecting, receive callbacks from the Bluetooth stack when input events (key presses, mouse moves, button mashes) occur.

Application flow will generally be:

1. Install the appropriate callbacks using the `BluetoothHIDMaster::onXXX` methods
2. Start the Bluetooth processing with `BluetoothHIDMaster::begin()` or `BluetoothHIDMaster::beginBLE()`
3. Connect to the first device found with `BluetoothHIDMaster::connectXXX()` and start receiving callbacks.
4. Callbacks will come at interrupt time and set global state variables, which the `main loop()` will process

33.4 Callback Event Handlers

The main application is informed of new inputs via a standard callback mechanism. These callbacks run at interrupt time and should not do significant work, `delay()`, or allocate or free memory. The most common way of handling this is setting global volatile flags and variables that the main `loop()` will poll and process.

33.4.1 Mouse Callbacks

The `BluetoothHIDMaster::onMouseMove` callback gets the delta X, Y, and wheel reported by the device. The `BluetoothHIDMaster::onMouseButton` gets a button number and state (up or down) and will be called each time an individual button is reported changed by the mouse.

```
void mouseMoveCB(void *cbdata, int dx, int dy, int dw) {
    // Process the deltas, adjust global mouse state
}

void mouseButtonCB(void *cbdata, int butt, bool down) {
    // Set the global button array with this new info
}
```

33.4.2 Keyboard Callbacks

The `BluetoothHIDMaster::onKeyDown` callback receives the raw HID key (**NOT ASCII**) sent by the device on a key press while `BluetoothHIDMaster::onKeyUp` gets the same when a key is released. Note that up to 6 keys can be pressed at any one time. For media keys (“consumer keys” in the USB HID documentation) the `BluetoothHIDMaster::onConsumerKeyDown` and `BluetoothHIDMaster::onConsumerKeyUp` perform the same function (and receive the consumer key IDs defined by the USB HID spec and not ASCII).

To convert the key press and release (including SHIFT handling), use a `HIDKeyStream` object. Simply write the raw HID key and the up/down state to the stream and read back the ASCII for use in an application.

```
HIDKeyStream keystream;

void keyDownCB(void *cbdata, int key) {
    keystream.write((uint8_t)key);
    keystream.write((uint8_t) true); // Keystream now has 1 ASCII character to read out,
    ↪and use
    char ascii = keystream.read();
    // ....
}

void keyUpCB(void *cbdata, int key) {
    // Normally don't do anything on this, the character was read in the keyDownCB
}

void consumerKeyDownCB(void *cbdata, int key) {
    // switch(key) and use cases from the USB Consumer Key page
}

void consumerKeyUpCB(void *cbdata, int key) {
    // switch(key) and use cases from the USB Consumer Key page
}
```

33.4.3 Joystick Callbacks

A single `BluetoothHIDMaster::onJoystick` callback gets activated every time a report from a joystick is processed. It receives (potentially, if supported by the device) 4 analog axes, one 8-way digital hat switch position, and up to 32 button states at a time.

```
void joystickCB(void *cbdata, int x, int y, int z, int rz, uint8_t hat, uint32_t_
↳buttons) {
    // HAT 0 = UP and continues clockwise. If no hat direction it is set to 0x0f.
    // Use "buttons & (1 << buttonNumber)" to look at the individual button states
    // ...
}
```

33.4.4 PianoKeyboard Example

See the `PianoKeyboard.ino` and `PianoKeyboardBLE.ino` examples for more information on callback operation.

33.4.5 BluetoothHIDMaster::onXXX Callback Installers

```
void BluetoothHIDMaster::onMouseMove(void (*)(void *, int, int, int), void *cbData =_
↳nullptr);
void BluetoothHIDMaster::onMouseButton(void (*)(void *, int, bool), void *cbData =_
↳nullptr);
void BluetoothHIDMaster::onKeyDown(void (*)(void *, int), void *cbData = nullptr);
void BluetoothHIDMaster::onKeyUp(void (*)(void *, int), void *cbData = nullptr);
void BluetoothHIDMaster::onConsumerKeyDown(void (*)(void *, int), void *cbData =_
↳nullptr);
void BluetoothHIDMaster::onConsumerKeyUp(void (*)(void *, int), void *cbData = nullptr);
void BluetoothHIDMaster::onJoystick(void (*)(void *, int, int, int, int, uint8_t, uint32_
↳t), void *cbData = nullptr);
```

33.5 BluetoothHIDMaster Class

33.5.1 bool BluetoothHIDMaster::begin()

Installs and configures the Bluetooth Classic stack and starts processing events. No connections are made at this point. When running in Classic mode, no BLE devices can be detected or used.

33.5.2 bool BluetoothHIDMaster::begin(const char *BLEName)

Installs and configures the Bluetooth BLE stack and starts processing events. No connections are made at this point. When running in BLE mode, no Classic devices can be detected or used.

33.5.3 bool BluetoothHIDMaster::connected()

Returns if the Bluetooth stack is up and running and a connection to a device is currently active.

33.5.4 void BluetoothHIDMaster::end()

Disables the Bluetooth stack. Note that with the current Bluetooth implementation restarting the stack (i.e. calling `begin()` after `end()`) is not stable and will not work. Consider storing state and rebooting completely if this is necessary.

33.5.5 `bool BluetoothHIDMaster::running()`

Returns if the Bluetooth stack is running at all. Does not indicate if there is an active connection or not.

33.5.6 `bool BluetoothHIDMaster::hciRunning()`

Returns if the Bluetooth stack has passed the initial HCI start up phase. Until this returns `true` no Bluetooth operations can be performed.

33.5.7 `std::vector<BTDeviceInfo> BluetoothHIDMaster::scan(uint32_t mask, int scanTimeSec, bool async)`

Passes through the `BluetoothHCI::scan()` function to manually scan for a list of nearby devices. If you want to connect to the first found device, this is not needed.

33.5.8 `bool BluetoothHIDMaster::connect(const uint8_t *addr)`

Start the connection process to the Bluetooth Classic device with the given MAC. Note that this returns immediately, but it may take several seconds until `connected()` reports that the connection has been established.

33.5.9 `bool BluetoothHIDMaster::connectKeyboard(), connectMouse(), connectJoystick(), connectAny()`

Connect to the first found specified Bluetooth Classic device type (or any HID device) in pairing mode. No need to call `scan()` or have an address.

33.5.10 `bool BluetoothHIDMaster::connectBLE(const uint8_t *addr, int addrType)`

Start the connection process to the Bluetooth BLE device with the given MAC. Note that this returns immediately, but it may take several seconds until `connected()` reports that the connection has been established.

33.5.11 `bool BluetoothHIDMaster::connectBLE()`

Connect to the first found BLE device that has a HID service UUID (keyboard, mouse, or joystick)

33.5.12 `bool BluetoothHIDMaster::disconnect()`

Shuts down the connection to the currently connected device.

33.5.13 `void BluetoothHIDMaster::clearPairing()`

Erases all Bluetooth keys from memory. This effectively “forgets” all pairing between devices and can help avoid issues with the beta Bluetooth stack in the SDK.

BLUETOOTH AUDIO (A2DP SOURCE AND SINK)

The PicoW can be used as a Bluetooth Audio sink or source with the `BluetoothAudio` class. Operation is generally handled “automatically” in the background so while the audio is playing or streaming the main application can perform other operations (like displaying playback info, polling buttons for controls, etc.)

```
#include <BluetoothAudio.h>
...
```

Note about CPU usage: Bluetooth SBC audio is a compressed format. That means that it takes non-trivial amounts of CPU to compress on send, or decompress on receive. Transmitting precompressed audio from, say, MP3 or AAC, requires first decompressing the source file into raw PCM and then re-compressing them in the SBC format. You may want to consider overclocking in this case to avoid underflow.

34.1 A2DPSink

This class implements slave sink-mode operation with player control (play, pause, etc.) and can play the received and decoded SBC audio to `PWMAudio`, `I2S`, or a user-created `BluetoothAudioConsumer`` class.

The `A2DPSink.ino` example demonstrates turning a PicoW into a Bluetooth headset with `PWMAudio`.

34.2 A2DPSource

This class implements a master source-mode SBC Bluetooth A2DP audio connection which transmits audio using the standard `Stream` interface (like `I2S` or `PWMAudio`). The main application connects to a Bluetooth speaker and then writes samples into a buffer that’s automatically transmitted behind the scenes.

The `A2DPSource.ino` example shows how to connect to a Bluetooth speaker, transmit data, and respond to commands from the speaker.

BLE (BLUETOOTH LOW ENERGY) SERVER/CLIENT

Support for using the Pico W as a BLE server (peripheral) or BLE client (central) is available through the BLE library.

Note: These instructions assume knowledge about BT and BLE in general. Look at the official ArduinoBLE documentation for a quick overview of the basics.

This library was developed specifically for the BT implementation used in the Pico SDK, BTStack. Its API is close to the ESP32 BLE and the official ArduinoBLE, but not directly compatible with either. However, if you have used either of those libraries then coming up to speed on Arduino-Pico BLE should be straightforward.

To use this library, include BLE.h in your sketch and ensure the Tools->IP/BT Stack option in the menus has + Bluetooth enabled (and, obviously, you need a BT-enabled Pico or compatible board with RM2 coprocessor).

```
#include <BLE.h>
...
void setup() {
  // Optionally set security mode, before .begin, see below
  BLE.begin(); // Initialize the BT stack
  ...
}
```

This library is not compatible with FreeRTOS due to memory allocations required at interrupt time.

35.1 General Architecture

BLE implements a hierarchical object structure, with a top-level BLE containing either a BLEServer or a BLEClient. BLE handles scanning for devices to connect to in BLEClient mode, but other than that all work is handled by the BLEServer or BLEClient as appropriate.

Applications can't generate their own BLEServer or BLEClient objects, they must use the BLE.server() or BLE.client() calls to get a pointer to the global server or client object.

```
#include <BLE.h>
void setup() {
  BLE.begin();
  auto server = BLE.server(); // Get pointer to single global server object
  // ... create a BLEService with BLECharacteristics somehow...
  server->addService(...); // Add the service we just made to the object
  server->startAdvertising(); // Tell the world about it!
}
```

BLEServer holds a collection of application-defined BLEService objects which represent a BLE service. Each BLEService can contain a list of BLECharacteristics which are what the host PC or phone will actually interact with. Each BLECharacteristic contains an application-defined value which can be read or written by the host PC.

The sketch can be notified when the host PC or phone writes to one of its characteristics (i.e. a callback could set the dimming of a LED depending on the value written by the PC).

`BLEClient` connects to a remote BLE server (peripheral) and creates a set of `BLERemoteService` objects, each of which can contain zero or more `BLERemoteCharacteristic` objects that the remote device supports. Each of those `BLERemoteCharacteristic` can be read or written (if allowed) and can be optionally notified when the remote changes through the `onNotify` callback (again, if the remote server allows it).

Sketches operate with the BLE at two levels: main application and BLE-event triggered callbacks. The main app can write or read a characteristic at any time. Callbacks happen when the remote end of the connection performs a read or write to a characteristic and execute at interrupt-level (so no filesystem access, etc.).

35.2 General Bluetooth Support Classes

35.2.1 BLEAddress

This class holds a BLE MAC address. As of the initial release, only public addresses are supported. Randomized ones are not yet, but if they're important to you please submit a PR.

`BLEAddress(uint8_t *a)`

Creates a `BLEAddress` using the 6-byte MAC of a device.

```
uint8_t mySpecialDevice[6] = {0x01, 0x02, 0x03, 0x04, 0x05, 0x06};
BLEAddress x(mySpecialDevice);
```

`BLEAddress(String a)`

Creates a `BLEAddress` by parsing the MAC in human readable form (hex separated with colons)

```
BLEAddress x("01:02:03:04:05:06");
```

35.2.2 BLEUUID

All services and characteristics are identified by UUIDs in BLE. There are many predefined 16-bit UUIDs for common devices such as exercise equipment or home monitoring, but anyone can create their own 128-bit UUID for a customized service and characteristics.

`BLEUUID(uint16_t u)`

Create a 16-bit UUID. See [Assigned Numbers](#) for the values predefined by the Bluetooth SIG.

```
BLEUUID batteryServiceUUID(0x180F);
```

`BLEUUID(const uint8_t u[16])`

Create a 128-bit UUID (16 bytes) from an array of bytes

```
uint8_t mySuperCool[16] = {0, 1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15};
BLEUUID mySuperCoolUUID(mySuperCool);
```

BLEUUID(String u)

Creates a 128-bit UUID from a human-readable string

```
BLEUUID myNewUUID("040b4668-cae0-4b57-88c6-a749d7b1e3dd");
```

35.3 BLE (Bluetooth Low Energy) Base

The BLE object is how a sketch interacts with the hardware Bluetooth stack. It manages the low-level BTStack and contains either a BLEClient or BLEServer where the actual BLE operations will happen.

35.3.1 Configuring Security and Starting Up

Before calling BLE.begin() you can specify if you want the Pico to request a bonding with “Just Works” security (used for things like mice or headsets where there really isn’t a good user input/output capability) or allow any device to connect without building a connection (the default)

BLE.setSecurity(BLESecurityNone or BLESecurityJustWorks)

Configures the BLE security model. By default no pairing will be needed and devices will be able to interact with any services shared on this Pico. BLESecurityJustWorks enables PIN-less pairing with a BLE central/client which enables encryption (but not authentication).

This must be called **before** BLE.begin() is executed

BLE.begin(String name)

Starts the BLE stack on the Pico. Call it before setting up any services or client operations. The name is used when advertising the device.

BLEAddress BLE.address()

Returns this Pico’s BLE MAC address. Only valid after BLE.begin().

35.4 Accessing the Global BLEServer or BLEClient

To get a pointer to either the server or client objects to actually do work, call the appropriate BLE method

35.4.1 BLEServer *BLE.server()

Returns the global server object which will contain a list of BLEService objects that will be used by the outside world to connect to this Pico. See the Server section below for more information.

35.4.2 BLEClient *BLE.client()

Returns the global client object which will be used to connect to a remote BLE server, remote services, and remove characteristics. See the Client section below

35.5 Configuring BLE Advertising

Advertising is the way that a BLE device shares its presence to the world. The BLE hardware will broadcast a small (31 byte) packet containing information such as the device name, what it looks like, and any service UUIDs it provides. BLE clients normally don’t need to advertise and can ignore the following information.

35.5.1 BLEAdvertising *BLE.advertising()

This call returns the current advertising object for any defined servers. In general, sketches do not need to work with this call or BLEAdvertising at all, but this call lets you do things like add URLs or appearance information.

35.5.2 BLE.startAdvertising(bool advertiseServiceUUID)

After all services are created (see below) the sketch needs to use this call to start broadcasting for BLE clients to find it. Call this after all services are defined, or after BLE.stopAdvertising() and changing services or characteristics. Without this call, your Pico won't be discoverable. The Boolean flag advertiseServiceUUID controls inclusion of the service UUID in the advertising data.

35.5.3 BLE.stopAdvertising()

Turns off advertising to allow modifying services/etc.

35.6 Finding BLE Servers to Connect To

BLE clients need to listen the BLE advertisements around them to discover servers they can connect to. This library allows for scanning for all servers, or only servers exposing a service they care about (i.e. only discovering available thermostats or heart rate monitors).

Listens to the BLE announcements for timeoutsec seconds and returns a BLEScanReport which is a `std::list<BLEAddress>` of all seen BLE servers available. Entire in this list can be used in a `BLE.client()->connect()` call to initiate a BLE client connection (see below).

Like the prior call, except only returns servers who are advertising the service UUID specified. Most sketches will want to use this call to look for only the device types they want (i.e. `auto cyclingInfoList = BLE.scan(BLEUUID(0x1816)); // Only look for cycling devices`)

The information for each BLE device seen is stored in memory, taking around 100 bytes of memory per device. If sketches are very memory constrained, call this method to free all the memory associated with the last `BLE.scan()` after you have selected a single device to connect to. Most sketches don't need to do this.

35.7 Implementing a BLE Server (peripheral/device)

A BLE gadget/peripheral/device offers zero or more BLEService to the outside world. Each BLEService contains zero or more BLECharacteristics that the outside world can read and/or write to. The objects defining these services and characteristics must be created before calling `BLE.startAdvertising()`.

35.7.1 BLEService

A BLEService is essentially a container to hold a list of BLECharacteristics identified by a BLEUUID that identifies the type of service.

For well known, predefined services these UUIDs are standardized by the Bluetooth SIG. If you are implementing a gadget that provides predefined services, using the well known service UUIDs (see section 3.4.1 in [Assigned Numbers](#)) will allow any BLE client device (PC, phone, home hub) to interact with the Pico.

You can (and should) generate your own UUID (uuidgen on Linux or any online generator) when creating custom services.

Create a BLEService with the UUID using new in a function

```

void setup() {
  BLE.begin();
  BLEService *cyclingPowerService = new BLEService(BLEUUID(0x1818)); // 0x1818 defined
  ↪by SIG as "Cycling Power Service"
  ...

```

or using a global variable (because you need the BLEService object to live for the entire application, you can't take the address of an immediate local variable... it won't be there after the function exits)

```

BLEService cyclingPowerService = BLEService(BLEUUID(0x1818)); // 0x1818 defined by SIG
  ↪as "Cycling Power Service"

void setup() {
  BLE.begin();
  ...

```

35.7.2 Adding Characteristics to a BLEService

Once you have a BLEService you need to create BLECharacteristics to share data (i.e. current temperature, running speed, solar power, etc.) with a client. They can be thought of as a free-form variable that both your sketch and the outside world can read (and update if permitted).

Characteristics have a UUID to identify them (again, there are well-known ones for well-known services and you should use them if appropriate, or generate your own for custom ones you generate).

Note that for custom UUIDs, the UUID used for characteristics should not be the same as the UUID for the custom service. Generate new UUIDs for every characteristic or it could confuse BLE clients.

Create a characteristic with the following constructor (again, be sure it is a "long lived" variable to make it global or use new to make it on the heap

BLECharacteristic(BLEUUID u, uint16_t characteristicPermission, const char *desc = nullptr, uint8_t permR = 0, uint8_t permW = 0)

Creates a characteristic with the given UUID.

Permissions is the binary OR (|) of BLERead, BLEWrite, BLENotify (i.e. BLERead | BLENotify or BLERead | BLEWrite) where BLERead means the client (and the sketch) can read the value (i.e. it is an output of your sketch), BLEWrite means the client can write the value (the sketch can, too, of course), and BLENotify means the Pico will let the client know when the Pico changes it with setValue(), via the BLE notify message.

The optional desc parameter is a human-readable text description of the characteristic. It is not mandatory and only certain BLE tools can read and display it.

```

void setup() {
  BLE.begin();
  BLEService *cyclingPowerService = new BLEService(BLEUUID(0x1818)); // 0x1818 defined
  ↪by SIG as "Cycling Power Service"
  BLECharacteristic *pwrChar = new BLECharacteristic(BLEUUID(0x2A63), BLERead, "How
  ↪hard am I working"); // 0x2a64 is "Cycling Power Measurement"

```

Once a characteristic has been created, add it to a service. Services can have many characteristics, and the order in which they are added is not generally important since they are identified by the UUID, not the index.

Keep the characteristic variable pointer handy to set values to it or receive callbacks when remote reads or writes happen.

BLEService::addCharacteristic(BLECharacteristic *c)

Adds the characteristic to the service. As always, the variable needs to be on the heap or a global to ensure the pointer remains valid the lifetime of the sketch.

35.7.3 Setting Characteristic Data

Characteristics can be read and written to by the sketch (and the remote client if permissions allow it). They can be any format desired (character strings, binary floating point, 1-byte booleans), but for well-known services be sure to use the format specified by the Bluetooth SIG.

When values are set by the application, if the BLE client requests (and is permitted) notification, they will automatically get a message with the new data, the sketch itself needs do nothing.

BLECharacteristic::setValue(<simple data type>)

The characteristic object can set by the sketch by calling this function. The single value passed in will be stored in the characteristic in the same format as passed-in (i.e. `setValue((uint16_t)0xabcd)` would set the characteristic to 2 bytes of data, {0xab, 0xcd}).

BLECharacteristic::setValue(const uint8_t *data, size_t size)

Sets the characteristic to any binary data (i.e. a large struct) you pass in, at any size. The data is copied over so the passed-in pointer can be invalidated by the sketch at any time.

35.7.4 Reading Characteristic Data

The BLE client (PC, phone, etc.) can write data to characteristics (if permissions allow) and the sketch can read those values and do things with them (i.e. set a thermostat, light an LED, etc.). Use the appropriate `BLECharacteristic::get<type>` call.

```

bool getBool()
char getChar()
uint8_t getInt8()
unsigned char getUChar()
uint8_t getUInt8()
short getShort()
int16_t getInt16()
unsigned short getUShort()
uint16_t getUInt16()
int getInt()
int32_t getInt32()
unsigned int getUInt()
uint32_t getUInt32()
long getLong()
unsigned long getULong()
long long getLongLong()
int64_t getInt64()
unsigned long long getULongLong()
uint64_t getUInt64()
float getFloat()
float getDouble()
String getString()
    
```

If you need the raw binary data use the following calls

```
const void * valueData()
size_t valueLen()
```

35.7.5 Getting Callbacks for Characteristics

Your sketch can get a callback to a function or class object whenever the remote devices reads or writes a characteristic (i.e. you could configure a callback whenever the home hub writes a new temperature setting to your device instead of polling `characteristic->getFloat()`).

To register a read or write callback (which will be executed at interrupt level so don't do things like filesystem access or flash writes) use

```
void myLEDReadCB(BLECharacteristic *c) {
    Serial.println("Yay, someone read me!");
}

void myLEDWriteCB(BLECharacteristic *c) {
    // Control the LED, immediately
    digitalWrite(LED_BUILTIN, c->getBool());
}

void setup() {
    BLE.begin("LEDMASTER");
    ... set up service
    auto s = new BLEService(BLEUUID(MYCUSTOMSVC));
    auto c = new BLECharacteristic(BLEUUID(MYCUSTOMUUID), BLEWrite | BLERead, "Lightbulb_
    ↪Control");
    c->onRead(myLEDReadCB);
    c->onWrite(myLEDWriteCB);
    s->addCharacteristic(c);
    BLE.startAdvertising();
}

void loop() {
    // Nothing here, the LED will be controlled thru the callback!
}
```

For a class-based callback demonstration, see the `BLEServiceUART.cpp` source file.

35.8 Implementing a BLE Client (BLE Central)

A BLE client scans the available device and then connects to one that offers the service it needs. When it connects it then gets a full list of zero or more remote services. For each of those remote services it then gets a full list of remote characteristics it can use to interact with the device.

Once a list of available servers is collected via `BLE.scan()` as explained above, the Pico chooses one to connect to with a call to

35.8.1 BLEClient()

`bool BLE.client()->connect(BLEAdvertising a, int timeoutsecs = 10)`

Attempts to connect to a remote BLE server and perform the scans described above. If the connection doesn't complete within the timeout, it will fail and return `false`. Note that further BLE operations to that server will use a different

timeout (default 2 seconds) which can be changed via `BLE.client()->setTimeout(int timeoutsecs)`

Accessing Remote Services

After successful connections, it is possible to examine the list of remote services or choose any specific one (most common)

BLERemoteService *BLE.client()->service(BLEUUID)

Returns either *nullptr* if no service exists, or `BLERemoteService` that can be used to find characteristics the sketch cares about. Don't delete this object, it is managed completely by the BLE object.

35.8.2 Accessing Remote Characteristics

Remote characteristics can be read, written, or registered for notification (remote permissions allowing it, of course). All remote characteristics are wrapped in `BLERemoteCharacteristic` objects.

There is no built-in caching, so every read of a remote characteristic goes over the BLE radio and can take some time. Your sketch should cache any values it needs to use repeatedly.

35.8.3 Remote Characteristic Permissions

The BLE server defines the permissions the Pico is given for each of the remote characteristics it provides.

```
bool BLERemoteCharacteristic::canRead()
bool BLERemoteCharacteristic::canWrite()
bool BLERemoteCharacteristic::canNotify()
```

String BLERemoteCharacteristic::description()

Returns the human readable text description associated with the remote characteristic, if the remote server supplies one. This is the equivalent of the `descriptino` parameter in the `BLECharacteristic` constructor.

35.8.4 Reading Remote Characteristics

The same `getXXX` calls as defined for `BLECharacteristic` (local characteristic) work for `BLERemoteCharacteristic`. They may be somewhat slower due to the need to poll the remote server for the data.

35.8.5 Writing Remote Characteristics

The same `setXXX` calls as defined for `BLECharacteristic` work for `BLERemoteCharacteristic` except, of course, that they send the new data to the remote device.

35.8.6 Getting Callbacks for Remote Characteristics

Your sketch can receive notifications when the remote server writes to a characteristic, assuming the remote server gives permission. That avoids having to read a remote characteristic over and over (using up radio time and power) to check for changes.

Both class and functional callbacks are available. Class-based works the same as for `BLECharacteristics`.

BLERemoteCharacteristic::onNotify(void (*notifyCB)(BLERemoteCharacteristic *c, const uint8_t *data, uint32_t len))

Registers a callback that will be called at interrupt level when a BLE notify message is received for the remote characteristic. Your callback will need to cast the returned data pointer to the appropriate format (i.e. a `bool` or a `char[]`).

35.9 BLE Beacons

BLE beacons are devices which just advertise their presence (infrequently, to save power) and provide no services or characteristics. All information about them (their UUID and their major and minor ID numbers) are contained in the advertisement.

The `BLEBeacon` class implements this functionality. Note that no `BLE..service()` calls should be used in this mode, just `BLEBeacon::begin()` (after setting the UUID and major/minor IDs. See the `Beacon.ino` example for usage

35.10 BLE Battery Service

The Bluetooth SIG standard BLE Battery service is implemented in `BLEServiceBattery`. Instantiate an instance of this object and `BLE.server()->addService()` it to gain this functionality.

Call `BLEBatteryService::set(int lvl /* 0-100 */)` from your main sketch as the battery state changes. All other work is handled behind-the-scenes.

This service can be added alongside other services, of course.

35.11 BLE Serial UART (Nordic SPP Service)

While not a Bluetooth SIG standard, the BLE “UART” service created by Nordic for their chipsets is very commonly used for low-power, low-volume data transmission over BLE. The `BLEServiceUART` class implements this “standard” as a `arduino::HardwareSerial` object (like `Serial` or `Serial1/2` or `SoftwareSerial`). This service can be combined with others, as always. It implements an automatic data flush mechanism, or the user can `flush()` as appropriate for their protocol.

See the `SerialBLE.ino` example for usage.

SINGLEFILEDRIVE

USB drive mode is supported through the `SingleFileDrive` class which allows the Pico to emulate a FAT-formatted USB stick while preserving the onboard LittleFS filesystem. A single file can be exported this way without needing to use FAT as the onboard filesystem (FAT is not appropriate for flash-based devices without complicated wear leveling because of the update frequency of the FAT tables).

This emulation is very simple and only allows for the reading of the single file, and deleting it.

36.1 Callbacks, Interrupt Safety, and File Operations

The `SingleFileDrive` library allows your application to get a callback when a PC attempts to mount or unmount the Pico as a drive. Your app can also get a callback if the user attempts to delete the file (but your sketch does not actually need to delete the file, it's up to you).

Note that when the USB drive is mounted by a PC it is not safe for your main sketch to make changes to the LittleFS filesystem or the file being exported. So, normally, your `onPlug` callback will set a flag letting your application know not to touch the filesystem, with the `onUnplug` callback clearing this flag.

Also, because the USB port can be connected at any time, it is important to disable interrupts using `noInterrupts()` before writing to a file you will be exporting (and restoring them with `interrupts()` afterwards). It is also important to `close()` the file after each update, or the on-flash version the `SingleFileDrive` will attempt to export may not be up to date causing issues later on.

See the included `DataLoggerUSB` sketch for an example of working with these limitations.

36.2 Using SingleFileDrive

Implementing the drive requires including the header file, starting LittleFS, defining your callbacks, and telling the library what file to export. No polling or other calls are required outside of your `setup()`. (Note that the callback routines allow for a parameter to be passed to them, but in most cases this can be safely ignored.)

```
#include <LittleFS.h>
#include <SingleFileDrive.h>

void myPlugCB(uint32_t data) {
    // Tell my app not to write to flash, we're connected
}

void myUnplugCB(uint32_t data) {
    // I can start writing to flash again
}
```

(continues on next page)

(continued from previous page)

```
void myDeleteDB(uint32_t data) {
    // Maybe LittleFS.remove("myfile.txt"? or do nothing
}

void setup() {
    LittleFS.begin();
    singleFileDrive.onPlug(myPlugCB);
    singleFileDrive.onUnplug(myUnplugCB);
    singleFileDrive.onDelete(myDeleteCB);
    singleFileDrive.begin("littlefsfile.csv", "Data Recorder.csv");
    // ... rest of setup ...
}

void loop() {
    // Take some measurements, delay, etc.
    if (okay-to-write) {
        noInterrupts();
        File f = LittleFS.open("littlefsfile.csv", "a");
        f.printf("%d,%d,%d\n", data1, data2, data3);
        f.close();
        interrupts();
    }
}
```

FATFSUSB

When the onboard flash memory is used as a `FatFS` filesystem, the `FatFSUSB` can be used to allow exporting it to a PC as a standard memory stick. The PC can then access, add, and remove files as if the Pico was a USB memory stick, and upon ejection the Pico can access any new files just as if it made them itself.

(Note, if you are using `LittleFS` then you need to use `SingleFileDrive` to export a single file, not this class, because the PC does not understand the `LittleFS` disk format.)

37.1 Callbacks, Interrupt Safety, and File Operations

The `FatFSUSB` library allows your application to get a callback when a PC attempts to mount or unmount the Pico as a FAT drive.

When the drive is being used by the Pico (i.e. any `File` is open for read or write, the `FatFS` is not `end()` -ed and still mounted, etc.) the host may not access it. Conversely, while the host PC is connected to the drive no `FatFS` access by the Pico is allowed.

Your `driveReady` callback will be called when the PC attempts to mount the drive. If you have any files open, then this callback can report back that the drive is not yet ready. When you complete file processing, the PC can re-attempt to mount the drive and your callback can return `true`.

The `onPlug` callback will generally `FatFS.end()` and set a global flag letting your application know not to touch the filesystem until the flag is cleared by the `onUnplug` callback (which will also do a `FatFS.begin()` call).

Failing to close all files **and** `FatFS.end()` before granting the PC access to flash memory will result in corruption. FAT does not allow multiple writers to access the same drive. Even mounting and only reading files from the PC may cause hidden writes (things like access time, etc.) which would also cause corruption.

See the included `Listfiles-USB` sketch for an example of working with these limitations.

FREERTOS SMP

The SMP (multicore) port of FreeRTOS is included with the core. This allows complex task operations and real preemptive multithreading in your sketches. While the `setup1` and `loop1` way of multitasking is simplest for most folks, FreeRTOS is much more powerful.

38.1 Enabling FreeRTOS

To enable FreeRTOS, simply add

```
#include <FreeRTOS.h>
```

to your sketch and select Tools->Operating System->FreeRTOS SMP to enable it.

When using Platform.IO you need to add the following define to your .ini file:

```
; Enable FreeRTOS Support  
build_flags = -DPIO_FRAMEWORK_ARDUINO_ENABLE_FREERTOS
```

38.2 Configuration and Predefined Tasks

FreeRTOS is configured with 8 priority levels (0 through 7) and a process for `setup()`/`loop()`, `setup1()`/`loop1()`, LWIP, and the USB port will be created. The task quantum is 1 millisecond (i.e. 1,000 switches per second).

`setup()` and `loop()` are assigned to only run on core 0, while `setup1()` and `loop1()` only run in core 1 in this mode, the same as the default multithreading mode.

There is an LWIP worker thread running on core 0 at priority (`configMAX_PRIORITIES - 2`) This should allow for LWIP to always make progress even with applications that don't yield or delay, while leaving the highest priority available for hard real time processes. This setting can be changed by defining `LWIP_TASK_PRIORITY` in your build process.

You can launch and manage additional processes using the standard FreeRTOS routines.

`delay()` and `yield()` free the CPU for other tasks, while `delayMicroseconds()` does not.

38.3 Caveats

While the core now supports FreeRTOS, most (probably all) Arduino libraries were not written to support preemptive multithreading. This means that all calls to a particular library should be made from a single task.

In particular, the `LittleFS` and `SDFS` libraries can not be called from different threads. Do all File operations from a single thread or else undefined behavior (aka strange crashes or data corruption) can occur.

38.4 More Information

For full FreeRTOS documentation look at [FreeRTOS.org](https://www.freertos.org) and [FreeRTOS SMP support](#).

WIFI (RASPBERRY PI PICO W) SUPPORT

WiFi is supported on the Raspberry Pi Pico W by selecting the “Raspberry Pi Pico W” board in the Boards Manager. It is generally compatible with the [Arduino WiFi library](#) and the [ESP8266 Arduino WiFi library](#).

Enable WiFi support by selecting the *Raspberry Pi Pico W* board in the IDE and adding `#include <WiFi.h>` in your sketch.

39.1 Non-Raspberry Pi WiFi Support

In addition to the official WiFi chip from Raspberry Pi, this core supports additional WiFi interface devices:

- Microchip WINC1500
- ESP32-based devices using [ESPHost](#)

See the examples in the respective library folders for instructions on instantiating and using these devices. Most of the features documented here will also work on these WiFi chips.

39.2 Supported Features

- WiFi connection (Open, WPA/WPA2)
 - Static IP or dynamic DHCP supported
 - Station Mode (STA, connects to an existing network)
 - Access Point Mode (AP, creates its own wireless network) with 4 clients
- WiFi Scanning and Reporting
 - See the `ScanNetworks.ino` example to better understand the process.

39.3 Important Information

- Adding WiFi increases flash usage by over 220KB
 - There is a 220KB binary firmware blob for the WiFi chip (CYW43-series) which the Pico W uses, even to control the onboard LED.
- Adding WiFi increases RAM usage by ~40KB.
 - LWIP, the TCP/IP driver, requires preallocated buffers to allow it to run in non-polling mode (i.e. packets can be sent and received in the background without the application needing to explicitly do anything).
- The WiFi driver has some limitations stemming from the upstream SDK:
 - Extensible Authentication Protocol (EAP) is not supported

- Combined STA/AP mode is not supported
- Multicore is supported, but only core 0 may run WiFi related code when in bare metal. When using FreeRTOS, any Task on any core can perform networking operations.

The WiFi library borrows much work from the [ESP8266 Arduino Core](#) , especially the `WiFiClient` and `WiFiServer` classes.

39.4 Special Thanks

Special thanks to:

- @todbot for donating one of his Pico W boards to the effort
- @d-a-v for much patient explanation about LWIP internals
- The whole ESP8266 Arduino team for their network classes
- Adafruit Industries for their kind donation

ETHERNETLWIP (WIRED ETHERNET) SUPPORT

Wired Ethernet interfaces are supported for all the internal networking libraries (`WiFiClient`, `WiFiClientSecure`, `WiFiServer`, `WiFiServerSecure`, `WiFiUDP`, `WebServer`, `Updater`, `HTTPClient`, etc.).

Using these wired interfaces is very similar to using the Pico-W WiFi so most examples in the core only require minor modifications to use a wired interface.

40.1 Supported Wired Ethernet Modules

- Wiznet W5100(s)
- Wiznet W5500
- Wiznet W55RP20
- Wiznet W6100
- Wiznet W6300
- ENC28J60
- USB (see *Ethernet over USB*)

40.2 Enabling Wired Ethernet

Simply replace the WiFi include at the top with:

```
#include <W5500lwIP.h> // Or W5100lwIP.h or ENC28J60.h
```

And add a global Ethernet object of the same type:

```
Wiznet5500lwIP eth(1); // Parameter is the Chip Select pin
```

In your `setup()` you may adjust the SPI pins you're using to match your hardware (be sure they are legal for the RP2040!), or skip this if you're using the default ones:

```
void setup() {  
  SPI.setRX(0);  
  SPI.setCS(1);  
  SPI.setSCK(2);  
  SPI.setTX(3);  
  ....  
}
```

And finally replace the `WiFi.begin()` and `WiFi.connected()` calls with `eth.begin()` and `eth.connected()`:

```
void setup() {
  ....
  // WiFi.begin(SSID, PASS)
  eth.begin();

  //while (!WiFi.connected()) {
  while (!eth.connected()) {
    Serial.print(".");
  }

  Serial.print("IP address: ");
  //Serial.println(WiFi.localIP());
  Serial.println(eth.localIP());

  ....
}
```

40.3 Adjusting LWIP Polling

LWIP operates in a polling mode for the wired Ethernet devices. By default it will run every 20ms, meaning that on average it will take half that time (10ms) before a packet received in the Ethernet module is received and operated upon by the Pico. This gives very low CPU utilization but in some cases this latency can affect performance.

Adding a call to `lwipPollingPeriod(XXX)` (where XXXX is the polling period in milliseconds) can adjust this setting on the fly. Note that if you set it too low, the Pico may not have enough time to service the Ethernet port before the timer fires again, leading to a lock up and hang.

40.4 Using Interrupt-Driven Handling

The WizNet and ENC28J60 devices support generating an interrupt when a packet is received, removing the need for polling and decreasing latency. Simply specify the SPI object to use and the interrupt pin when instantiating the Ethernet object:

```
#include <W5100lwIP.h>
Wiznet5100lwIP eth(SS /* Chip Select*/, SPI /* SPI interface */, 17 /* Interrupt GPIO */);
```

40.5 Adjusting SPI Speed

By default a 4MHz clock will be used to clock data into and out of the Ethernet module. Depending on the module and your wiring, a higher SPI clock may increase performance (but too high of a clock will cause communications problems or hangs).

This value may be adjusted using the `eth.setSPISpeed(hz)` call **before** starting the device. (You may also use custom SPI settings instead via `eth.setSPISettings(spis)``)

For example, to set the W5500 to use a 30MHZ clock:

```
#include <W5500lwIP.h>
Wiznet5500lwIP eth(1);

void setup() {
```

(continues on next page)

(continued from previous page)

```
eth.setSPISpeed(30000000);
lwipPollingPeriod(3);
...
eth.begin();
...
}
```

40.6 Using the WIZnet W5100S-EVB-Pico

You can use the onboard Ethernet chip with these drivers, in interrupt mode, by utilizing the following options:

```
#include <W5100lwIP.h>
Wiznet5100lwIP eth(17, SPI, 21); // Note chip select is **17**

void setup() {
  // Set SPI to the onboard Wiznet chip
  SPI.setRX(16);
  SPI.setCS(17);
  SPI.setSCK(18);
  SPI.setTX(19);
  ...
  eth.begin();
  ...
}
```

40.7 Example Code

The following examples allow switching between WiFi and Ethernet:

- WebServer/AdvancedWebServer
- HTTPClient/BasicHTTPClient

40.8 Caveats

The same restrictions for WiFi apply to these Ethernet classes, namely:

- Only core 0 may run any networking related code.
- In FreeRTOS, only the setup and loop task can call networking libraries, not any tasks.

40.9 Special Thanks

- LWIPEthernet classes come from the ESP8266 Arduino team
- Some individual Ethernet drivers were written by Nicholas Humfrey, others submitted by users.

ETHERNET OVER USB

A USB connection with a PC or Smartphone can be used as a wired network connection. It requires no additional hardware. Other USB functions like Serial, Keyboard, Mouse or Joystick can be used at the same time. Both IPv4 and IPv6 are supported.

The protocol is called Network Control Model (NCM) and is the newest of three possible protocols defined by the USB standard. NCM is natively supported by Windows, Linux, macOS, Android, ChromeOS, iOS and more.

To use it, both the Raspberry Pi Pico and the USB Host need to be configured.

41.1 USB Device configuration on Raspberry Pi Pico

Add this to your sketch:

```
#include <NCMEthernetlwIP.h>
```

And add a global Ethernet object of the same type:

```
NCMEthernetlwIP eth;
```

In your `setup()`, add this:

```
void setup() {  
  eth.begin();  
  ....  
}
```

You can use `eth.connected()` to check the state of the connection.

```
void setup() {  
  ....  
  eth.begin();  
  
  while (!eth.connected()) {  
    Serial.print(".");  
  }  
  
  Serial.print("IP address: ");  
  Serial.println(eth.localIP());  
  
  ....  
}
```

The Raspberry Pi Pico will try to get an IP Address via DHCP and stateless DHCPv6. Alternatively, static addresses may be set:

```
IPAddress my_static_ip_addr(192, 168, 137, 100);
IPAddress my_static_gateway(192, 168, 137, 1);
IPAddress my_static_dns(192, 168, 137, 1);

void setup() {
    ....
    eth.config(my_static_ip_addr, my_static_gateway, IPAddress(255, 255, 255, 0), my_
↪static_dns);
    eth.begin();
    ....
}
```

See also the examples:

- `lwIP_USB_NCM/WiFiClient-NCMEthernet`
- `lwIP_USB_NCM/WiFiClient-NCMEthernet-platformio`

41.2 USB Host configuration on Windows

The Raspberry Pi Pico will appear as a USB to Ethernet adapter, creating an additional network interface on the host. It must be configured to allow a successful network connection.

On Windows we must use [Internet Connection Sharing](#). It provides DHCP on the 192.168.137.0/24 subnet and routing to the rest of the network using network address translation.

1. Win + R, then type `ncpa.cpl`
2. Connect Raspberry Pi Pico with a NCM-enabled sketch
3. A new network connection should appear
4. Right click your **normal** network connection, select *Properties*.
5. Select the *Sharing* Tab
6. Check the box for *Allow other network users to connect through this computer's Internet connection*
7. As *Home networking connection*, choose the **new** network connection that appeared in Step 3.

The Pico may get any address in 192.168.137.0/24. Either print it on a serial terminal or use a static IP address. It will respond to pings if everything is setup correctly.

41.3 USB Host configuration on Linux

The Raspberry Pi Pico will appear as a USB to Ethernet adapter, creating an additional network interface on the host. It must be configured to allow a successful network connection. Network configuration on Linux depends on your network management software. If you don't know which one you are running, try these commands:

- `sudo systemctl status NetworkManager`
- `sudo systemctl status systemd-networkd`
- `sudo systemctl status dhcpcd`

One of them will be active (running).

41.3.1 NetworkManager

1. Prepare your Raspberry Pi Pico with a NCM-enabled sketch and configure it with DHCP or a static ip address.
2. `ip link` to check your existing network interfaces
3. Connect the Raspberry Pi Pico
4. `ip link` again, a new network interface should be listed. This example assumes `usb0`
5. `nmcli connection add type ethernet ifname usb0 con-name pico ipv4.method shared ipv4.address 192.168.142.1/24`
6. `sudo iptables -A FORWARD -i usb0 -j ACCEPT`
7. `sudo iptables -A FORWARD -o usb0 -j ACCEPT`
8. `pyserial-miniterm /dev/ttyACM0`. Check the IP address it reports. Check for successful requests. Alternatives to `pyserial-miniterm` are `picocom` or `minicom`.
9. `ping <ip address from previous step>`
10. make iptables rules persistent by adding them to the files in `/etc/iptables/*.rules`

41.3.2 dhcpd

`dhcpd` cannot act as a DHCP server, so we must use static ip addresses.

1. Prepare your Raspberry Pi Pico with a NCM-enabled sketch and configure it with static ip address `192.168.137.100` and gateway `192.168.137.1`.
2. `ip link` to check your existing network interfaces
3. Connect the Raspberry Pi Pico
4. `ip link` again, a new network interface should be listed. This example assumes `usb0`
5. add the following to `/etc/dhcpd.conf`:

```
interface usb0
static ip_address=192.168.137.1/24
```

6. `systemctl restart dhcpd`
7. `ping 192.168.137.100`
8. `sudo sysctl -w net.ipv4.conf.all.forwarding=1`
9. `sudo iptables -A FORWARD -i usb0 -j ACCEPT`
10. `sudo iptables -A FORWARD -o usb0 -j ACCEPT`
11. `pyserial-miniterm /dev/ttyACM0`. Check for successful requests. Alternatives to `pyserial-miniterm` are `picocom` or `minicom`.
12. make iptables rules persistent by adding them to the files in `/etc/iptables/*.rules`

41.3.3 systemd-networkd

1. Prepare your Raspberry Pi Pico with a NCM-enabled sketch and configure it with DHCP or static ip address `192.168.137.100` and gateway `192.168.137.1`.
2. `ip link` to check your existing network interfaces
3. Connect the Raspberry Pi Pico

4. `ip link` again, a new network interface should be listed. This example assumes `usb0`
5. create `/etc/systemd/network/pico.network` with this content:

```
[Match]
Name=usb0

[Network]
Address=192.168.137.1/24

IPv4Forwarding=yes
IPMasquerade=yes
DHCP Server=yes

IPv6Forwarding=yes
IPv6SendRA=yes
DHCP PrefixDelegation=yes

[DHCP Server]
EmitDNS=yes
UplinkInterface=:auto

[IPv6SendRA]
EmitDNS=yes
UplinkInterface=:auto
```

6. `sudo iptables -A FORWARD -i usb0 -j ACCEPT`
7. `sudo iptables -A FORWARD -o usb0 -j ACCEPT`
8. `sudo systemctl restart systemd-networkd`
9. `pyserial-miniterm /dev/ttyACM0`. Check the IP address it reports. Check for successful requests. Alternatives to `pyserial-miniterm` are `picocom` or `minicom`.
10. `ping <ip address from previous step>`
11. make iptables rules persistent by adding them to the files in `/etc/iptables/*.rules`

41.3.4 Manual config

This config will not survive a Linux reboot, but may be ok for testing.

1. Prepare your Raspberry Pi Pico with a NCM-enabled sketch and configure it with static ip address `192.168.137.100` and gateway `192.168.137.1`.
2. `ip link` to check your existing network interfaces
3. Connect the Raspberry Pi Pico
4. `ip link` again, a new network interface should be listed. This example assumes `usb0`
5. You can also check `lsusb -t` and `dmesg`
6. `ip link set usb0 up`
7. `ip addr add 192.168.137.1/24 dev usb0`
8. `ping 192.168.137.100`

41.4 Special Thanks

- tinyUSB contributors for the NCM implementation
- NCMEthernetwIP driver written by functionpointer

Methods documented for `Client` in `Arduino`

1. `WiFiClient()`
2. `connected()`
3. `connect()`
4. `write()`
5. `print()`
6. `println()`
7. `available()`
8. `read()`
9. `flush()`
10. `stop()`

Methods and properties described further down are specific to ESP8266. They are not covered in `Arduino WiFi library` documentation. Before they are fully documented please refer to information below.

42.1 flush and stop

`flush(timeoutMs)` and `stop(timeoutMs)` both have now an optional argument: `timeout` in millisecond, and both return a boolean.

Default input value 0 means that effective value is left at the discretion of the implementer.

`flush()` returning `true` indicates that output data have effectively been sent, and `false` that a timeout has occurred.

`stop()` returns `false` in case of an issue when closing the client (for instance a timed-out `flush`). Depending on implementation, its parameter can be passed to `flush()`.

42.2 setNoDelay

`setNoDelay(nodelay)`

With `nodelay` set to `true`, this function will to disable `Nagle algorithm`.

This algorithm is intended to reduce TCP/IP traffic of small packets sent over the network by combining a number of small outgoing messages, and sending them all at once. The downside of such approach is effectively delaying individual messages until a big enough packet is assembled.

Example:

```
client.setNoDelay(true);
```

42.3 getNoDelay

Returns whether NoDelay is enabled or not for the current connection.

42.4 setSync

This is an experimental API that will set the client in synchronized mode. In this mode, every `write()` is flushed. It means that after a call to `write()`, data are ensured to be received where they went sent to (that is `flush` semantic).

When set to `true` in `WiFiClient` implementation,

- It slows down transfers, and implicitly disable the Nagle algorithm.
- It also allows to avoid a temporary copy of data that otherwise consumes at most `TCP_SND_BUF = (2 * MSS)` bytes per connection,

42.5 getSync

Returns whether Sync is enabled or not for the current connection.

42.6 setDefaultNoDelay and setDefaultSync

These set the default value for both `setSync` and `setNoDelay` for every future instance of `WiFiClient` (including those coming from `WiFiServer.available()` by default).

Default values are false for both NoDelay and Sync.

This means that Nagle is enabled by default *for all new connections*.

42.7 getDefaultNoDelay and getDefaultSync

Return the values to be used as default for NoDelay and Sync for all future connections.

42.8 Other Function Calls

```
uint8_t status ()
virtual size_t write (const uint8_t *buf, size_t size)
size_t write_P (PGM_P buf, size_t size)
size_t write (Stream &stream)
size_t write (Stream &stream, size_t unitSize) __attribute__((deprecated))
virtual int read (uint8_t *buf, size_t size)
virtual int peek ()
virtual size_t peekBytes (uint8_t *buffer, size_t length)
size_t peekBytes (char *buffer, size_t length)
virtual operator bool ()
IPAddress remoteIP ()
uint16_t remotePort ()
IPAddress localIP ()
uint16_t localPort ()
```

Documentation for the above functions is not yet available.

SERVER CLASS

Methods documented for the [Server Class in Arduino](#)

1. [WiFiServer\(\)](#)
2. [begin\(\)](#)
3. [available\(\)](#)
4. [write\(\)](#)
5. [print\(\)](#)
6. [println\(\)](#)

In [ESP8266WiFi](#) library the [ArduinoWiFiServer](#) class implements [available](#) and the write-to-all-clients functionality as described in the [Arduino WiFi](#) library reference. The [PageServer](#) example shows how [available](#) and the write-to-all-clients works.

For most use cases the basic [WiFiServer](#) class of the [ESP8266WiFi](#) library is suitable.

Methods and properties described further down are specific to [ESP8266](#). They are not covered in [Arduino WiFi](#) library documentation. Before they are fully documented please refer to information below.

43.1 [accept](#)

Method [accept\(\)](#) returns a waiting client connection. [accept\(\)](#) is documented for the [Arduino Ethernet](#) library.

43.2 [available](#)

see [accept](#)

[available](#) in the [ESP8266WiFi](#) library's [WiFiServer](#) class doesn't work as documented for the [Arduino WiFi](#) library. It works the same way as [accept](#).

43.3 [write \(write to all clients\) not supported](#)

Please note that the [write](#) method on the [WiFiServer](#) object is not implemented and returns failure always. Use the returned [WiFiClient](#) object from the [WiFiServer::accept\(\)](#) method to communicate with individual clients. If you need to send the exact same packets to a series of clients, your application must maintain a list of connected clients and iterate over them manually.

43.4 setNoDelay

```
setNoDelay(nodelay)
```

With `nodelay` set to `true`, this function will to disable [Nagle algorithm](#).

This algorithm is intended to reduce TCP/IP traffic of small packets sent over the network by combining a number of small outgoing messages, and sending them all at once. The downside of such approach is effectively delaying individual messages until a big enough packet is assembled.

Example:

```
server.begin();
server.setNoDelay(true);
```

By default, `nodelay` value will depends on `global WiFiClient::getDefaultNoDelay()` (currently false by default).

However, a call to `wiFiServer.setNoDelay()` will override `NoDelay` for all new `WiFiClient` provided by the calling instance (`wiFiServer`).

43.5 Other Function Calls

```
bool hasClient ()
size_t hasClientData ()
bool hasMaxPendingClients ()
bool getNoDelay ()
virtual size_t write (const uint8_t *buf, size_t size)
uint8_t status ()
void close ()
void stop ()
```

Documentation for the above functions is not yet prepared.

UDP CLASS

Methods documented for `WiFiUDP` Class in Arduino

1. `begin()`
2. `available()`
3. `beginPacket()`
4. `endPacket()`
5. `write()`
6. `parsePacket()`
7. `peek()`
8. `read()`
9. `flush()`
10. `stop()`
11. `remoteIP()`
12. `remotePort()`

NETWORK TIME PROTOCOL (NTP)

NTP allows the Pico to set its internal clock using the internet, and is required for secure connections because the certificates used have valid date stamps.

After `WiFi.begin()` use `NTP.begin(s1)` or `NTP.begin(s1, s2)` to use one or two NTP servers (common ones are `pool.ntp.org` and `time.nist.gov`).

```
WiFi.begin("ssid", "pass");  
NTP.begin("pool.ntp.org", "time.nist.gov");
```

Either names or `IPAddress` may be used to identify the NTP server to use.

It may take seconds to minutes for the system time to be updated by NTP, depending on the server. It is often useful to check that `time(NULL)` returns a sane value before continuing a sketch:

```
void setClock() {  
  NTP.begin("pool.ntp.org", "time.nist.gov");  
  
  Serial.print("Waiting for NTP time sync: ");  
  time_t now = time(nullptr);  
  while (now < 8 * 3600 * 2) {  
    delay(500);  
    Serial.print(".");  
    now = time(nullptr);  
  }  
  Serial.println("");  
  struct tm timeinfo;  
  gmtime_r(&now, &timeinfo);  
  Serial.print("Current time: ");  
  Serial.print(asctime(&timeinfo));  
}
```

45.1 `bool NTP.waitSet(uint32_t timeout)`

This call will wait up to `timeout` milliseconds for the time to be set, and returns success or failure. It will also begin NTP with a default “`pool.ntp.org`” server if it is not already running. Using this method, the above code becomes:

```
void setClock() {  
  NTP.begin("pool.ntp.org", "time.nist.gov");  
  NTP.waitSet();  
  time_t now = time(nullptr);  
  struct tm timeinfo;
```

(continues on next page)

(continued from previous page)

```
gmtime_r(&now, &timeinfo);
Serial.print("Current time: ");
Serial.print(asctime(&timeinfo));
}
```

45.2 bool NTP.waitSet(void (*cb)(), uint32_t timeout)

Allows for a callback that will be called every 1/10th of a second while waiting for NTP sync. For example, using lambdas you can simply print “.:s:”

```
void setClock() {
  NTP.begin("pool.ntp.org", "time.nist.gov");
  NTP.waitSet([]() { Serial.print("."); });
  time_t now = time(nullptr);
  struct tm timeinfo;
  gmtime_r(&now, &timeinfo);
  Serial.print("Current time: ");
  Serial.print(asctime(&timeinfo));
}
```

BEARSSL WIFI CLASSES

Methods and properties described in this section are specific to the Raspberry Pi Pico W and the ESP8266. They are not covered in [Arduino WiFi library](#) documentation. Before they are fully documented please refer to information below.

The [BearSSL](#) library (with modifications for ESP8266 compatibility and to use ROM tables whenever possible) is used to perform all cryptography and TLS operations. The main ported repo is available [on GitHub](#).

46.1 CPU Requirements

SSL operations take significant CPU cycles to run, so it will connect significantly slower than unprotected connections on the Pico, but the actual data transfer rates once connected are similar.

See the section on *sessions* and *limiting cryptographic negotiation* for ways of ensuring faster modes are used.

46.2 Memory Requirements

BearSSL doesn't perform memory allocations at runtime, but it does require allocation of memory at the beginning of a connection. There are two memory chunks required: . A per-application secondary stack . A per-connection TLS receive/transmit buffer plus overhead

The per-application secondary stack is approximately 7KB in size and is used for temporary variables during BearSSL processing. Only one stack is required, and it will be allocated whenever any *BearSSL::WiFiClientSecure* or *BearSSL::WiFiServerSecure* are instantiated. So, in the case of a global client or server, the memory will be allocated before *setup()* is called.

The per-connection buffers are approximately 22KB in size, but in certain circumstances it can be reduced dramatically by using MFLN or limiting message sizes. See the *MLFN section* below for more information.

46.3 Object Lifetimes

There are many configuration options that require passing in a pointer to an object (i.e. a pointer to a private key, or a certificate list). In order to preserve memory, BearSSL does NOT copy the objects passed in via these pointers and as such any pointer passed in to BearSSL needs to be preserved for the life of the client object. For example, the following code is **in error**:

```
BearSSL::WiFiClientSecure client;
const char x509CA PROGMEM = ".....";
void setup() {
    BearSSL::X509List x509(x509CA);
    client.setTrustAnchor(&x509);
}
```

(continues on next page)

(continued from previous page)

```
void loop() {
  client.connect("192.168.1.1", 443);
}
```

Because the pointer to the local object `x509` no longer is valid after `setup()`, expect to crash in the main `loop()` where it is accessed by the `client` object.

As a rule, either keep your objects global, use `new` to create them, or ensure that all objects needed live inside the same scope as the client.

46.4 TLS and HTTPS Basics

The following discussion is only intended to give a rough idea of TLS/HTTPS (which is just HTTP over a TLS connection) and the components an application needs to manage to make a TLS connection. For more detailed information, please check the relevant [RFC 5246](#) and others.

TLS can be broken into two stages: verifying the identities of server (and potentially client), and then encrypting blocks of data bidirectionally. Verifying the identity of the other partner is handled via keys encoded in X509 certificates, optionally signed by a series of other entities.

46.5 Public and Private Keys

Cryptographic keys are required for many of the BearSSL functions. Both public and private keys are supported, with either Elliptic Curve or RSA key support.

To generate a public or private key from an existing PEM (ASCII format) or DER (binary format), the simplest method is to use the constructor:

```
BearSSL::PublicKey(const char *pemString)
... or ...
BearSSL::PublicKey(const uint8_t *derArray, size_t derLen)
```

Note that *PROGMEM* strings and arrays are natively supported by these constructors and no special **_P* modes are required. There are additional functions to identify the key type and access the underlying BearSSL proprietary types, but they are not needed by user applications.

46.6 TLS Sessions

TLS supports the notion of a session (completely independent and different from HTTP sessions) which allow clients to reconnect to a server without having to renegotiate encryption settings or validate X509 certificates. This can save significant time (3-4 seconds in the case of EC keys) and can help save power by allowing the ESP8266 to sleep for a long time, reconnect and transmit some samples using the SSL session, and then jump back to sleep quicker.

`BearSSL::Session` is an opaque class. Use the `BearSSL::WiFiClientSecure.setSession(&BearSSLSession)` method to apply it before the first `BearSSL::WiFiClientSecure.connect()` and it will be updated with session parameters during the operation of the connection. After the connection has had `.close()` called on it, serialize the `BearSSL::Session` object to stable storage (EEPROM, RTC RAM, etc.) and restore it before trying to reconnect. See the `BearSSL_Sessions` example for a detailed example.

`Sessions` contains additional information on the sessions API.

46.7 X.509 Certificate(s)

X509 certificates are used to identify peers in TLS connections. Normally only the server identifies itself, but the client can also supply an X509 certificate if desired (this is often done in MQTT applications). The certificate contains many fields, but the most interesting in our applications are the name, the public key, and potentially a chain of signing that leads back to a trusted authority (like a global internet CA or a company-wide private certificate authority).

Any call that takes an X509 certificate can also take a list of X509 certificates, so there is no special *X509* class, simply *BearSSL::X509List* (which may only contain a single certificate).

Generating a certificate to be used to validate using the constructor

```
BearSSL::X509List(const char *pemX509);
...or...
BearSSL::X509List(const uint8_t *derCert, size_t derLen);
```

If you need to add additional certificates (unlikely in normal operation), the *::append()* operation can be used.

46.8 Certificate Stores

The web browser you're using to read this document keeps a list of 100s of certification authorities (CAs) worldwide that it trusts to attest to the identity of websites.

In many cases your application will know the specific CA it needs to validate web or MQTT servers against (often just a single, self-signing CA private to your institution). Simply load your private CA in a *BearSSL::X509List* and use that as your trust anchor.

However, there are cases where you will not know beforehand which CA you will need (i.e. a user enters a website through a keypad), and you need to keep the list of CAs just like your web browser. In those cases, you need to generate a certificate bundle on the PC while compiling your application, upload the *certs.ar* bundle to LittleFS or SD when uploading your application binary, and pass it to a *BearSSL::CertStore()* in order to validate TLS peers.

See the *BearSSL_CertStore* example for full details.

46.9 Supported Crypto

Please see the [BearSSL website](#) for detailed cryptographic information. In general, TLS 1.2, TLS 1.1, and TLS 1.0 are supported with RSA and Elliptic Curve keys and a very rich set of hashing and symmetric encryption codes. Please note that Elliptic Curve (EC) key operations take a significant amount of time.

WIFICLIENTSECURE CLASS

BearSSL::WiFiClientSecure is the object which actually handles TLS encrypted WiFi connections to a remote server or client. It extends *WiFiClient* and so can be used with minimal changes to code that does unsecured communications.

47.1 Validating X509 Certificates (Am I talking to the server I think I'm talking to?)

Prior to connecting to a server, the *BearSSL::WiFiClientSecure* needs to be told how to verify the identity of the other machine. **By default BearSSL will not validate any connections and will refuse to connect to any server.**

There are multiple modes to tell BearSSL how to verify the identity of the remote server. See the *BearSSL_Validation* example for real uses of the following methods:

47.1.1 `setInsecure()`

Don't verify any X509 certificates. There is no guarantee that the server connected to is the one you think it is in this case.

47.1.2 `setKnownKey(const BearSSL::PublicKey *pk)`

Assume the server is using the specific public key. This does not verify the identity of the server or the X509 certificate it sends, it simply assumes that its public key is the one given. If the server updates its public key at a later point then connections will fail.

47.1.3 `setFingerprint(const uint8_t fp[20]) / setFingerprint(const char *fpStr)`

Verify the SHA1 fingerprint of the certificate returned matches this one. If the server certificate changes, it will fail. If an array of 20 bytes are sent in, it is assumed they are the binary SHA1 values. If a *char** string is passed in, it is parsed as a series of human-readable hex values separated by spaces or colons (e.g. *setFingerprint("00:01:02:03:...:1f");*)

This fingerprint is calculated on the raw X509 certificate served by the server. In very rare cases, these certificates have certain encodings which should be normalized before taking a fingerprint (but in order to preserve memory BearSSL does not do this normalization since it would need RAM for an entire copy of the cert), and the fingerprint BearSSL calculates will not match the fingerprint OpenSSL calculates. In this case, you can enable SSL debugging and get a dump of BearSSL's calculated fingerprint and use that one in your code, or use full certificate validation. See the [original issue and debug here](#).

47.1.4 `setTrustAnchors(BearSSL::X509List *ta)`

Use the passed-in certificate(s) as a trust anchor, accepting remote certificates signed by any of these. If you have many trust anchors it may make sense to use a *BearSSL::CertStore* because it will only require RAM for a single trust anchor (while the *setTrustAnchors* call requires memory for all certificates in the list).

47.1.5 setX509Time(time_t now)

For *setTrustAnchors* and *CertStore*, the current time (set via SNTP) is used to verify the certificate against the list, so SNTP must be enabled and functioning before the connection is attempted. If you cannot use SNTP for some reason, you can manually set the “present time” that BearSSL will use to validate a certificate with this call where *now* is standard UNIX time.

47.2 Client Certificates (Proving I’m who I say I am to the server)

TLS servers can request that a client identify themselves with an X509 certificate signed by a trust anchor it honors (i.e. a global TA or a private CA). This is commonly done for applications like MQTT. By default the client doesn’t send a certificate, and in cases where a certificate is required the server will disconnect and no connection will be possible.

47.2.1 setClientRSACert / setClientECCert

Sets a client certificate to send to a TLS server that requests one. It should be called before *connect()* to add a certificate to the client in case the server requests it. Note that certificates include both a certificate and a private key. Both should be provided to you by your certificate generator. Elliptic Curve (EC) keys require additional information, as shown in the prototype.

47.3 MFLN or Maximum Fragment Length Negotiation (Saving RAM)

Because TLS was developed on systems with many megabytes of memory, they require by default a 16KB buffer for receive and transmit. That’s enormous for the ESP8266, which has only around 40KB total heap available.

We can (and do) minimize the transmission buffer down to slightly more than 512 bytes to save memory, since BearSSL can internally ensure transmissions larger than that are broken up into smaller chunks that do fit. But that still leaves the 16KB receive buffer requirement since we cannot in general guarantee the TLS peer will send in smaller chunks.

TLS 1.2 added MFLN, which lets a client negotiate smaller buffers with a server and reduce the memory requirements on the ESP8266. Unfortunately, BearSSL needs to know the buffer sizes before it begins connection, so applications that want to use smaller buffers need to check the remote server’s support before *connect()*.

47.3.1 probeMaxFragmentLength(host, port, len)

Use one of these calls **before** connection to determine if a specific fragment length is supported (len must be a power of two from 512 to 4096, per the specification). This does **not** initiate a SSL connection, it simply opens a TCP port and performs a trial handshake to check support.

47.3.2 setBufferSizes(int recv, int xmit)

Once you have verified (or know beforehand) that MFLN is supported you can use this call to set the size of memory buffers allocated by the connection object. This must be called **before** *connect()* or it will be ignored.

In certain applications where the TLS server does not support MFLN (not many do as of this writing as it is relatively new to OpenSSL), but you control both the ESP8266 and the server to which it is communicating, you may still be able to *setBufferSizes()* smaller if you guarantee no chunk of data will overflow those buffers.

47.3.3 bool getMFLNStatus()

After a successful connection, this method returns whether or not MFLN negotiation succeeded or not. If it did not succeed, and you reduced the receive buffer with *setBufferSizes* then you may experience reception errors if the server attempts to send messages larger than your receive buffer.

47.4 Sessions (Resuming connections fast)

47.4.1 `setSession(BearSSL::Session &sess)`

If you are connecting to a server repeatedly in a fixed time period (usually 30 or 60 minutes, but normally configurable at the server), a TLS session can be used to cache crypto settings and speed up connections significantly.

47.5 Errors

BearSSL can fail in many more unique and interesting ways. Use these calls to get more information when something fails.

47.5.1 `getLastSSLError(char *dest = NULL, size_t len = 0)`

Returns the last BearSSL error code encountered and optionally set a user-allocated buffer to a human-readable form of the error. To only get the last error integer code, just call without any parameters (*int errorCode = getLastSSLError();*).

47.6 Limiting Ciphers (New connections faster)

There is very rarely reason to use these calls, but they are available.

47.6.1 `setCiphers()`

Takes an array (in PROGMEM is valid) or a `std::vector` of 16-bit BearSSL cipher identifiers and restricts BearSSL to only use them. If the server requires a different cipher, then connection will fail. Generally this is not useful except in cases where you want to connect to servers using a specific cipher. See the BearSSL headers for more information on the supported ciphers.

47.6.2 `setCiphersLessSecure()`

Helper function which essentially limits BearSSL to less secure ciphers than it would natively choose, but they may be helpful and faster if your server depended on specific crypto options.

47.7 Limiting TLS(SSL) Versions

By default, BearSSL will connect with TLS 1.0, TLS 1.1, or TLS 1.2 protocols (depending on the request of the remote side). If you want to limit to a subset, use the following call:

47.8 `setTLSConnectTimeout(int connectTimeout)`

Because the Pico doesn't have any cryptographic acceleration, TLS connections can take up to 10 or 15 seconds to complete whereas the default *Stream* and *WiFiClient* timeout is only 5 seconds. To allow for this large difference, the timeout used for a *WiFiClientSecure::connect()* call is different from that used for a normal read or write (or normal *WiFiClient::connect()* call).

By default, the connection phase of a TLS *WiFiClientSecure::connect()* is set to 15 seconds (all other read/writes use the value set with *setTimeout()*). If your application needs to reduce this connection timeout, simply call:

```
WiFiClientSecure::setTLSConnectTimeout(5000); // Value is in milliseconds
```

This setting is global for all TLS connections.

47.8.1 setSSLVersion(uint32_t min, uint32_t max)

Valid values for min and max are *BR_TLS10*, *BR_TLS11*, *BR_TLS12*. Min and max may be set to the same value if only a single TLS version is desired.

47.9 ESP32 Compatibility

Simple ESP32 WiFiClientSecure compatibility is built-in, allow for some sketches to run without any modification. The following methods are implemented:

```
void setCACert(const char *rootCA);
void setCertificate(const char *client_ca);
void setPrivateKey(const char *private_key);
bool loadCACert(Stream& stream, size_t size);
bool loadCertificate(Stream& stream, size_t size);
bool loadPrivateKey(Stream& stream, size_t size);
int connect(IPAddress ip, uint16_t port, int32_t timeout);
int connect(const char *host, uint16_t port, int32_t timeout);
int connect(IPAddress ip, uint16_t port, const char *rootCABuff, const char *cli_cert,
↳const char *cli_key);
int connect(const char *host, uint16_t port, const char *rootCABuff, const char *cli_
↳cert, const char *cli_key);
```

Note that the SSL backend is very different between Arduino-Pico and ESP32-Arduino (BearSSL vs. mbedTLS). This means that, for instance, the SSL connection will check valid dates of certificates (and hence require system time to be set on the Pico, which is automatically done in this case).

TLS-Pre Shared Keys (PSK) is not supported by BearSSL, and hence not implemented here. Neither is ALPN.

For more advanced control, it is recommended to port to the native Pico calls which allows much more flexibility and control.

WIFISERVERSECURE CLASS

Implements a TLS encrypted server with optional client certificate validation. See [Server Class](#) for general information and [BearSSL Secure Client Class](#) for basic server and BearSSL concepts.

48.1 `setBufferSizes(int recv, int xmit)`

Similar to the `BearSSL::WiFiClientSecure` method, sets the receive and transmit buffer sizes. Note that servers cannot request a buffer size from the client, so if these are shrunk and the client tries to send a chunk larger than the receive buffer, it will always fail. Needs to be called before `begin()`

48.2 Setting Server Certificates

TLS servers require a certificate identifying itself and containing its public key, and a private key they will use to encrypt information with. The application author is responsible for generating this certificate and key, either using a self-signed generator or using a commercial certification authority. **Do not reuse the certificates included in the examples provided.**

This example command will generate a RSA 2048-bit key and certificate:

```
openssl req -x509 -nodes -newkey rsa:2048 -keyout key.pem -out cert.pem -days 4096
```

Again, it is up to the application author to generate this certificate and key and keep the private key safe and **private**.

48.2.1 `setRSACert(const BearSSL::X509List *chain, const BearSSL::PrivateKey *sk)`

Sets a RSA certificate and key to be used by the server when connections are received. Needs to be called before `begin()`

48.2.2 `setECCert(const BearSSL::X509List *chain, unsigned cert_issuer_key_type, const BearSSL::PrivateKey *sk)`

Sets an elliptic curve certificate and key for the server. Needs to be called before `begin()`.

48.3 Client sessions (Resuming connections fast)

The TLS handshake process takes a long time because of all the back and forth between the client and the server. You can shorten it by caching the clients' sessions which will skip a few steps in the TLS handshake. In order for this to work, your client also needs to cache the session. `BearSSL::WiFiClientSecure` can do that as well as modern web browsers.

Here are the kind of performance improvements that you'll be able to see for TLS handshakes with an ESP8266 with its clock set at 160MHz on a network with fairly low latency:

- With an EC key of 256 bits, a request taking ~360ms without caching takes ~60ms with caching.
- With an RSA key of 2048 bits, a request taking ~1850ms without caching takes ~70ms with caching.

48.3.1 `setCache(BearSSL::ServerSessions *cache)`

Sets the cache for the server's sessions. When choosing the size of the cache, remember that each client session takes 100 bytes. If you setup a cache for 10 sessions, it will take 1000 bytes. Needs to be called before *begin()*

When creating the cache, you can use any of the 2 available constructors:

- `BearSSL::ServerSessions(ServerSession *sessions, uint32_t size)`: Creates a cache with the given buffer and number of sessions.
- `BearSSL::ServerSessions(uint32_t size)`: Dynamically allocates a cache for the given number of sessions.

48.4 Requiring Client Certificates

TLS servers can request the client to identify itself by transmitting a certificate during handshake. If the client cannot transmit the certificate, the connection will be dropped by the server.

48.4.1 `setClientTrustAnchor(const BearSSL::X509List *client_CA_ta)`

Sets the trust anchor (normally a self-signing CA) that all received certificates will be verified against. Needs to be called before *begin()*.

HTTPCLIENT LIBRARY

A simple HTTP requester that can handle both HTTP and HTTPS requests is included as the HTTPClient library.

Check the examples for use under HTTP and HTTPS configurations. In general, for HTTP connections (unsecured and very uncommon on the internet today) simply passing in a URL and performing a GET is sufficient to transfer data.

```
// Error checking is left as an exercise for the reader...
HTTPClient http;
if (http.begin("http://my.server/url")) {
    if (http.GET() > 0) {
        String data = http.getString();
    }
    http.end();
}
```

For HTTPS connections, simply add the appropriate WiFiClientSecure calls as needed (i.e. `setInsecure()`, `setTrustAnchor`, etc.). See the WiFiClientSecure documentation for more details.

```
// Error checking is left as an exercise for the reader...
HTTPClient https;
https.setInsecure(); // Use certs, but do not check their authenticity
if (https.begin("https://my.secure.server/url")) {
    if (https.GET() > 0) {
        String data = https.getString();
    }
    https.end();
}
```

Unlike the ESP8266 and ESP32 HTTPClient implementations it is not necessary to create a WiFiClient or WiFiClientSecure to pass in to the HTTPClient object.

OTA UPDATES

50.1 Introduction

OTA (Over the Air) update is the process of uploading firmware to a Pico using a Wi-Fi, Ethernet, or other connection rather than a serial port. This is especially useful for WiFi enabled Picos, like the Pico W, because it lets systems be updated remotely, without needing physical access.

OTA may be done using:

- *Arduino IDE*
- *Web Browser*
- *HTTP Server*
- Any other method (ZModem receive over a UART port, etc.) by using the `Updater` object in your sketch

The Arduino IDE option is intended primarily for the software development phase. The other two options would be more useful after deployment, to provide the module with application updates either manually with a web browser, or automatically using an HTTP server.

In any case, the first firmware upload has to be done over a serial port. If the OTA routines are correctly implemented in the sketch, then all subsequent uploads may be done over the air.

By default, there is no imposed security for the OTA process. It is up to the developer to ensure that updates are allowed only from legitimate / trusted sources. Once the update is complete, the module restarts, and the new code is executed. The developer should ensure that the application running on the module is shut down and restarted in a safe manner. Chapters below provide additional information regarding security and safety of OTA updates.

50.1.1 OTA Requirements

OTA requires a LittleFS partition to store firmware upgrade files. Make sure that you configure the sketch with a filesystem large enough to handle whatever size firmware binary you expect. Updates may be compressed, minimizing the total space needed.

50.1.2 Power Fail Safety

The update commands are all stored in flash, so a power cycle during update (except if the OTA bootloader is being changed) should not brick the device because when power is restored the OTA bootloader will begin the process from scratch once again.

50.1.3 Security Disclaimer

No guarantees as to the level of security provided for your application by the following methods is implied. Please refer to the GNU LGPL license associated for this project for full disclaimers. If you do find security weaknesses, please don't hesitate to contact the maintainers or supply pull requests with fixes. The MD5 verification and password protection schemes are already known to supply a very weak level of security.

50.1.4 Basic Security

The module has to be exposed wirelessly to get it updated with a new sketch. That poses a risk of the module being violently hacked and programmed with some other code. To reduce the likelihood of being hacked, consider protecting your uploads with a password, selecting certain OTA port, etc.

Check functionality provided with the [ArduinoOTA](#) library that may improve security:

```
void setPort(uint16_t port);
void setHostname(const char* hostname);
void setPassword(const char* password);
```

Certain basic protection is already built in and does not require any additional coding by the developer. [ArduinoOTA](#) and [esptota.py](#) use [Digest-MD5](#) to authenticate uploads. Integrity of transferred data is verified on the Pico side using [MD5](#) checksum.

Make your own risk analysis and, depending on the application, decide what library functions to implement. If required, consider implementation of other means of protection from being hacked, like exposing modules for uploads only according to a specific schedule, triggering OTA only when the user presses a dedicated “Update” button wired to the Pico, etc.

50.1.5 Advanced Security - Signed Updates

While the above password-based security will dissuade casual hacking attempts, it is not highly secure. For applications where a higher level of security is needed, cryptographically signed OTA updates can be required. This uses SHA256 hashing in place of MD5 (which is known to be cryptographically broken) and RSA-2048 bit level public-key encryption to guarantee that only the holder of a cryptographic private key can produce signed updates accepted by the OTA update mechanisms.

Signed updates are updates whose compiled binaries are signed with a private key (held by the developer) and verified with a public key (stored in the application and available for all to see). The signing process computes a hash of the binary code, encrypts the hash with the developer's private key, and appends this encrypted hash (also called a signature) to the binary that is uploaded (via OTA, web, or HTTP server). If the code is modified or replaced in any way by anyone except the holder of the developer's private key, the signature will not match and the Pico will reject the upload.

Cryptographic signing only protects against tampering with binaries delivered via OTA. If someone has physical access, they will always be able to flash the device over the serial port. Signing also does not encrypt anything but the hash (so that it can't be modified), so this does not protect code inside the device: if a user has physical access they can read out your program.

Securing your private key is paramount. The same private/public key pair that was used with the original upload must also be used to sign later binaries. Loss of the private key associated with a binary means that you will not be able to OTA-update any of your devices in the field. Alternatively, if someone else copies the private key, then they will be able to use it to sign binaries which will be accepted by the Pico.

Signed Binary Format

The format of a signed binary is compatible with the standard binary format, and can be uploaded to a non-signed Pico via serial or OTA without any conditions. Note, however, that once an unsigned OTA app is overwritten by this signed version, further updates will require signing.

As shown below, the signed hash is appended to the unsigned binary, followed by the total length of the signed hash (i.e., if the signed hash was 64 bytes, then this uint32 data segment will contain 64). This format allows for extensibility (such as adding a CA-based validation scheme allowing multiple signing keys all based on a trust anchor). Pull requests are always welcome. (currently it uses SHA256 with RSASSA-PKCS1-V1_5-SIGN signature scheme from RSA PKCS #1 v1.5)

```
NORMAL-BINARY <SIGNATURE> <uint32 LENGTH-OF-SIGNATURE>
```

Signed Binary Prerequisites

OpenSSL is required to run the standard signing steps, and should be available on any UNIX-like or Windows system. As usual, the latest stable version of OpenSSL is recommended.

Signing requires the generation of an RSA-2048 key (other bit lengths are supported as well, but 2048 is a good selection today) using any appropriate tool. The following shell commands will generate a new public/private key pair. Run them in the sketch directory:

```
openssl genrsa -out private.key 2048
openssl rsa -in private.key -outform PEM -pubout -out public.key
```

Automatic Signing

The simplest way of implementing signing is to use the automatic mode, which presently is only possible on Linux and Mac due to some of the tools not being available for Windows. This mode uses the IDE to configure the source code to enable signing verification with a given public key, and signs binaries as part of the standard build process using a given public key.

To enable this mode, just include *private.key* and *public.key* in the sketch *.ino* directory. The IDE will call a helper script (*tools/signing.py*) before the build begins to create a header to enable key validation using the given public key, and to actually do the signing after the build process, generating a *sketch.bin.signed* file. When OTA is enabled (ArduinoOTA, Web, or HTTP), the binary will automatically only accept signed updates.

When the signing process starts, the message:

```
Enabling binary signing
```

will appear in the IDE window before a compile is launched. At the completion of the build, the signed binary file will be displayed in the IDE build window as:

```
Signed binary: /full/path/to/sketch.bin.signed
```

If you receive either of the following messages in the IDE window, the signing was not completed and you will need to verify the *public.key* and *private.key*:

```
Not enabling binary signing
... or ...
Not signing the generated binary
```

Manual Signing of Binaries

Users may also manually sign executables and require the OTA process to verify their signature. In the main code, before enabling any update methods, add the following declarations and function call:

```
<in globals>
BearSSL::PublicKey signPubKey( ... key contents ... );
BearSSL::HashSHA256 hash;
BearSSL::SigningVerifier sign( &signPubKey );
...
<in setup()>
Update.installSignature( &hash, &sign );
```

The above snippet creates a BearSSL public key and a SHA256 hash verifier, and tells the Update object to use them to validate any updates it receives from any method.

Compile the sketch normally and, once a *.bin* file is available, sign it using the signer script:

```
<PicoArduinoPath>/tools/signing.py --mode sign --privatekey <path-to-private.key> --bin
↳<path-to-unsigned-bin> --out <path-to-signed-binary>
```

50.2 Compression

The bootloader incorporates a GZIP decompressor, built for very low code requirements. For applications, this optional decompression is completely transparent.

No changes to the application are required. The *Updater* class and bootloader (which performs actual application overwriting on update) automatically search for the *gzip* header in the uploaded binary, and if found, handle it.

Compress an application *.bin* file or filesystem package using any *gzip* available, at any desired compression level (*gzip -9* is recommended because it provides the maximum compression and uncompresses as fast as any other compression level). For example:

```
gzip -9 sketch.bin # Maximum compression, output sketch.bin.gz
<Upload the resultant sketch.bin.gz>
```

If signing is desired, sign the *gzip* compressed file *after* compression.

```
gzip -9 sketch.bin
<PicoPath>/tools/signing.py --mode sign --privatekey <path-to-private.key> --bin sketch.
↳bin.gz --out sketch.bin.gz.signed
```

50.2.1 Safety

The OTA process consumes some of the Pico's resources and bandwidth during upload. Then, the module is restarted and a new sketch executed. Analyse and test how this affects the functionality of the existing and new sketches.

If the Pico is in a remote location and controlling some equipment, you should devote additional attention to what happens if operation of this equipment is suddenly interrupted by the update process. Therefore, decide how to put this equipment into a safe state before starting the update. For instance, your module may be controlling a garden watering system in a sequence. If this sequence is not properly shut down and a water valve is left open, the garden may be flooded.

The following functions are provided with the [ArduinoOTA](#) library and intended to handle functionality of your application during specific stages of OTA, or on an OTA error:

```
void onStart(OTA_CALLBACK(fn));
void onEnd(OTA_CALLBACK(fn));
void onProgress(OTA_CALLBACK_PROGRESS(fn));
void onError(OTA_CALLBACK_ERROR(fn));
```

50.3 Uploading from the Arduino IDE

Uploading modules wirelessly from Arduino IDE is intended for the following typical scenarios:

- During firmware development as a quicker alternative to loading over a serial port,
- For updating a small number of modules,
- Only if modules are accessible on the same network as the computer with the Arduino IDE.
- For all IDE uploads, the Pico W and the computer must be connected to the same network.

To upload wirelessly from the IDE:

1. Build a sketch that starts WiFi and includes the appropriate calls to `ArduinoOTA` (see the examples for reference). These include the `ArduinoOTA.begin()` call in `setup()` and periodically calling `ArduinoOTA.handle()`; from the `loop()`
2. Upload using standard USB connection the first time.
3. The `Tools->Port` should now list `pico-#####` under the `Network Ports`. Select it (you won't be able to use the serial monitor, of course).
4. Try another upload. It should display the OTA process in place of the serial port upload.

50.4 Password Protection

Protecting your OTA uploads with a password is really straightforward. All you need to do, is to include the following statement in your code:

```
ArduinoOTA.setPassword((const char *)"123");
```

Where 123 is a sample password that you should replace with your own.

Before implementing it in your sketch, it is a good idea to check how it works using `BasicOTA.ino` sketch available under `File > Examples > ArduinoOTA`. Go ahead, open `BasicOTA.ino`, uncomment the above statement that is already there, and upload the sketch. To make troubleshooting easier, do not modify example sketch besides what is absolutely required. This includes the original simple 123 OTA password. Then attempt to upload a sketch again (using OTA). After compilation is complete, once upload is about to begin, you should see a prompt for password.

Enter the password and upload should be initiated as usual with the only difference being `Authenticating...OK` message visible in the upload log.

You will not be prompted for a reentering the same password next time. Arduino IDE will remember it for you. You will see a prompt for password only after reopening the IDE, or if you change it in your sketch, upload the sketch and then try to upload it again.

Please note, it is possible to reveal password entered previously in Arduino IDE, if the IDE has not been closed since last upload. This can be done by enabling `Show verbose output during: upload` in `File > Preferences` and attempting to upload the module.

50.5 Web Browser

Updates described in this chapter are done with a web browser that can be useful in the following typical scenarios:

- after application deployment if loading directly from Arduino IDE is inconvenient or not possible,
- after deployment if user is unable to expose module for OTA from external update server,
- to provide updates after deployment to small quantity of modules when setting an update server is not practicable.

50.5.1 Requirements

- The Pico and the computer must be connected to the same network, or the IP of the Pico should be known if on a different network.

50.5.2 Implementation Overview

Updates with a web browser are implemented using `HTTPUpdateServer` class together with `WebServer` and `LEAmDNS` or `SimpleMDNS` classes. The following code is required to get it work:

`setup()`

```
MDNS.begin(host);

httpUpdater.setup(&httpServer);
httpServer.begin();

MDNS.addService("http", "tcp", 80);
```

`loop()`

```
httpServer.handleClient();
```

In case OTA update fails dead after entering modifications in your sketch, you can always recover module by loading it over a serial port. Then diagnose the issue with sketch using Serial Monitor. Once the issue is fixed try OTA again.

50.6 HTTP Server

`HTTPUpdate` class can check for updates and download a binary file from HTTP web server. It is possible to download updates from every IP or domain address on the network or Internet.

Note that by default this class closes all other connections except the one used by the update, this is because the update method blocks. This means that if there's another application receiving data then TCP packets will build up in the buffer leading to out of memory errors causing the OTA update to fail. There's also a limited number of receive buffers available and all may be used up by other applications.

There are some cases where you know that you won't be receiving any data but would still like to send progress updates. It's possible to disable the default behaviour (and keep connections open) by calling `closeConnectionsOnUpdate(false)`.

50.6.1 Requirements

- web server

50.6.2 Arduino code

Simple updater

Simple updater downloads the file every time the function is called.

```
WiFiClient client;
HTTPUpdate.update(client, "192.168.0.2", 80, "/arduino.bin");
```

Advanced updater

It's possible to point the update function to a script on the server. If a version string argument is given, it will be sent to the server. The server side script can use this string to check whether an update should be performed.

The server-side script can respond as follows: - response code 200, and send the firmware image, - or response code 304 to notify Pico that no update is required.

```
WiFiClient client;
t_httpUpdate_return ret = HTTPUpdate.update(client, "192.168.0.2", 80, "/pico/update/
↪arduino.php", "optional current version string here");
switch(ret) {
    case HTTP_UPDATE_FAILED:
        Serial.println("[update] Update failed.");
        break;
    case HTTP_UPDATE_NO_UPDATES:
        Serial.println("[update] Update no Update.");
        break;
    case HTTP_UPDATE_OK:
        Serial.println("[update] Update ok.");
        break;
}
```

TLS updater

Please read and try the examples provided with the library.

50.6.3 Server request handling

Simple updater

For the simple updater the server only needs to deliver the binary file for update.

Advanced updater

For advanced update management a script (such as a PHP script) can run on the server side. It will receive the following headers which it may use to choose a specific firmware file to serve:

```
::
[User-Agent] => Pico-HTTP-Update [x-Pico-STA-MAC] => 18:FE:AA:AA:AA:AA [x-Pico-AP-MAC] =>
1A:FE:AA:AA:AA:AA [x-Pico-Version] => DOOR-7-g14f53a19 [x-Pico-Mode] => sketch
```

50.7 Stream Interface

The Stream Interface is the base for all other update modes like OTA, HTTP Server / client. Given a Stream-class variable *streamVar* providing *byteCount* bytes of firmware, it can store the firmware as follows:

```
Update.begin(firmwareLengthInBytes);
Update.writeStream(streamVar);
Update.end();
```

50.7.1 OTA Bootloader and Memory Map

A firmware file is uploaded via any method (Ethernet, WiFi, serial ZModem, etc.) and stored on the LittleFS filesystem as a normal file. The Updater class (or the underlying PicoOTA) will make a special “OTA command” file on the filesystem, which will be read by the OTA bootloader. On a reboot, this OTA bootloader will check for an upgrade file, verify its contents, and then perform the requested update and reboot. If no upgrade file is present, the OTA bootloader simply jumps to the main sketch.

The ROM layout consists of:

```
[boot2.S] [OTA Bootloader] [0-pad] [OTA partition table] [Main sketch] [LittleFS_
↪filesystem] [EEPROM]
```

LIBRARIES PORTED/OPTIMIZED FOR THE RP2040

Most Arduino libraries that work on modern 32-bit CPU based Arduino boards will run fine using Arduino-Pico.

The following libraries have undergone additional porting and optimizations specifically for the RP2040 and you should consider using them instead of the generic versions available in the Library Manager

- [Adafruit GFX Library](#) by @Bodmer, 2-20x faster than the standard version on the Pico
- [Adafruit ILI9341 Library](#) again by @Bodmer
- [ESP8266Audio](#) ported to use the included I2S library

USING THE RASPBERRY PI PICO SDK (PICO-SDK)

52.1 Included SDK

A complete copy of the [Raspberry Pi Pico SDK](#) is included with the Arduino core, and all functions in the core are available inside the standard link libraries.

For simple programs wishing to call these functions, simply include the appropriate header as shown below

```
#include "pico/stdlib.h"

void setup() {
    const uint LED_PIN = 25;
    gpio_init(LED_PIN);
    gpio_set_dir(LED_PIN, GPIO_OUT);
    while (true) {
        gpio_put(LED_PIN, 1);
        sleep_ms(250);
        gpio_put(LED_PIN, 0);
        sleep_ms(250);
    }
}

void loop() {}
```

Note: When you call SDK functions in your own app, the core and libraries are not aware of any changes to the Pico you perform. So, you may break the functionality of certain libraries in doing so.

52.2 Multicore (CORE1) Processing

Warning: While you may spawn multicore applications on CORE1 using the SDK, the Arduino core may have issues running properly with them. In particular, anything involving flash writes (i.e. EEPROM, filesystems) will probably crash due to CORE1 attempting to read from flash while CORE0 is writing to it.

52.3 PIOASM (Compiling for the PIO processors)

A precompiled version of the PIOASM tool is included in the download package and can be run from the CLI.

There is also a fully online version of PIOASM that runs in a web browser without any CLI required, thanks to @jake653: <https://wokwi.com/tools/pioasm> (GitHub source: <https://github.com/wokwi/pioasm-wasm>)

There is also Docker code available for the tool at: <https://github.com/kahara/pioasm-docker>

LICENSING AND CREDITS

Arduino-Pico is licensed under the LGPL license as detailed in the included README.

In addition, it contains code from additional open source projects:

- The [Arduino IDE](#) and [ArduinoCore-API](#) are developed and maintained by the Arduino team. The IDE is licensed under [GPL](#).
- The [RP2040 GCC-based toolchain](#) is licensed under under the [GPL](#).
- The [Pico-SDK](#) and [Pico-Extras](#) are by Raspberry Pi (Trading) Ltd. and licensed under the [BSD 3-Clause license](#).
- [Arduino-Pico](#) core files are licenses under the [LGPL](#).
- [LittleFS](#) library written by ARM Limited and released under the [BSD 3-clause license](#) .
- [UF2CONV.PY](#) is by Microsoft Corporation and licensed under the [MIT license](#).
- Some filesystem code taken from the [ESP8266 Arduino Core](#) and licensed under the [LGPL](#).